TABLE OF CONTENTS

1	Before driving	Adjusting and operating features such as door locks, mirrors, and steering column.	
2	When driving	Driving, stopping and safe-driving information.	
3	Interior features	Air conditioning and audio systems, as well as other in- terior features for a comfortable driving experience.	
4	Maintenance and care	Cleaning and protecting your vehicle, performing do-it- yourself maintenance, and maintenance information.	
5	When trouble arises	What to do if the vehicle needs to be towed, gets a flat tire, or is involved in an accident.	
6	Vehicle specifications	Detailed vehicle information.	
7	For owners	Reporting safety defects for U.S. owners, and seat belt and SRS airbag instructions for Canadian owners	
	Index	Alphabetical listing of information contained in this manual.	

TABLE OF CONTENTS Index

1 Before driving					
1-1.	Key information				
	Keys	24			
1-2.	Opening, closing and lockin the doors	ng			
	Wireless remote control	26			
	Side doors	30			
	Back door	33			
1-3.	Adjustable components (seats, mirrors, steering wheel)				
	Front seats	37			
	Rear seats	40			
	Seat belts	43			
	Steering wheel	49			
	Anti-glare inside rear view				
	mirror	50			
	Outside rear view mirrors	52			
1-4.	Opening and closing the windows				
	Power windows	55			
1-5.	Refueling				
	Opening the fuel tank cap	58			
1-6.	Theft deterrent system Engine immobilizer				
	system	62			
	Theft prevention labels	64			

1-7. Safety information

Correct driving posture	65
SRS airbags	67
Front passenger occupant	
classification system	81
Child restraint systems	87
Installing child restraints	92

2 When driving

2-1. Driving procedures

Driving the vehicle	104
Engine (ignition) switch	113
Automatic transmission	116
Turn signal lever	117
Parking brake	118
Horn	120

2-2. Instrument cluster

Gauges and meters	121
Indicators and warning	
lights	123
Multi-information display	126

2-3. Operating the lights and wipers

Headlight switch	132
Windshield wipers and	
washer	136
Rear window wiper and	
washer	139

2-4. Using other driving systems Driving assist systems 141

2-5. Driving information

Cargo and luggage	146
Vehicle load limits	150
Winter driving tips	151
Trailer towing	155
Dinghy towing	156

3 Interior features

3-1.	Using the air conditioning
	system and defogger

Air conditioning system	158
Rear window defogger	164
Rear window and outside	
rear view mirror	
defoggers	165

3-2. Using the audio system

Using the AUX port/	
USB port	167
Using the steering wheel	
audio switches	168

3-3. Using the interior lights

Interior lights list	169
Interior light	170

3-4. Using the storage features

L	ist	of	storage	features		171	
---	-----	----	---------	----------	--	-----	--

- Cup holder 172

3-5. Other interior features

Sun visors	175
Vanity mirrors	176
Power outlet	177
Assist grips	178
Floor mat	179
Luggage compartment	
features	181

4 Maintenance and care

4-1. Maintenance and care

Cleaning and protecting the vehicle exterior	184
Cleaning and protecting the vehicle interior	187

4-2. Maintenance

190
192
195

4-3. Do-it-yourself maintenance

Do-it-yourself service	
precautions	196
Hood	199
Positioning a floor jack	201
Replacing the tire	204
Engine compartment	210
Tires	222
Tire inflation pressure	230
Wheels	234
Air conditioning filter	236

2

4

.....

TABLE OF CONTENTS Index

Key battery	240
Checking and replacing	
fuses	244
Light bulbs	255

5 When trouble arises

5-1. Essential information

Emergency flashers	268
If your vehicle needs to	
be towed	269
If you think something	
is wrong	275
Fuel pump shut off	
system	276

5-2. Steps to take in an emergency

If a warning light turns on	
or a warning buzzer	
sounds	277
If you have a flat tire	288
If the engine will not start	305
If the shift lever cannot	
be shifted from P	307
If you lose your keys	308
If the vehicle battery	
is discharged	309
If your vehicle overheats	312
If the vehicle becomes	
stuck	315
If your vehicle has to	
be stopped in	
an emergency	317

6 Vehicle specifications

6-1. Specifications

Maintenance data	
(fuel, oil level, etc.)	320
Fuel information	329
Tire information	332

6-2. Customization

Customizable features	343
Items to initialize	345


For owners


Reporting safety defects for U.S. owners	348
Seat belt instructions	
for Canadian owners	
(in French)	349
SRS airbag instructions	
for Canadian owners	
(in French)	351


Index


Abbreviation list	362
Alphabetical index	363
What to do if	372


Þ





























For your information

Main Owner's Manual

Please note that this manual applies to all models and all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Scion policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of equipment.

Noise from under vehicle after turning off the engine

Approximately five hours after the engine is turned off, you may hear sound coming from under the vehicle for several minutes. This is the sound of a fuel evaporation leakage check and, it does not indicate a malfunction.

Accessories, spare parts and modification of your Scion

A wide variety of non-genuine spare parts and accessories for Scion vehicles are currently available in the market. You should know that Toyota does not warrant these products and is not responsible for their performance, repair, or replacement, or for any damage they may cause to, or adverse effect they may have on, your Scion vehicle.

This vehicle should not be modified with non-genuine Scion products. Modification with non-genuine Scion products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

Installation of a mobile two-way radio system

The installation of a mobile two-way radio system in your vehicle could affect electronic systems such as:

- Multiport fuel injection system/sequential multiport fuel injection system
- Anti-lock brake system
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with your Scion dealer for precautionary measures or special instructions regarding installation of a mobile two-way radio system.

Vehicle data recordings

Your Scion is equipped with several sophisticated computers that will record certain data, such as:

- Engine speed
- Accelerator status
- Brake status
- Vehicle speed
- Shift position

The recorded data varies according to the vehicle grade level and options with which it is equipped. Furthermore, these computers do not record conversations, sounds or pictures.

Data usage

Scion may use the data recorded in these computers to diagnose malfunctions, conduct research and development, and improve quality.

Scion will not disclose the recorded data to a third party except:

- With the consent of the vehicle owner or with the consent of the lessee if the vehicle is leased
- In response to an official request by the police, a court of law or a government agency
- For use by Scion in a lawsuit
- For research purposes where the data is not tied to a specific vehicle or vehicle owner

Event data recorder

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- · How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR. • Disclosure of the EDR data

Scion will not disclose the data recorded in an EDR to a third party except when:

- An agreement from the vehicle's owner (or the lessee for a leased vehicle) is obtained
- In response to an official request by the police, a court of law or a government agency
- For use by Scion in a lawsuit

However, if necessary, Scion may:

- Use the data for research on vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing information about the specific vehicle or vehicle owner

Scrapping of your Scion

The SRS airbag and seat belt pretensioner devices in your Scion contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Scion dealer before you scrap your vehicle.

Perchlorate Material

Special handling may apply,

See www.dtsc.ca.gov/hazardouswaste/perchlorate.

Your vehicle has components that may contain perchlorate. These components may include airbag, seat belt pretensioners, and wireless remote control batteries.

CAUTION

General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the cigarette lighter, the windows, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

Symbols used throughout this manual

Cautions & Notices

CAUTION

This is a warning against something which, if ignored, may cause death or serious injury to people. You are informed about what you must or must not do in order to reduce the risk of death or serious injury to yourself and others.

NOTICE


This is a warning against something which, if ignored, may cause damage to the vehicle or its equipment. You are informed about what you must or must not do in order to avoid or reduce the risk of damage to your Scion and its equipment.

Symbols used in illustrations



Safety symbol

The symbol of a circle with a slash through it means "Do not", "Do not do this", or "Do not let this happen".



Arrows indicating operations

- Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
- ☐>Indicates the outcome of an operation (e.g. a lid opens).

Before driving

1


1-1.	Key information	
	Keys	24
1-2.	Opening, closing and locki the doors	ng
	Wireless remote control	26
	Side doors	30
	Back door	33
1-3.	Adjustable components (seats, mirrors, steering wheel)	
	Front seats	37
	Rear seats	40
	Seat belts	43
	Steering wheel	49
	Anti-glare inside rear view mirror	50
	Outside rear view mirrors	
1-4.	Opening and closing the windows	
	Power windows	55

-5.	Refueling Opening the fuel tank cap	58
-6.	Theft deterrent system Engine immobilizer	
	system	62
	Theft prevention labels	64
-7.	Safety information	
	Correct driving posture	65
	SRS airbags	67
	Front passenger occupant	
	classification system	81
	Child restraint systems	87
	Installing child restraints	92


1-1. Key information **Keys**

The following keys are provided with the vehicle.


► Type A



► Type B



► Type C



Keys (with a wireless remote control function)

Operating the wireless remote control function (\rightarrow P. 26)

- 2 Key (without a wireless remote control function)
- 3 Key number plate

1 Keys

Operating the wireless remote control function (\rightarrow P. 26)


2 Key number plate

1 Keys

Operating the wireless remote control function (\rightarrow P. 26)

2 Key number plate

Using the master key (type C)



Press the button to open the key.

To stow, press the button then fold the key.

Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. In the event that a key is lost, a new key can be made by your Scion dealer using the key number plate. (\rightarrow P. 308)

When riding in an aircraft

When bringing a wireless remote control key onto an aircraft, make sure you do not press any buttons on the wireless remote control key while inside the aircraft cabin. If you are carrying a wireless remote control key in your bag etc, ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the wireless remote control key to emit radio waves that could interfere with the operation of the aircraft.

NOTICE

To prevent key damage


Do not subject the keys to strong shocks, expose them to high temperatures by placing them in direct sunlight, or get them wet.

 Do not expose the keys to electromagnetic materials or attach any material that blocks electromagnetic waves to the key surface.


1-2. Opening, closing and locking the doors Wireless remote control

The wireless remote control can be used to lock/unlock the vehicle from outside the vehicle.

► Type A



► Type B



1 Locks all doors

Check that the door is securely locked.

2 Unlocks all doors

Pressing the button unlocks the driver's door. Pressing the button again within 3 seconds unlocks the other doors.

- Sounds alarm (push and hold)
- 1 Locks all doors

Check that the door is securely locked.

2 Sounds alarm (push and hold)

3 Unlocks all doors

Pressing the button unlocks the driver's door. Pressing the button again within 3 seconds unlocks the other doors.

Operation signals

The emergency flashers flash to indicate that the doors have been locked/ unlocked. (Locked: Once; Unlocked: Twice)

Panic mode



When $\overset{\text{HOLD}}{(r)}$ is pushed for longer than about one second, an alarm will sound for about 60 seconds and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, push any button on the wireless remote control.

Key battery depletion

The standard battery life is 1 to 2 years. (The battery becomes depleted even if the key is not used.) If the wireless remote control function does not operate, the battery may be depleted. Replace the battery when necessary. (\rightarrow P. 240)

Security feature

If a door is not opened within approximately 60 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

Conditions affecting operation

The wireless remote control function may not operate normally in the following situations.

- Near a TV tower, radio station, electric power plant, airport, gas station or other facility that generates strong radio waves
- When carrying a portable radio, cellular phone or other wireless communication device
- When multiple wireless keys are in the vicinity
- When the wireless key has come into contact with, or is covered by a metallic object
- When a wireless key (that emits radio waves) is being used nearby
- When the wireless key has been left near an electrical appliance such as a personal computer

Customization that can be configured at Scion dealer

Settings (e.g. wireless remote control system) can be changed. (Customizable features \rightarrow P. 343)

Certification for wireless remote control

For vehicles sold in U.S.A.

FCC ID: MOZB41RH FCC ID: MOZB52TH

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For vehicles sold in Canada

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

► For vehicles sold in U.S.A.

FCC ID: MOZB95TH

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The FCC ID/IC Certification number is affixed inside the equipment. You can find the ID/number when replacing the battery.

For vehicles sold in Canada

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

The FCC ID/IC Certification number is affixed inside the equipment. You can find the ID/number when replacing the battery.


1-2. Opening, closing and locking the doors **Side doors**

The vehicle can be locked and unlocked using the wireless remote control, key or door lock switch.

Wireless remote control

→P. 26

Key




Door lock switch

► For driver's use

1 Locks all doors

2 Unlocks all doors

Turning the key a single time in the driver's door unlocks the driver's door, and turning the key again unlocks the other doors.




Unlocks all doors
 Locks all doors

TY12AJZ08

► For front passenger's use

Locks all doors
 Unlocks all doors

Inside door lock button



Locks the door Unlocks the door

Pulling the inside handle can open the side doors even if the lock button is in the lock position.

Locking the side doors from the outside without a key

STEP 1 Move the inside door lock button to the lock position.

STEP 2 Close the door.

The door cannot be locked if the key is in the engine switch.

Key reminder buzzer

A buzzer sounds if the driver's door is opened, while the engine switch is in the ACC or LOCK position to remind you to remove the key.

Customization that can be configured at Scion dealer

Settings (e.g. unlocking function using a key) can be changed. (Customizable features \rightarrow P. 343)

CAUTION

To prevent an accident

Observe the following precautions while driving the vehicle. Failing to do so may result in a door opening and an occupant falling out, resulting in death or serious injury.

- Always use a seat belt.
- Always lock all doors.
- Ensure that all doors are properly closed.
- Do not pull the inside handle of the doors while driving. The doors may be opened and the passengers are thrown out of the vehicle and it may result in serious injury or death.
- Be especially careful for the side doors, as the doors may be opened even if the inside lock buttons are in locked position.

1-2. Opening, closing and locking the doors Back door

The back door can be locked/unlocked and opened by the following procedures.


- Locking and unlocking the back door
- ► Door lock switch
 - →P. 30
- ► Wireless remote control

→P. 26

►Key

→P. 24


Opening the back door from outside the vehicle



Raise the back door while pushing up the back door opener switch.

The back door cannot be closed immediately after the back door opener switch is pushed.

When closing the back door



Lower the back door using the back door handle, and make sure to push the back door down from the outside to close it.

CAUTION

Caution while driving

Keep the back door closed while driving.

If the back door is left open, it may hit near-by objects while driving or luggage may be unexpectedly thrown out, causing an accident.

In addition, exhaust gases may enter the vehicle, causing death or a serious health hazard. Make sure to close the back door before driving.

Before driving the vehicle, make sure that the back door is fully closed. If the back door is not fully closed, it may open unexpectedly while driving, causing an accident.

Never let anyone sit in the luggage compartment. In the event of sudden braking or a collision, they are susceptible to death or serious injury.

When children are in the vehicle

Observe the following precautions. Failure to do so may result in death or serious injury.

- Do not allow children to play in the luggage compartment.
 If a child is accidentally locked in the luggage compartment, they could have heat exhaustion or other injuries.
- Do not allow a child to open or close the back door. Doing so may cause the back door to move unexpectedly, or cause the child's hands, head, or neck to be caught by the closing back door.

Operating the back door

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in death or serious injury.

- Remove any heavy loads, such as snow and ice, from the back door before opening it. Failure to do so may cause the back door to suddenly shut again after it is opened.
- When opening or closing the back door, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the back door is about to open or close.

 Use caution when opening or closing the back door in windy weather as it may move abruptly in strong wind.

Operating the back door





- The back door may suddenly shut if it is not opened fully. It is more difficult to open or close the back door on an incline than on a level surface, so beware of the back door unexpectedly opening or closing by itself. Make sure that the back door is fully open and secure before using the luggage compartment.
- When closing the back door, take extra care to prevent your fingers etc. from being caught.
- When closing the back door, make sure to press it lightly on its outer surface. If the back door handle is used to fully close the back door, it may result in hands or arms being caught.
- Do not pull on the back door damper stay to close the back door, and do not hang on the back door damper stay.

Doing so may cause hands to be caught or the back door damper stay to break, causing an accident.

If a bicycle carrier or similar heavy object is attached to the back door, it may suddenly shut again after being opened, causing someone's hands, head or neck to be caught and injured. When installing an accessory part to the back door, using a genuine Scion part is recommended.


NOTICE

Back door damper stays

The back door is equipped with damper stays that hold the back door in place.

Observe the following precautions.


Failure to do so may cause damage to the back door damper stay, resulting in malfunction.




- Do not attach any foreign objects, such as stickers, plastic sheets, or adhesives to the damper stay rod.
- Do not touch the damper stay rod with gloves or other fabric items.
- Do not attach any heavy accessory to the back door. Scion recommends genuine Scion parts.
- Do not place your hand on the damper stay or apply lateral forces to it.

1-3. Adjustable components (seats, mirrors, steering wheel) **Front seats**

► Type A



- Seat position adjustment lever
- 2 Seatback angle adjustment lever
- Seatback angle adjustment lever (passenger's seat only)



Moving the front passenger's seat

For easy access to the rear seat.

STEP 1 Lift up the seatback angle adjustment lever.

When the seatback is folded to the forward limit, the seat can slide back and forth.

STEP 2 Slide the seat to the front-most position.

After rear passengers are in, lift up the seatback and return the seat until it locks.

By raising the seatback, the seat locks at the upright position.

Head restraints

Head restraints are provided for all front seats.

The head restraints do not have adjustment function.

CAUTION

Seat adjustment

- When sliding the seat rearward, make sure not to squash the legs of the rear passengers.
- Do not recline the seat more than necessary when the vehicle is in motion to reduce the risk of sliding under the lap belt.

If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.

- After adjusting the seat, make sure that the seat is locked in position.
- When returning the seatback upright, be careful not to be hit by the seatback which will rebound with considerable spring force.
- When operating the front seat from the rear seat, make sure that no passenger is seated in the front seat.

After returning the seatback

Push and pull the seatback to confirm that it is securely locked.

When sitting down or getting up off the rear seat

When sitting down or getting up off the rear seat, make sure not to trip over the seat rail grooves.


Caution while driving

 Never operate the seat position adjustment lever and the seatback angle adjustment lever while driving.


 Do not place anything under the front seats.
 The items may fly out and interrupt pedal operation in events such as sudden braking, and may cause an accident.

1-3. Adjustable components (seats, mirrors, steering wheel) Rear seats


Folding down rear seatbacks



Stow the seat belt buckles.




Press the lock release button and fold down the seatback until it reaches the position where the head restraints can be removed.



Remove the head restraints.


Pull the head restraint up while pushing the lock release button.



Fold down the seatbacks.

Stow the head restraints between seatbacks and seat cushion as shown.

Installing the head restraints



Align the head restraint with the installation holes and push it down to the lock position.

Head restraints

Head restraints are provided for all rear seats.

The head restraints do not have adjustment function.

Observe the following precautions. Failure to do so may result in death or serious injury.

When operating the rear seat

- Do not operate the seat while driving.
- Stop the vehicle on level ground, set the parking brake and shift the shift lever to P.
- Be careful not to get your hands or feet pinched in the seat.
- Do not allow anyone to sit on a folded seatback or in the luggage compartment while driving.
- Do not allow children to enter the luggage compartment.

After returning the rear seats to their original position

- Make sure the seatbacks are securely locked.
- Check that the seat belts are not twisted or caught under the seats.

Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Do not drive with the head restraints removed.

▲ NOTICE

Before folding the seatbacks

- The seat belts buckles must be stowed.
- The head restraints must be removed.

When operating the rear seat

Make sure that the rear seat does not come into contact with the front seat. Do not forcibly operate the rear seat. Otherwise, the seat cover may be damaged or the seat may be broken.

1-3. Adjustable components (seats, mirrors, steering wheel) Seat belts


Make sure that all occupants are wearing their seat belts before driving the vehicle.

Correct use of the seat belts




- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.

Fastening and releasing the seat belt



Fastening the belt

Push the tab into the buckle until a clicking sound is heard.




Releasing the belt

Press the release button.


Stowing the seat belts (rear seat)

When not using the seat belt, follow the method and hook the plate into the seat belt holder to fasten the seat belt.



- 1 Flip the plate
- Hook the plate into the seat belt holder.

Seat belt pretensioners (front seats)



The pretensioner helps the seat belt to quickly restrain the occupant by retracting the seat belt when the vehicle is subjected to certain types of severe frontal or side collision.

The pretensioner may not activate in the event of a minor frontal impact, a minor side impact, a rear impact or a vehicle rollover.


Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

Automatic locking retractor (ALR)

When a passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold the child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more. (\rightarrow P. 92)

Pregnant women



Obtain medical advice and wear the seat belt in the proper way. $(\rightarrow P. 43)$

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants. Extend the shoulder belt completely over the shoulder and position the belt across the chest. Avoid belt contact over the rounding of the abdominal area.

If the seat belt is not worn properly, not only a pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.

People suffering illness

Obtain medical advice and wear the seat belt in the proper way.

Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.

- •Use a child restraint system appropriate for the child, until the child become large enough to properly wear the vehicle's seat belt. (\rightarrow P. 87)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions on P. 43 regarding seat belt usage.

Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

Seat belt extender



If your seat belts cannot be fastened securely because they are not long enough, a personalized seat belt extender is available from your Scion dealer free of charge.

CAUTION

Observe the following precautions to reduce the risk of injury in the event of emergency braking, sudden swerving or an accident. Failing to do so may cause death or severe injury.

Wearing a seat belt

- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Scion recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- Do not recline the seat any more than necessary to achieve a proper seating position. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips.

When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

Seat belt pretensioners

Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not activate in the event of a collision.

 If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Scion dealer.

CAUTION

Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belt cannot protect an occupant from death or serious injury.
- Ensure that the belt and tab are locked and the belt is not twisted.
 If the seat belt does not function correctly, immediately contact your Scion dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Scion dealer. Inappropriate handling of the pretensioner may prevent it from operating properly resulting in death or serious injury.

Using a seat belt extender

- Do not wear the seat belt extender, if you can fasten the seat belt without the extender.
- Do not use the seat belt extender when installing a child restraint system, because the belt will not securely hold the child restraint system, increasing the risk of death or serious injury in the event of an accident.
- The personalized extender may not be safe on another vehicle, when used by another person, or at a different seating position other than the one originally intended.


When using a seat belt extender

When releasing the seat belt, press on the buckle release button on the extender, not on the seat belt.


This helps prevent damage to the vehicle interior and the extender itself.

1-3. Adjustable components (seats, mirrors, steering wheel) Steering wheel

The steering wheel can be adjusted to a comfortable position.



Hold the steering wheel and press the lever down.



Adjust to the ideal position by moving the steering wheel vertically.

After adjustment, pull the lever up to secure the steering wheel.

A CAUTION

Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and an accident may occur resulting in death or serious injury.


After adjusting the steering wheel

Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident and resulting in death or serious injury.


1-3. Adjustable components (seats, mirrors, steering wheel) Anti-glare inside rear view mirror

Glare from the headlights of vehicles behind can be reduced by using the following functions.



Normal position
 Anti-glare position

Adjusting the height of rear view mirror



Adjust the height of the rear view mirror by moving it up and down.


CAUTION

Caution while driving

Do not adjust the position of the mirror while driving. Doing so may lead to mishandling of the vehicle and an accident, resulting in death or serious injury.


1-3. Adjustable components (seats, mirrors, steering wheel) Outside rear view mirrors

Mirror angle can be adjusted using the switch.



- Select a mirror to adjust.(L: left or R: right)
- 2 Adjust the mirror up, down, in or out using the switch.

Folding back the mirrors



Push backward to fold the mirrors.

Mirror operating conditions

The engine switch is in the ACC or ON position.

When the mirrors are fogged up (vehicles with outside rear view mirror defoggers)

Turn on the mirror defoggers to defog the mirrors. (\rightarrow P. 165)

CAUTION

When driving the vehicle

Observe the following precautions while driving. Failing to do so may result in loss of control of the vehicle and cause an acci-

dent, resulting in death or serious injury.

Do not adjust the mirrors while driving.

- Do not drive with the mirrors folded back.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

When the mirror defoggers are operating (vehicles with outside rear view mirror defoggers)

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

NOTICE


If ice should jam the mirror

Do not operate the control or scrape the mirror face. Use a spray de-icer to free the mirror.

1-4. Opening and closing the windows **Power windows**

The power windows can be opened and closed using the following switches.

Driver's power window switches




Closing
 One-touch closing*

3 Opening

4 One-touch opening*

*: To stop the window partway, operate the switch in the opposite direction.

Front passenger's power window switch



1 Closing


2 One-touch closing*

3 Opening

4 One-touch opening*

*: To stop the window partway, operate the switch in the opposite direction.

Window lock switch



Press the switch down to lock passenger window switch.

Use this switch to prevent children from accidentally opening or closing a passenger window.

The power windows can be operated when

The engine switch is in the ON position.

Operating the power windows after turning the engine switch off

The power windows can be operated for approximately 45 seconds even after the engine switch is turned off. They cannot, however, be operated once either side door is opened.

Jam protection function

If an object becomes caught between the window and the window frame, window travel is stopped and the window opens slightly.

When the power window does not close normally

If the jam protection function is operating abnormally and a window cannot be closed, perform the following operations using the power window switch on the relevant door.

- After stopping the vehicle, the window can be closed by holding the power window switch in the one-touch closing position while the engine switch is turned to the ON position.
- If the window still cannot be closed even by carrying out the operation explained above, initialize the function by performing the following procedure.
- STEP 1 Hold the power window switch in the one-touch closing position. Continue holding the switch for a further 6 seconds after the window has closed.
- STEP 2 Hold the power window switch in the one-touch opening position. Continue holding the switch for a further 2 seconds after the window has opened completely.
- STEP 3 Hold the power window switch in the one-touch closing position once again. Continue holding the switch for a further 2 seconds after the window has closed.

If you release the switch while the window is moving, start again from the beginning. If the window continues to close but then re-open slightly even after performing the above procedure correctly, have the vehicle inspected by your Scion dealer.

1-4. Opening and closing the windows

CAUTION

Closing the windows

Observe the following precautions. Failing to do so may result in death or serious injury.

The driver is responsible for all the power window operations, including the operation for the passengers. In order to prevent accidental operation, especially by a child, do not let a child operate the power windows. It is possible for children and other passengers to have body parts caught in the power window. Also, when riding with a child, it is recommended to use the window lock switch. (→P. 55)

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- When exiting the vehicle, turn the engine switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

Jam protection function

- Never try jamming any part of your body to activate the jam protection function intentionally.
- The jam protection function may not work if something gets caught just before the window fully closes.


1-5. Refueling Opening the fuel tank cap

Perform the following steps to open the fuel tank cap.

Before refueling the vehicle


Turn the engine switch off and ensure that all the doors and windows are closed.


Opening the fuel tank cap



Pull up the opener to open the fuel filler door.


Turn the fuel tank cap slowly to open.





Hang the fuel tank cap on the back of the fuel filler door.

Closing the fuel tank cap



When replacing the fuel tank cap, turn it until a clicking sound is heard.

After releasing your hand, the cap will turn slightly to the opposite direction.

Fuel types

Unleaded gasoline. (Octane rating 87 [Research Octane Number 91] or higher)

Fuel tank capacity

Approximately 8.5 gal. (32.0 L, 7.0 Imp.gal.)

Fuel gauge

When filled with less than 2.6 gal. (10 L, 2.2 Imp.gal.) per refueling, the fuel gauge may not display accurately.

CAUTION

Refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

 Touch the vehicle or some other metal surface to discharge any static electricity.

Sparks resulting from discharging static electricity may cause the fuel vapors to ignite.

Always hold the grips on the fuel tank cap and turn it slowly to remove it. A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out of the filler neck and cause injury.

- Do not allow anyone that has not discharged static electricity from their bodies to come close to an open fuel tank.
- Do not inhale vaporized fuel.
 Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle.
 Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.

This may cause static electricity to build up, resulting in a possible ignition hazard.

When replacing the fuel tank cap

Do not use anything but a genuine Scion fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

Refueling

Do not spill fuel during refueling.


Doing so may damage the vehicle, such as causing the exhaust systems to operate abnormally or damaging fuel system components or the vehicle's painted surface.

1-6. Theft deterrent system Engine immobilizer system*

The vehicle's keys have built-in transponder chips that prevent the engine from starting if the key has not been previously registered in the vehicle's on-board computer.

Never leave the keys inside the vehicle when you leave the vehicle.

This system is designed to help prevent vehicle theft but does not guarantee absolute security against all vehicle thefts.



The indicator light flashes after the key has been removed from the engine switch to indicate that the system is operating.

The indicator light stops flashing after the registered key has been inserted into the engine switch to indicate that the system has been canceled.

System maintenance

The vehicle has a maintenance-free type engine immobilizer system.

Conditions that may cause the system to malfunction

- If the key is in contact with a metallic object
- If the key is in close proximity to or touching a key to the security system (key with a built-in transponder chip) of another vehicle

Certifications for the engine immobilizer system


For vehicles sold in Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

1-6. Theft deterrent system Theft prevention labels



These labels are attached to the vehicle to reduce vehicle theft by facilitating the tracing and recovery of parts from stolen vehicles. Do not remove under penalty of law.

1-7. Safety information Correct driving posture

Drive in a good posture as follows:



- **1** Sit upright and well back in the seat. $(\rightarrow P. 37)$
- Adjust the position of the seat forward or backward to ensure the pedals can be reached and easily depressed to the extent required. $(\rightarrow P. 37)$
- Adjust the seatback so that the controls are easily operable.
- ▲ Adjust the tilt positions of the steering wheel downward so the airbag is facing your chest. (→P. 49)
- 5 Wear the seat belt correctly. $(\rightarrow P. 43)$

CAUTION

While driving


- Do not adjust the position of the driver's seat while driving.
 Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback.
 A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint, increasing the risk of death or serious injury to the driver or passenger.
- Do not place anything under the front seats. Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident. The adjustment mechanism may also be damaged.

Adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.

Fingers or hands may become jammed in the seat mechanism.

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.



► Front airbags

SRS driver airbag/front passenger airbag Can help protect the head and chest of the driver and front passenger from impact with interior components.

2 SRS knee airbags

Can help provide driver and front passenger protection.

3 SRS seat cushion airbags

Can help restrain the driver and front passenger.


- ► Side and curtain shield airbags
- 4 SRS side airbags

Can help protect the torso of the front seat occupants.

SRS curtain shield airbags Can help protect primarily the head of occupants.SRS rear window curtain shield airbag

Can help protect primarily the head of rear occupants.

SRS airbag system components



- Rear airbag sensors
- Curtain shield airbag sensors
- 3 Curtain shield airbags
- AIR BAG ON and AIR BAG OFF indicator lights
- 5 Side airbags
- Passenger seat cushion airbag
- 7 Front passenger airbag
- 8 Knee airbags
- Seat belt pretensioners and force limiters
- Side and curtain shield airbag sensors

- Front passenger occupant classification system (ECU and sensors)
- 12 Front airbag sensors
- Airbag sensor assembly
- Front passenger's seat belt buckle switch
- Rear window curtain shield airbag
- 16 SRS warning light
- 17 Driver airbag
- Driver's seat belt buckle switch
- Driver's seat position sensor
- 20 Driver seat cushion airbag

Your vehicle is equipped with ADVANCED AIRBAGS designed based on the US motor vehicle safety standards (FMVSS208). The airbag sensor assembly (ECU) controls airbag deployment based on information obtained from the sensors etc. shown in the system components diagram above. This information includes crash severity and occupant information. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

If the SRS airbags deploy (inflate)

- Bruising and slight abrasions may result from contact with a deploying (inflating) SRS airbag.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the front seats, and parts of the front and rear pillars, roof side rail and rear roof headlining may be hot for several minutes. The airbag itself may also be hot.
- The front windshield may crack.

Operating conditions (SRS front airbags)

 The SRS front airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 12-18 mph [20-30 km/h] frontal collision with a fixed wall that does not move or deform).

However, this threshold velocity will be considerably higher if the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact, or if the vehicle is involved in an underride collision (e.g. a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck, etc.).

- Depending on the type of collision, it is possible that only the seat belt pretensioners will activate.
- The SRS front airbags for the front passenger will not activate if there is no passenger sitting in the front passenger seat. However, the SRS front airbags for the front passenger may deploy if luggage is put in the seat, even if the seat is unoccupied. (\rightarrow P. 81)

- The SRS seat cushion airbags on the front seats will not operate if the occupant is not wearing a seat belt.
- Operating conditions (SRS side airbags and SRS curtain shield airbags)
 - The SRS side airbags and SRS curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 3300 lb. [1500 kg] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 12-18 mph [20-30 km/h]).
 - The SRS side airbags and SRS curtain shield airbags may also deploy in the event of a severe rear collision.
 - The SRS curtain shield airbags may also deploy in the event of a severe frontal collision.


Operating conditions (SRS rear window curtain shield airbag)

The SRS rear window curtain shield airbag is designed to inflate when the passenger compartment is subjected to a severe impact from the rear or side.

Conditions under which the SRS airbags may deploy (inflate), other than a collision

Front airbags


The SRS front airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.



- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or vehicle falling

► Rear window curtain shield airbag


The SRS rear window curtain shield airbag may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.



- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or vehicle falling

Types of collisions that may not deploy the SRS airbag (SRS front airbags)


The SRS front airbags and SRS seat cushion airbags are generally not designed to inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.



- Collision from the side
- Collision from the rear
- Vehicle rollover


Types of collisions that may not deploy the SRS airbag (SRS side airbags and SRS curtain shield airbags)

The SRS side airbags and curtain shield airbags system may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.




- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle

The SRS side airbags do not generally inflate if the vehicle is involved in a frontal collision, if it rolls over, or if it is involved in a low-speed side or low-speed rear collision.



- Collision from the front
- Vehicle rollover


The SRS curtain shield airbags do not generally inflate if the vehicle rolls over, or if it is involved in a low-speed side or low-speed frontal or low-speed rear collision.



Vehicle rollover

Types of collisions that may not deploy the SRS airbag (SRS rear window curtain shield airbag)

The SRS rear window curtain shield airbag is generally not designed to inflate if the vehicle is involved in a front collision, if it rolls over, or if it is involved in a low-speed rear or low-speed side collision.



Collision from the front


Vehicle rollover

When to contact your Scion dealer


In the following cases, contact your Scion dealer as soon as possible.


• Any of the SRS airbags have been inflated.

STY17AJZ08




- The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS front airbags to inflate.
- A portion of a door is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side airbags and curtain shield airbags to inflate.









- The rear of the vehicle is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS rear window curtain shield airbag to inflate.
- The pad section of the steering wheel or dashboard near the front passenger airbag cover or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.
- The front seat cushion surface is scratched, cracked, or otherwise damaged.
- The surface of the seats with the side airbags are scratched, cracked or otherwise damaged.
- The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside are scratched, cracked or otherwise damaged.
- The portion of the rear roof headlining or rear pillars containing the rear window curtain shield airbag is scratched, cracked or otherwise damaged.

SRS airbag precautions

Observe the following precautions regarding the airbags. Failure to do so may cause death or serious injury.

• The driver and all passengers in the vehicle must wear their seat belts properly.

The SRS airbags are supplemental devices to be used with the seat belts.

 The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag. The National Highway Traffic Safety Administration ("NHTSA") advises:

Since the risk zone for the driver's airbag is the first 2 - 3 in. (50 - 75 mm) of inflation, placing yourself 10 in. (250 mm) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 10 in. (250 mm) away now, you can change your driving position in several ways:

- Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- Slightly recline the back of the seat. Although vehicle designs vary, many drivers can achieve the 10 in. (250 mm) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.
- If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended by NHTSA above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

Before driving

SRS airbag precautions



- If the seat belt extender has been connected to the front seat belt buckles but the seat belt extender has not also been fastened to the latch plate of the seat belt, the SRS front airbags will judge that the driver and front passenger are wearing the seat belt even though the seat belt has not been connected. In this case, the SRS front airbags may not activate correctly in a collision, resulting in death or serious injury in the event of a collision. Be sure to wear the seat belt with the seat belt extender.
- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Scion strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. (→P. 87)



Do not sit on the edge of the seat or lean against the dashboard.

SRS airbag precautions






- Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.
- Do not allow the front seat occupants to hold items on their knees.
- Do not lean against the door, the roof side rail or the front, side and rear pillars.
- Do not a passenge their hear

STY17AJZ12

- Do not allow anyone to kneel on the passenger seat toward the door or put their head or hands outside the vehicle.
- Do not allow anyone to kneel on the rear seat toward the back door.



SRS airbag precautions



Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel.

These items can become projectiles when the SRS driver, front passenger and knee airbags deploy.

- Do not attach anything to areas such as the door, windshield glass, side door glass, front and rear pillars, roof side rail or assist grip. (Except for the speed limit label →P. 295)
- Do not attach any heavy, sharp or hard objects such as keys or accessories to the key. The objects may restrict the SRS knee airbags inflation or be thrust into the driver's seat area by the force of the deploying airbag, thus causing a danger.
- If a vinyl cover is put on the area where the SRS knee airbags will deploy, be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags and SRS seat cushion airbags inflate as they may interfere with inflation of the airbags. Such accessories may prevent the side airbags and seat cushion airbags from activating correctly, disable the system or cause the side airbags and seat cushion airbags to inflate accidentally, resulting in death or serious injury.
- Do not strike or apply significant levels of force to the area of the SRS airbag components.

Doing so can cause the SRS airbags to malfunction.

STY17AJ032

SRS airbag precautions

- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbag has deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front and rear pillar garnishes, are damaged or cracked, have them replaced by your Scion dealer.

Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting your Scion dealer.


The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags.
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars or roof side rail.
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment.
- Installation of snow plows, winches, etc. to the front grille (bull bars, kangaroo bar etc.).
- Installation of racks etc. to the back door (strap racks, bicycle rack etc.).
- Modifications to the vehicle's suspension system.
- Installation of electronic devices such as mobile two-way radios or CD players.
- Modifications to your vehicle for a person with a physical disability.

1-7. Safety information

Front passenger occupant classification system

Your vehicle is equipped with a front passenger occupant classification system. This system detects the conditions of the front passenger seat and activates or deactivates the devices for the front passenger.



1 SRS warning light

- 2 AIR BAG OFF indicator light
- **3** AIR BAG ON indicator light
- Front passenger's seat belt reminder light

Condition and operation in the front passenger occupant classification system

Adult*1

Indicator/ warning light	AIR BAG ON and AIR BAG OFF indicator lights	AIR BAG ON
	SRS warning light	Off
	Front passenger's seat belt reminder light	Off*2
		or
		flashing* ³
Devices	Front passenger airbag	
	Side airbag on the front passenger seat	
	Curtain shield airbag in the front passenger side	Activated
	Front passenger knee airbag	
	Seat cushion airbag in the front passenger side	Activated*2
		or
	Side	deactivated*3
	Front passenger's seat belt pretensioner	Activated

Child^{*4} or child restraint system^{*5}

Indicator/ warning light	AIR BAG ON and AIR BAG OFF indicator lights	AIR BAG OFF ^{*6}
	SRS warning light	Off
		Off*2
	Front passenger's seat belt reminder light	or
		flashing*3
Devices	Front passenger airbag	Deactivated
	Side airbag on the front passenger seat	
	Curtain shield airbag in the front passenger	Activated
	side	
	Front passenger knee airbag	
	Seat cushion airbag in the front passenger	Deactivated
	side	
	Front passenger's seat belt pretensioner	Activated

Unoccupied

Indicator/ warning light	AIR BAG ON and AIR BAG OFF indicator lights	Not illuminated
	SRS warning light	Off
	Front passenger's seat belt reminder light	
Devices	Front passenger airbag	Deactivated
	Side airbag on the front passenger seat	
	Curtain shield airbag in the front passenger side	Activated
	Front passenger knee airbag	
	Seat cushion airbag in the front passenger side	Deactivated
	Front passenger's seat belt pretensioner	Deactivated ^{*7} or activated ^{*8}

There is a malfunction in the system

Indicator/ warning light	AIR BAG ON and AIR BAG OFF indicator	AIR BAG
	lights	OFF
	SRS warning light	On
	Front passenger's seat belt reminder light	Off
Devices	Front passenger airbag	Deactivated
	Side airbag on the front passenger seat	
	Curtain shield airbag in the front passenger	Activated
	side	
	Front passenger knee airbag	
	Seat cushion airbag in the front passenger	Deactivated
	side	
	Front passenger's seat belt pretensioner	Activated

- *1: The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may recognize him/her as a child depending on his/her physique and posture.
- *2: In the event the front passenger is wearing a seat belt.
- *3: In the event the front passenger does not wear a seat belt.
- *4: When a larger child who has outgrown a child restraint system sits in the front passenger seat, the system may recognize him/her as an adult depending on his/her physique or posture.
- *5: Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P. 87)
- *6: In case the indicator is not illuminated, consult this manual as for installing the child restraint system properly. (→P. 92)

*7: In the event of a frontal collision

*8: In the event of a side collision

A CAUTION Front passenger occupant classification system precautions Observe the following precautions regarding front passenger occupant classification system. Failure to do so may cause death or serious injury. Wear the seat belt properly. Make sure the front passenger's seat belt tab has not been left inserted into the buckle before someone sits in the front passenger seat. Make sure the AIR BAG OFF indicator light is not illuminated when using the seat belt extender for the front passenger seat. If the AIR BAG OFF indicator light is illuminated, disconnect the extender tongue from the seat belt buckle, then reconnect the seat belt. Reconnect the seat belt extender after making sure the AIR BAG ON indicator light is illuminated. If you use the seat belt extender while the AIR BAG OFF indicator light is illuminated, the SRS airbags for the passenger may not activate correctly, which could cause death or serious injury in the event of collision. Do not apply a heavy load to the front passenger seat or equipment. Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat. Do not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs. Do not put objects under the front passenger seat. Do not recline the front passenger seatback so far that it touches a rear seat. This may cause the AIR BAG OFF indicator light to be illuminated, which indicates that the passenger's airbags will not deploy in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.

Before driving

Front passenger occupant classification system precautions

- If an adult sits in the front passenger seat, the AIR BAG ON indicator light is illuminated. If the AIR BAG OFF indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the AIR BAG OFF indicator still remain illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- When it is unavoidable to install the forward-facing child restraint system on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. (→P. 92)
- Do not modify or remove the front seats.
- Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the detection system. In this case, contact your Scion dealer immediately.
- Child restraint systems installed on the rear seat should not contact the front seatbacks.
- Do not use a seat accessory, such as a cushion and seat cover, that covers the seat cushion surface.
- Do not modify or replace the upholstery of the front seat.

A child restraint system for a small child or baby must itself be properly restrained on the seat with the lap portion of the lap/shoulder belt.

The laws of all 50 states of the U.S.A. and Canada now require the use of child restraint systems.

Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one to the front passenger seat.

- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.
 General installation instructions are provided in this manual.

(→P. 92)

Types of child restraints

Child restraint systems are classified into the following 3 types according to the age and size of the child.

▶ Rear facing — Infant seat/convertible seat



► Forward facing — Convertible seat




► Booster seat



When installing the child restraint system on the rear seat (vehicles with type A front seat)

Adjust the front seat position so that the seat rails are completely covered by the covers bearing a triangle mark.



- 1 Cover 2 Triangle mark
- 3 Seat rail

Slide the front seat forward until the seat rail is no longer visible, when the cover triangle section is viewed from above.

When installing the child restraint system on the front passenger seat



- Adjust the seatback to the most upright position.
- 2 Always move the seat as far back as possible.

Selecting an appropriate child restraint system

STY17AJZ54

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belts.
- If a child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. (→P. 43)

Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior.
- Scion strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- Never install a rear-facing child restraint system on the front passenger seat even if AIR BAG OFF indicator light is illuminated. In the event of an accident, the force of the rapid inflation of the SRS front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.
- A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top tether strap should not be used in the front passenger seat since there is no top tether strap anchor for the front passenger seat. Adjust the seatback as upright as possible and always move the seat as far back as possible even if the AIR BAG OFF indicator light is illuminated, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.
- Do not use the seat belt extender when installing a child restraint system on the front or rear passenger seat. If installing a child restraint system with the seat belt extender connected to the seat belt, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of emergency braking, sudden swerving or an accident.
- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front and rear pillars or roof side rail from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.

Child restraint precautions

• Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of emergency braking, sudden swerving or an accident.

When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

When the child restraint system is not in use


 Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the restraint unsecured in the passenger compartment.

If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the luggage compartment. This will prevent it from injuring passengers in the event of emergency braking, sudden swerving or an accident.

1-7. Safety information Installing child restraints

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the rear seats using the LATCH anchors or a seat belt. Attach the top tether strap when installing a child restraint.

The lap/shoulder belt can be used if your child restraint system is not compatible with the LATCH (Lower Anchors and Tethers for Children) system.




Child restraint LATCH anchors

LATCH anchors are provided for the rear seats. (Buttons displaying the location of the anchors are attached to the seats.)



Seat belts equipped with a child restraint locking mechanism (ALR/ELR belts except driver's seat belt) (\rightarrow P. 43)




Anchor bracket (for top tether strap)

Anchor brackets are provided for all rear seats.

Installation with LATCH system

► Type A




- STEP 1 Widen the gap between the seat cushion and seatback slightly.
- STEP 2 Latch the hooks of the lower straps onto the LATCH anchors and tighten the lower straps.
- STEP 3 If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor. $(\rightarrow P. 99)$

For owners in Canada:

The symbol on a child restraint system indicates the presence of a lower connector system.

► Type B




- STEP 1 Widen the gap between the seat cushion and seatback slightly.
- STEP 2 Latch the buckles onto the LATCH anchors.
- STEP 3 If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor. $(\rightarrow P. 99)$

For owners in Canada:


The symbol on a child restraint system indicates the presence of a lower connector system.

Installing child restraints using a seat belt (child restraint lock function belt)

Rear facing — Infant seat/convertible seat



Place the child restraint system on the rear seat facing the rear of the vehicle.



STEP 3

Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.

Fully extend the shoulder belt and then allow it to retract slightly in order to activate the ALR lock mode.

Lock mode allows the seat belt to retract only.




While pushing the child restraint system down into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.


■ Forward facing — Convertible seat



Place the child restraint system on the seat facing the front of the vehicle.



Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.



Fully extend the shoulder belt and then allow it to retract slightly in order to activate the ALR lock mode.

Lock mode allows the seat belt to retract only.




While pushing the child restraint system down into the rear seat, allow the shoulder belt to retract until the child seat is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.

STEP 5 If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor. (\rightarrow P. 99)

Booster seat




Place the child restraint system on the seat facing the front of the vehicle.



Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.

Check that the shoulder belt is correctly positioned over the child's shoulder, and that the lap belt is as low as possible. $(\rightarrow P. 43)$


Removing a child restraint installed with a seat belt



Push the buckle release button and fully retract the seat belt.

Child restraint systems with a top tether strap

STEP 1 Secure the child restraint system using the seat belt or the LATCH anchors.




Remove the anchor bracket cover.

Store the removed cover in a safe place.


STEP 3 Latch the hook onto the anchor bracket and tighten the top strap.

Make sure the top strap is securely latched.

► Type A



► Type B



Laws and regulations pertaining to anchorages

The LATCH system conforms to FMVSS225 or CMVSS210.2. Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to the SAE J1819.

When installing a booster seat

Do not fully extend the shoulder belt to prevent the belt from going to ALR lock mode. (\rightarrow P. 45)

In ALR lock mode the belt is locked in that position and cannot be extended, which could cause injury or discomfort to the child seated in the booster seat.

When installing a child restraint system

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of emergency braking, sudden swerving or an accident.





- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the righthand rear seat.
- Adjust the front passenger seat so that it does not interfere with the child restraint system.
- Only put a forward-facing or booster child seat on the front seat when unavoidable. When installing a forwardfacing or booster child seat on the front passenger seat, move the seat as far back as possible even if AIR BAG OFF indicator light is illuminated. Failing to do so may result in death or serious injury if the airbags deploy (inflate).

When installing a child restraint system

- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of emergency braking, sudden swerving or an accident.
- Ensure that the belt and tab are securely locked and the seat belt is not twisted.

 Push and pull the child restraint system from side to side and forward to be sure it is secure.

- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.

Do not use a seat belt extender

If a seat belt extender is used when installing a child restraint system, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of emergency braking, sudden swerving or an accident.

To correctly attach a child restraint system to the anchors

When using the LATCH anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of emergency braking, sudden swerving or an accident.

When driving

2-1. Driving procedures

Driving the vehicle	104
Engine (ignition) switch	113
Automatic transmission	116
Turn signal lever	117
Parking brake	118
Horn	120

2-2. Instrument cluster

Gauges and meters	121
Indicators and	
warning lights	123
Multi-information	
display	126

2-3. Operating the lights and wipers

Headlight switch	132
Windshield wipers and	
washer	136
Rear window wiper and	
washer	139

2-4. Using other driving systems Driving assist systems 141

2-5. Driving information

2

Cargo and luggage	146
Vehicle load limits	150
Winter driving tips	151
Trailer towing	155
Dinghy towing	156

The following procedures should be observed to ensure safe driving.

Starting the engine (\rightarrow P. 113)

Driving

STEP 1 With the brake pedal depressed, shift the shift lever to D.

STEP 2 Release the parking brake. $(\rightarrow P. 118)$

STEP 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

Stopping

STEP 1 With the shift lever in D, depress the brake pedal.

STEP 2 If necessary, set the parking brake.

When the vehicle is stopped for an extended period of time, shift the shift lever to P or N. $(\rightarrow P. 116)$

Parking the vehicle

- STEP 1 With the shift lever in D, depress the brake pedal.
- STEP 2 Set the parking brake. $(\rightarrow P. 118)$
- STEP 3 Shift the shift lever to P.

(→P. 116)

(→P. 116)

When parking on a hill, if necessary, block the wheels.

- STEP 4 Turn the engine switch off to stop the engine.
- STEP 5 Lock the door, making sure that you have the key on your person.


Starting on a steep uphill

- STEP 1 With the brake pedal depressed, firmly set the parking brake and shift the shift lever to D.
- STEP 2 Gently depress the accelerator pedal.
- STEP 3 Release the parking brake.

Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

Eco-friendly driving



During Eco-friendly acceleration operation (Eco driving), Eco Driving Indicator Light will turn on. When the acceleration exceeds Zone of Eco driving, and when the vehicle is stopped, the light turns off.

Eco Driving Indicator Light will not operate in the following conditions:

- The shift lever is in anything other than D.
- The vehicle speed is approximately 80 mph (130 km/h) or higher.

Eco Driving Indicator Light can be activated or deactivated. (\rightarrow P. 127)

Engine speed while driving

In the following conditions, the engine speed may become high while driving. This is due to automatic up-shifting control or down-shifting implementation to meet driving conditions. It does not indicate sudden acceleration.

- The vehicle is judged to be driving uphill or downhill
- When the accelerator pedal is released

Breaking in your new Scion

To extend the life of the vehicle, the following precautions are recommended to observe:

• For the first 186 miles (300 km): Avoid sudden stops.

For the first 1000 miles (1600 km):

- Do not drive at extremely high speeds.
- Avoid sudden acceleration.
- Do not drive continuously in the low gears.
- Do not drive at a constant speed for extended periods.

Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. (\rightarrow P. 329)

CAUTION

When starting the vehicle

Always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
 - Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident that could result in death or serious injury.
 - When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
 - Make sure to keep a correct driving posture even when moving the vehicle only slightly, allowing you to depress the brake and accelerator pedals properly.
 - Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials. The exhaust system and exhaust gases can be extremely hot. This may cause a fire if there is any flammable material nearby.

When driving the vehicle

• Do not let the vehicle roll backward while the shift lever is in a driving position, or roll forward while the shift lever is in R.

Doing so may cause the engine to stall or lead to poor brake and steering performance, resulting in an accident or damage to the vehicle.

If the smell of exhaust is noticed inside the vehicle, open the windows and check that the back door is closed. Large amounts of exhaust in the vehicle can cause driver drowsiness and an accident, resulting in death or a serious health hazard. Have the vehicle inspected by your Scion dealer immediately.

Do not shift the shift lever to P while the vehicle is moving.
 Doing so can damage the transmission and may result in a loss of vehicle control.

- Do not shift the shift lever to R while the vehicle is moving forward.
 Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to D while the vehicle is moving backward. Doing so can damage the transmission and may result in a loss of vehicle control.
- Moving the shift lever to N while the vehicle is moving will disengage the engine from the transmission. Engine braking is not available when N is selected.

• During normal driving, do not turn off the engine. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.

However, in the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way. (\rightarrow P. 317)

 Use engine braking to maintain a safe speed when driving down a steep hill.

Using the brakes continuously may cause the brakes to overheat and lose effectiveness. (\rightarrow P. 116)

When driving the vehicle

- When stopped on an inclined surface, use the brake pedal and parking brake to prevent the vehicle from rolling backward or forward and causing an accident.
- Do not adjust the position of the steering wheel, the seat, or the inside or outside rear view mirrors while driving.

Doing so may result in a loss of vehicle control that can cause accidents that may result in death or serious injury.

- Always check that all passengers' arms, heads or other parts of their bodies are not outside the vehicle, as this may result in death or serious injury.
- Do not drive in excess of the speed limit. Even if the legal speed limit permits it, do not drive over 85 mph (140 km/h) unless your vehicle has high-speed capability tires. Driving over 85 mph (140 km/h) may result in tire failure, loss of control and possible injury. Be sure to consult a tire dealer to determine whether the tires on your vehicle are high-speed capability tires or not before driving at such speeds.

When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle, resulting in an accident.
- Sudden acceleration, engine braking due to shifting, or changes in engine speed could cause the vehicle to skid, resulting in an accident.
- After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected, resulting in an accident.

When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

CAUTION

When the vehicle is stopped

Do not race the engine.

If the vehicle is in any gear other than P or N, the vehicle may accelerate suddenly and unexpectedly, and may cause an accident.

 Do not leave the vehicle with the engine running for a long time.
 If such a situation cannot be avoided, park the vehicle in an open space and check that exhaust fumes do not enter the vehicle interior.

In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the engine is running, and apply the parking brake as necessary.

 If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.

Avoid revving or racing the engine.

Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

When the vehicle is parked

 Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.

Doing so may result in the following.

- Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
- The temperature inside the vehicle may cause the plastic lenses and plastic material of eye glasses to deform or crack.
- Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Always apply the parking brake, shift the shift lever to P, stop the engine and lock the vehicle.

Do not leave the vehicle unattended while the engine is running.

 Do not touch the exhaust pipe while the engine is running or immediately after turning the engine off.

Doing so may cause burns.

When driving

CAUTION

When the vehicle is parked

• Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.

Exhaust gases

Exhaust gases include harmful carbon monoxide (CO) that is colorless and odorless. Inhaling exhaust gases may lead to death or a serious health hazard.

- If the vehicle is in a poorly ventilated area, stop the engine. In a closed area, such as a garage, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.
- The exhaust should be checked occasionally. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Scion dealer. Failure to do so may allow exhaust gases to enter the vehicle, resulting in death or a serious health hazard.

When taking a nap in the vehicle

Always turn the engine off. Otherwise, you may accidentally move the shift lever or depress the accelerator pedal, which could cause an accident or fire due to engine overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

When braking the vehicle

When the brakes are wet, drive more cautiously. Braking distance increases when the brakes are wet, and may cause one side of the vehicle to brake differently than the other side. Also the parking brake may not securely hold the vehicle.

 If the power brake assist function does not operate, do not follow other vehicles closely and avoid downhills or sharp turns that require braking. In this case, braking is still possible, but it will require more force on the pedal than usual. Braking distance may also increase. Have your brakes fixed immediately.

CAUTION

When braking the vehicle

Do not pump the brake pedal if the engine stalls.

Each push on the brake pedal uses up the reserve for the power-assisted brakes.

The brake system consists of 2 individual hydraulic systems: If one of the systems fails, the other will still operate. In this case, the brake pedal should be depressed more firmly than usual and braking distance becomes longer.

Have your brakes fixed immediately.

When driving the vehicle

- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain driving torque.
- Do not use the accelerator pedal or depress accelerator and brake pedals together to hold the vehicle on a hill.

When parking the vehicle

Always put the shift lever in P.

Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

Avoiding damage to vehicle parts

Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.

Doing so may damage the power steering motor.

 When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

If you hear a squealing or scraping noise while driving (brake pad wear limit indicators)

Have the brake pads checked and replaced by your Scion dealer as soon as possible.

The rotor damage can result if the pads are not replaced when needed.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or that of the brake discs are exceeded.

If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually press the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds.
- The vehicle will behave abnormally.

If a tire goes flat, confirm the extent of the damage to the tire.

- If the tire is reparable, complete the emergency repair procedure.
 (→P. 288)
- If the tire is irreparable, please contact your Scion dealer.

When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle.


- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Scion dealer check the following.

- Brake function
- Changes in quantity and quality of engine oil, transmission fluid, etc.
- Lubricant condition for the bearings and suspension joints (where possible) and the function of all joints, bearings, etc.

2-1. Driving procedures Engine (ignition) switch

Engine switch



1 LOCK

The steering wheel is locked and the key can be removed. (The key can be removed only when the shift lever is in P.)

2 ACC

Some electrical components such as the audio system can be used.

3 ON

All electrical components can be used.

4 START

For starting the engine.

Starting the engine

STEP 1 Check that the parking brake is set.

STEP 2 Check that the shift lever is set in P.

STEP 3 Sit in the driver's seat and firmly depress the brake pedal.

STEP 4 Turn the engine switch to the START position and start the engine.

113


Turning the key from ACC to LOCK



Steering lock release

STEP 1 Shift the shift lever to P. $(\rightarrow P. 116)$

STEP 2 Push in the key and turn it to the LOCK position.



When starting the engine, the engine switch may seem stuck in the LOCK position. To free it, turn the key while turning the steering wheel slightly in either direction.

If the engine does not start (vehicles with engine immobilizer system)

The engine immobilizer system may not have been deactivated. (\rightarrow P. 62)

Key reminder function

A buzzer sounds if the driver's door is opened, while the engine switch is in the ACC or LOCK position to remind you to remove the key.

A CAUTION

When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

Caution while driving

Do not turn the engine switch to the LOCK position.

If in an emergency, you must turn the engine off while the vehicle is moving, turn the engine switch only to the ACC position.

To prevent battery discharge

Do not leave the key in the ACC or ON position for long periods if the engine is not running.


When starting the engine

- Do not crank for more than 30 seconds at a time. This may overheat the starter and wiring systems.
- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have the engine checked immediately.

2-1. Driving procedures Automatic transmission

Select a shift position appropriate for the driving conditions.

Shifting the shift lever



While the engine switch is in the ON position, depress the brake pedal and move the shift lever.


Shift position uses

Shift position	Function		
Р	Parking the vehicle or starting the engine		
R	Reversing		
N	Neutral		
D	Normal driving*		
S	Engine braking		
В	Maximum engine braking		

*: To improve fuel consumption and reduce noises, set the shift lever in D for normal driving.

If the shift lever cannot be shifted from P (\rightarrow P. 307)

2-1. Driving procedures Turn signal lever



1 Left turn

- 2 Right turn
- Move and hold the lever partway to signal a lane change.

The left hand signal will flash until you release the lever.

Move and hold the lever partway to signal a lane change.

The right hand signal will flash until you release the lever.

Turn signals can be operated when

The engine switch is in the ON position.

If the indicators flash faster than usual

Check that a light bulb in the front or rear turn signal lights has not burned out.


Set the parking brake



Fully set the parking brake while depressing the brake pedal.

At this time, the indicator will come on.

Release the parking brake



1 Slightly raise the lever

2 Press the button

3 Lower it completely

Parking brake engaged warning buzzer

→P. 277

Usage in winter time


See "Winter driving tips" for parking brake usage in winter time. (\rightarrow P. 151)

Before driving

Fully release the parking brake.

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.


2-1. Driving procedures **Horn**



After adjusting the steering wheel

Make sure that the steering wheel is securely locked. The horn may not sound if the steering wheel is not securely locked. $(\rightarrow P. 49)$

2-2. Instrument cluster Gauges and meters



Multi-information display

→P. 126

2 Speedometer

Displays the vehicle speed.

3 Tachometer

Displays the engine speed in revolutions per minute.

4 Clock reset button


→P. 130

5 MODE button

→P. 127

Instrument panel light control

The brightness of the instrument panel lights can be adjusted.



When the tail lights/headlights are turned on, the brightness level can be changed with each press of the switch.

Instrument panel light control display



Displays the instrument panel light control display.

To prevent damage to the engine and its components


 Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.

The engine may be overheating if the high engine coolant temperature warning light flashes or comes on. In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (->P. 312)


2-2. Instrument cluster Indicators and warning lights

The indicator and warning lights on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

► Instrument cluster



► Center panel



Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator $(\rightarrow P. 117)$



Headlight high beam indicator (\rightarrow P. 134)



Shift position and shift range indicators $(\rightarrow P. 116)$



Low engine coolant temperature indicator Indicates the engine coolant temperature is cool.



VSC OFF indicator $(\rightarrow P. 142)$

TRAC OFF indicator $(\rightarrow P. 142)$



Engine immobilizer system indicator $(\rightarrow P. 62)$



AIR BAG

ON

AIR BAG OFF Eco Driving Indicator Light (\rightarrow P. 105, 129)

AIR BAG ON indicator $(\rightarrow P. 81)$

AIR BAG OFF indicator $(\rightarrow P. 81)$




Slip indicator (\rightarrow P. 142)

*1: These lights turn on when the engine switch is turned to the ON position to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Scion dealer.

*2: The indicator flashes to indicate that the system is operating.

Warning lights

Warning lights inform the driver of malfunctions in any of the vehicle's systems. (\rightarrow P. 277)



*: These lights turn on when the engine switch is turned to the ON position to indicate that a system check is being performed. They will turn off after the engine is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by your Scion dealer.


CAUTION

If a safety system warning light does not come on

Should a safety system light such as ABS and the SRS airbag warning light not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Scion dealer immediately if this occurs.

2-2. Instrument cluster Multi-information display

The multi-information display presents the driver with a variety of driving-related information, including the current outside temperature and time.



Fuel gauge

Displays the quantity of fuel remaining in the tank.

2 Shift position and shift range/gear display

(→P. 116)

Displays the shift position along with the currently selected shift range or gear.

3 Clock (→P. 130)

Displays the time and sets the clock.

 Outside temperature display


Displays the outside air temperature.

The temperature range that can be displayed is from -40°F (-40°C) to 122°F (50°C).

5 Trip information $(\rightarrow P. 127)$

Displays odometer, trip meter, fuel consumption, Stop & Start system operation time, Stop & Start system total operation time and other cruising-related information.

Switch the display



Display items can be switched by pressing the MODE button.

Odometer



Displays the total distance the vehicle has been driven.

• Trip meter A*1



Displays the distance the vehicle has been driven since the meter was last reset.

The function can be reset by pressing the MODE button for longer than 1 second when the trip meter A is displayed.

• Trip meter B*1



Displays the distance the vehicle has been driven since the meter was last reset.

The function can be reset by pressing the MODE button for longer than 1 second when the trip meter B is displayed.

*1: Trip meters A and B can be used to record and display different distances independently.

Instantaneous fuel consumption



Displays the Eco Driving Indicator Zone Display and instantaneous fuel consumption.

Average fuel consumption after refueling^{*2}



Displays Eco Driving Indicator Zone Display and average fuel consumption since the function was reset.

Use the displayed average fuel consumption as a reference.

Setting Eco Driving Indicator Light



Eco Driving Indicator Light can be switched on and off.

The display can be switched on or off by pressing the MODE button for longer than 1 second.

• Average vehicle speed



Displays the average vehicle speed since the engine was started or the function was reset.


*²: When filled with less than 2.6 gal. (10 L, 2.2 Imp.gal.) per refueling, the "average fuel consumption after refueling" may not be displayed accurately.

Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- •When stopped, or driving at low speeds (less than 12 mph [20 km/h])
- When the outside temperature has changed suddenly (at the entrance/ exit of a garage, tunnel, etc.)

Eco Driving Indicator



Suggests Zone of Eco driving with current Eco driving ratio based on acceleration. During Eco-friendly driving acceleration (Eco driving), Eco Driving Indicator Light (1) will turn on.

Vehicle to exceed Zone of Eco driving (2), the right of Eco Driving Indicator Zone Display will blink and Eco Driving Indicator Light will turn off.

Eco Driving Indicator Light will operate in the following conditions:

- The shift lever in D.
- When the vehicle is at a speed of approximately 80 mph (130 km/h) or below.


NOTICE

The multi-information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

When driving

Setting the clock



- STEP 1 Press and hold the clock reset button to enter the adjustment mode for the clock.
- STEP 2 Press the clock reset button to adjust the minutes.

After adjusting the minutes, wait 5 seconds to allow the minutes to be automatically input.

STEP 3 Press the clock reset button to adjust the hours.

After adjusting the hours, wait 5 seconds to allow the hours to be automatically input and the mode to return to normal.

The multi-information display can be operated when

The engine switch is in the ON position.

When disconnecting and reconnecting battery terminals

The following information will be reset.

- Clock
- Trip meter
- Average fuel consumption after refueling
- Average vehicle speed

Adjusting to a full hour

If you press the clock reset button, the minute values will be rounded to the nearest hour. So, minute values from ":00" to ":29" are rounded down, and values from ":30" to ":59" are rounded up.^{*}


*: e.g.

1:00 to 1:29 \rightarrow 1:00

1:30 to 1:59 \rightarrow 2:00

The headlights can be operated manually or automatically.


► Type A



 O Vehicles with daytime running light system: The daytime running lights turn on.

- The side marker, parking, tail, license plate, daytime running lights (if equipped) and instrument panel lights turn on.
- 3 意○ The headlights and all lights listed above (except daytime running lights) turn on.


► Type B



- OFF Vehicles with daytime running light system: The daytime running lights turn on.
- 2 DOC The side marker, parking, tail, license plate, daytime running lights (if equipped) and instrument panel lights turn on.
- Image Strain Strain

AUTO The headlights and (if equipped) all lights listed above turn on and off automatically. (When the engine switch is in the ON position)

Turning on the high beam headlights



With the headlights on, push the lever forward to turn on the high beams.

Pull the lever back to the center position to turn the high beams off.


Pull the lever toward you to turn on the high beams.

Release the lever to turn them off. You can flash the high beams with the headlights on or off.

Daytime running light system (if equipped)

- To make your vehicle more visible to other drivers, the headlights turn on automatically (at a reduced intensity) whenever the engine is started and the parking brake is released. Daytime running lights are not designed for use at night.
- Compared to turning on the headlights, the daytime running light system offers greater durability and consumes less electricity, so it can help improve fuel economy.

Headlight control sensor (if equipped)



The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.

Automatic light off system (if equipped)

- When the headlights come on: The headlights and tail lights automatically turn off after 30 seconds when a door is opened and closed with the engine switch turned to the ACC or LOCK position. (The lights turn off immediately if the figure button on the wireless remote control is pressed after all doors are locked.)
- When only the tail lights come on: The tail lights turn off automatically with the engine switch turned to the ACC or LOCK position and the driver's door is opened.

Customization that can be configured at Scion dealer

Settings of the light sensor sensitivity can be changed. (Customizable features \rightarrow P. 343)


To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is not running. When driving


2-3. Operating the lights and wipers Windshield wipers and washer

Intermittent wiper

► Type A




1	\mathcal{P}	Intermittent		wind-	
		shield	wiper	opera-	
		tion			
2	▼	Low	speed	wind-	
		shield	wiper	opera-	
		tion			
3	₹	High	speed	wind-	
		shield	wiper	opera-	
		tion			
4	Δ	Temporary operation			



5 Washer/wiper dual operation

Wipers will automatically operate a couple of times after the washer squirts.

► Type B



The windshield wiper and washer can be operated when

The engine switch must be in the ON position.

If no windshield washer fluid sprays

Check that the washer nozzles are not blocked and if there is washer fluid in the windshield washer fluid reservoir.

When the windshield is dry

Do not use the wipers, as they may damage the windshield.

When there is no washer fluid spray from the nozzle


Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

When a nozzle becomes blocked


Do not try to clear it with a pin or other object. The nozzle will be damaged.

2-3. Operating the lights and wipers Rear window wiper and washer

► Type A



► Type B



The rear window wiper and washer can be operated when

The engine switch must be in the ON position.

▲ NOTICE

When the rear window is dry

Do not use the wipers, as they may damage the rear window.

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface.

Brake Assist

Generates an increased level of braking force after the brake pedal is depressed, when the system detects a panic stop situation.

VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces.

TRAC (Traction Control)

Maintains drive power and prevents the front wheels from spinning when starting the vehicle or accelerating on slippery roads.


EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel.

Enhanced VSC (Enhanced vehicle stability control)

Provides cooperative control of the ABS, TRAC, VSC and EPS. Helps to maintain directional stability when swerving on slippery road surfaces by controlling steering performance.

When the TRAC/VSC systems are operating




The slip indicator will flash while the TRAC/VSC systems are operating.

To disable TRAC and/or VSC systems

If the vehicle gets stuck in fresh snow or mud, TRAC and VSC systems may reduce power from the engine to the wheels. You may need to turn the system off to enable you to rock the vehicle in order to free it.

Turning off TRAC




To turn the TRAC system off, quickly press and release the button.

The TRAC OFF indicator will come on.

Press the button again to turn the system back on.

Turning off TRAC and VSC systems



Press and hold the button for more than 3 seconds while the vehicle is stopped to turn off both TRAC and VSC systems.

The TRAC OFF and VSC OFF indicators will come on.

Press the button again to turn both systems back on.

When the TRAC OFF indicator comes on even if the VSC OFF switch has not been pressed

TRAC system cannot be operated. Contact your Scion dealer.

Sounds and vibrations caused by the ABS, TRAC, VSC and brake assist system

- A sound may be heard from the engine compartment when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
 - Vibrations may be felt through the vehicle body and steering.
 - A motor sound may be heard after the vehicle comes to a stop.
 - The brake pedal may pulsate slightly after the ABS is activated.
 - The brake pedal may move down slightly after the ABS is activated.

Automatic reactivation of TRAC and VSC systems

After turning the TRAC and VSC systems off, the systems will be automatically reactivated in the following situations:

- When the engine switch is turned off
- If only the TRAC system is turned off, the TRAC will turn on when vehicle speed increases

If both the TRAC and VSC systems are turned off, automatic reactivation will not occur when vehicle speed increases.

If the slip indicator comes on

There is a malfunction in the TRAC and VSC systems. Contact your Scion dealer and have your Scion inspected.

EPS operation sound

When the steering wheel is operated, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

Reduced effectiveness of the EPS system

The effectiveness of the EPS system is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the engine off. The EPS system should return to normal within 10 minutes.

CAUTION

The ABS does not operate effectively when

- The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road).
- The vehicle hydroplanes while driving at high speed on the wet or slick road.

Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations.

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or uneven roads

When VSC is activated

The slip indicator flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator flashes.

CAUTION

TRAC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if TRAC is operating.

Do not drive the vehicle in conditions where stability and power may be lost.

When TRAC and VSC systems are turned off

Be especially careful and drive at a speed appropriate to the road conditions. As these are systems to help ensure vehicle stability and driving force, do not turn off TRAC and VSC systems unless necessary.

Replacing tires

Make sure that all tires are of the same size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the appropriate tire pressure level.

The ABS and VSC systems will not function correctly if different tires are fitted on the vehicle.

Contact your Scion dealer for further information when replacing tires or wheels.

Handling of tires and suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause the system to malfunction.

Take notice of the following information about storage precautions, cargo capacity and load.

- Stow cargo and luggage in the luggage compartment whenever possible.
- Be sure all items are secured in place.
- Be careful to keep the vehicle level. Placing the weight as far forward as possible helps maintain vehicle balance.
- For better fuel economy, do not carry unnecessary weight.

Capacity and distribution

Cargo capacity depends on the total weight of the occupants.

(Cargo capacity) = (Total load capacity) – (Total weight of occupants)

Steps for Determining Correct Load Limit—

- (1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3)Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity.


For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs. $(1400 - 750 (5 \times 150) = 650 \text{ lbs.})$

(5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.

(6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle.

Scion does not recommend towing a trailer with your vehicle. Your vehicle is not designed for trailer towing.

Calculation formula for your vehicle



Cargo capacity

2 Total load capacity (vehicle capacity weight) (\rightarrow P. 320)

When 2 people with the combined weight of A lb. (kg) are riding in your vehicle, which has a total load capacity (vehicle capacity weight) of B lb. (kg), the available amount of cargo and luggage load capacity will be C lb. (kg) as follows:

 B^{*2} lb. (kg) – A^{*1} lb. (kg) = C^{*3} lb. (kg)

*1: A = Weight of people

*2: B = Total load capacity

*3: C = Available cargo and luggage load

In this condition, if 2 more passengers with the combined weight of D lb. (kg) get on, the available cargo and luggage load will be reduced E lb. (kg) as follows:

C lb. $(kg) - D^{*4}$ lb. $(kg) = E^{*5}$ lb. (kg)

*4: D = Additional weight of people

*5: E = Available cargo and luggage load

As shown in the above example, if the number of occupants increases, the cargo and luggage load will be reduced by an amount that equals the increased weight due to the additional occupants. In other words, if an increase in the number of occupants causes an excess of the total load capacity (combined weight of occupants plus cargo and luggage load), you must reduce the cargo and luggage on your vehicle.

CAUTION

Things that must not be carried in the luggage compartment

The following things may cause a fire if loaded in the luggage compartment.

- Receptacles containing gasoline
- Aerosol cans

Storage precautions

Observe the following precautions.

Failing to do so may result in death or serious injury.

- Stow cargo and luggage in the luggage compartment whenever possible.
- Do not stack cargo and luggage in the luggage compartment higher than the seatbacks.

Such items may be thrown about and possibly injure people in the vehicle in the event of sudden braking or in an accident.

- Do not place cargo or luggage in or on the following locations as the item may get under the brake or accelerator pedal and prevent the pedals from being depressed properly, block the driver's vision, or hit the driver or passengers, causing an accident.
 - Driver's feet
 - Front passenger or rear seats (when stacking items)
 - Instrument panel
 - Dashboard
 - Auxiliary box or tray that has no lid

 Secure all items in the occupant compartment, as they may shift and injure someone during emergency braking, sudden swerving or an accident.

Storage precautions

Never allow anyone to ride in the luggage compartment. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened. Otherwise, they are much more likely to suffer serious bodily injury, in the event of emergency braking, sudden swerving or an accident.

Capacity and distribution

- Do not exceed the maximum axle weight rating or the total vehicle weight rating.
- Even if the total load of occupant's weight and the cargo load is less than the total load capacity, do not apply the load unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

2-5. Driving information Vehicle load limits

Vehicle load limits include total load capacity, seating capacity, towing capacity and cargo capacity.

■ Total load capacity (vehicle capacity weight): (→P. 320) Total load capacity means the combined weight of occupants, cargo and luggage.

Seating capacity: 4 occupants (Front 2, Rear 2)

Seating capacity means the maximum number of occupants whose estimated average weight is 150 lb. (68 kg) per person.

Even if the number of occupants are within the seating capacity, do not exceed the total load capacity.

Towing capacity

Scion does not recommend towing a trailer with your vehicle.

Cargo capacity

Cargo capacity may increase or decrease depending on the weight and the number of occupants.

Total load capacity and seating capacity

These details are also described on the tire and loading information label. (\rightarrow P. 230)

A CAUTION

Overloading the vehicle

Do not overload the vehicle.

It may not only cause damage to the tires, but also degrade steering and braking ability, resulting in an accident.

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

Pre-winter preparations

- Use fluids that are appropriate to the prevailing outside temperatures.
 - Engine oil
 - · Engine coolant
 - · Washer fluid
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the front tires.

Ensure that all tires are the same size and brand, and that chains match the size of the tires.

Before driving the vehicle

Perform the following according to the driving conditions.

- Do not try to forcibly open a window, scrape an outside rear view mirror surface or move a wiper or outside rear view mirror that is frozen. Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Remove any ice that has accumulated on the vehicle chassis.
- Periodically check for and remove any excess ice or snow that may have accumulated in the wheel well or on the brakes.

When driving the vehicle


Accelerate the vehicle slowly and drive at a reduced speed suitable to road conditions.

When parking the vehicle

Park the vehicle and move the shift lever to P without setting the parking brake. The parking brake may freeze up, preventing it from being released. If necessary, block the wheels to prevent inadvertent sliding or creeping.

Selecting tire chains

Use the correct tire chain size when mounting the snow chains. Chain size is regulated for each tire size.



- Side chain
- 10.12 in. (3 mm) in diameter
- 20.39 in. (10 mm) in width
- 3 1.18 in. (30 mm) in length
- ► Cross chain
- 40.16 in. (4 mm) in diameter
- 5 0.55 in. (14 mm) in width
- 6 0.98 in. (25 mm) in length

Regulations on the use of snow chains

 Regulations regarding the use of tire chains vary according to location and type of road. Always check local regulations before installing chains.

Install the chains on the front tires.

Retighten the chains after driving 1/4 - 1/2 mile (0.5 - 1.0 km).

Snow chain installation

Observe the following precautions when installing and removing chains.

- Install and remove tire chains in a safe location.
- Install tire chains on the front tires only. Do not install tire chains on the rear tires.
- Install the tire chains on front tires as tightly as possible.
- Install tire chains following the instructions provided in the accompanying instructions.

A CAUTION

Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the size specified for your vehicle.
- Maintain the recommended level of air pressure.
- Do not drive in excess of 75 mph (120 km/h) regardless of the type of snow tires being used.
- Snow tires should be installed on all wheels.

Driving with snow chains

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used or 30 mph (50 km/h), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden turns and braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.

When driving

Repairing or replacing snow tires

Request repairs of and obtain replacement snow tires from Scion dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

Fitting tire chains


The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.

Scion does not recommend towing a trailer with your vehicle. Scion also does not recommend the installation of a tow hitch or the use of a tow hitch carrier of a wheelchair, scooter, bicycle, etc. Your vehicle is not designed for trailer towing or for the use of tow hitch mounted carriers.



2-5. Driving information **Dinghy towing**

Your vehicle is not designed to be dinghy towed (with 4 wheels on the ground) behind a motor home.



To avoid serious damage to your vehicle

Do not tow your vehicle with four wheels on the ground.

Interior features

3-1.	Using the air conditioning	g
	system and defogger	
	Air conditioning system	158

Rear window defogger	164
Rear window and	
outside rear view mirror	
defoggers	165

3-2. Using the audio system

Jsing the AUX port/	
USB port	167
Jsing the steering wheel	
audio switches	168

3-3. Using the interior lights

Interior lights list	169
Interior light	170

3-4. Using the storage features

List of storage features	171
• Cup holder	172
Bottle helders	172


Bottlo	oraor	• • • • • • • • • • • • • • • • • • • •	
Auxiliar	y box		174

3-5. Other interior features

3

Sun visors	175
Vanity mirrors	176
Power outlet	177
Assist grips	178
Floor mat	179
Luggage compartment	
features	181

3-1. Using the air conditioning system and defogger **Air conditioning system**



Adjusting the settings

Adjusting the temperature setting

Turn the temperature control dial clockwise (warm) or counterclockwise (cool).

If $(\overline{A/C})$ is not pressed, the system will blow ambient temperature air or heated air.

For quick cooling, turn the temperature control dial to the MAX A/C position and press the recirculated air mode switch to turn on the recirculated air mode.

Adjusting the fan speed


Turn the fan speed control dial clockwise (increase) or counterclockwise (decrease).

Set the dial to "0" to turn the fan off.

Selecting the air outlets

Set the air outlet selection dial to an appropriate position.


The positions between the air outlet selections shown below can also be selected for more detailed adjustment.



When the dial is set to **;**, air flows to the upper body.


When the dial is set to 🞲, air flows to the upper body and feet.

Some models



Some models

When the dial is set to **,**, air flows mainly to the feet.




Some models

When the dial is set to 😰, air flows to the feet and the windshield defogger operates.

The air intake selector is automatically set to outside air mode.

In this position, the air intake selector cannot be changed to the recirculated air mode.



When the dial is set to when the dial is set to when the dial is set to when air flows to the windshield and side windows to defog them.

The air intake selector is automatically set to outside air mode.

In this position, the air intake selector cannot be changed to the recirculated air mode.

(A/C) to turn the air Pressing

conditioning on clears the windshield and side windows faster.

Switching between outside air and recirculated air modes

Press (🖘



The mode switches between $(\overline{\clubsuit})$ (outside air mode) and $(\overline{\clubsuit})$



(recirculated air mode) each time the switch is pressed.

Adjusting the position and opening and closing the air outlets


TY31AJZZ

► Center outlets

- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

Interior features

▶ Right and left side outlets



- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

For quick cooling

Turn the temperature control dial to the "MAX A/C" position and select the recirculated air mode.

Using the system in recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

When outside air temperature approaches 32°F (0°C)

The air conditioning system may not operate even when

is pressed.

(A/C

When 🞲 is selected for the air outlets used

For your driving comfort, air flowing to the feet may be warmer than air flowing to the upper body depending on the position of the temperature adjustment dial.

Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring: It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.

CAUTION

To prevent the windshield from fogging up

Do not set the air outlet selection dial to (\mathfrak{W}) during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.

Λ ΝΟΤΙCE

To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is stopped.

3-1. Using the air conditioning system and defogger **Rear window defogger**^{*}

23

S

This feature is used to defog the rear window.

Turns the defogger on/off

Press the button to turn on the rear window defogger. The indicator will come on. Pressing the button again also turns the defogger off.

The rear window defogger can be operated when

STY31AJZ03


The engine switch is in the ON position.

To prevent battery discharge

Do not leave the rear window defogger on longer than necessary when the engine is stopped.

3-1. Using the air conditioning system and defogger Rear window and outside rear view mirror defoggers^{*}

This feature is used to defog the rear window. (Turning the rear window defogger on will also turn the outside rear view mirror defoggers on. The outside rear view mirror defoggers is used to remove raindrops, dew and frost from the outside rear view mirrors.)



Turns the defoggers on/off

Press the button to turn on the rear window defogger. The indicator will come on. Pressing the button again also turns the defoggers off.

The rear window and outside rear view mirror defoggers can be operated when

The engine switch is in the ON position.

When the outside rear view mirror defoggers are on

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.


To prevent battery discharge

Do not leave the rear window and outside rear view mirror defoggers on longer than necessary when the engine is stopped.

3-2. Using the audio system Using the AUX port/USB port

This port can be used to connect a portable audio device and listen to it through the vehicle's speakers.

For more information, please refer to the "SCION Audio System Owner's Manual" or "SCION Navigation System Owner's Manual".



Open the cover and connect the portable audio device.

5

Operating portable audio devices connected to the audio system

The volume and sound quality can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable audio device itself.


When using a portable audio device connected to the power outlet

Noise may occur during playback. Use the battery power source of the portable audio device to reduce noise.

3-2. Using the audio system Using the steering wheel audio switches

Some audio features (audio volume control, radio, CD player etc.) can be controlled using the switches on the steering wheel.

For more information, please refer to the "SCION Audio System Owner's Manual" or "SCION Navigation System Owner's Manual".




A CAUTION

To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.

3-3. Using the interior lights Interior lights list



Illuminated entry system

When the interior light switch is in the D position, the interior light automatically turns on/off according to whether the doors are locked/unlocked, whether the doors are open/closed, and the engine switch position.


To prevent the battery from being discharged

If the interior light remains on when the door is not fully closed and the interior light switch is in the () position, the light will go off automatically after 20 minutes.


Customization that can be configured at Scion dealer

Settings (e.g. The time elapsed before lights turn off) can be changed. (Customizable features \rightarrow P. 343)

Interior light




Door position
 Off
 On



The interior light angle can be adjusted.

3-4. Using the storage features List of storage features



- 1 Bottle holders
- 2 Auxiliary box
- 3 Cup holder


A CAUTION

Items that should not be left in the storage spaces

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

- Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

Cup holder



A CAUTION

Items unsuitable for the cup holder


Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.

3-4. Using the storage features


Bottle holders

Bottle holders

► Front




►Rear



Items that should not be stowed in the bottle holders

Put the cap on before stowing a bottle. Do not place open bottles in the bottle holders, or glasses and paper cups containing liquid. The contents may spill and glasses may break.

Auxiliary box



Lift up the tray and pull it forward.

A CAUTION


While the vehicle is in motion

Keep the tray under the seat.

The pulled out tray may hit passengers or items in the tray may be thrown out in the event of an accident or sudden braking and may cause an accident.

Injuries may result in the event of an accident or sudden braking.


3-5. Other interior features **Sun visors**



- Forward position: Flip down.
- 2 Side position:


Flip down, unhook, and swing to the side.

3-5. Other interior features Vanity mirrors



3-5. Other interior features Power outlet

The power outlet can be used for 12 V accessories that run on less than 10 A.



The power outlet can be used when

The engine switch is in the ACC or ON position.

🕂 NOTICE

To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit.

To prevent the fuse from being blown


Do not use an accessory that uses more than 12 V 10 A.

To prevent battery discharge

Do not use the power outlet longer than necessary when the engine is not running.

3-5. Other interior features Assist grips

An assist grip installed on the ceiling can be used to support your body while sitting on the seat.



A CAUTION

Assist grip

Do not use the assist grip when getting in or out of the vehicle or rising from your seat.


NOTICE

To prevent damage to the assist grip


Do not hang any heavy object or put a heavy load on the assist grip.

3-5. Other interior features **Floor mat**

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.



Insert the retaining hooks (clips) into the floor mat eyelets.



Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.

*: Always align the \triangle marks.

The shape of the retaining hooks (clips) may differ from that shown in the illustration.

A CAUTION


Observe the following precautions.

Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle, leading to a serious accident.

When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles, even if they are Scion Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided.
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.


Before driving



- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- With the engine stopped and the shift lever in P, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.

3-5. Other interior features Luggage compartment features

Luggage box



Open the lid.

A CAUTION

Caution while driving

Keep the luggage box closed. Injuries may result in the event of an accident or sudden braking.

3-5. Other interior features

Maintenance and care

4

4-1. Maintenance and care

Cleaning and protecting	
the vehicle exterior	184
Cleaning and protecting	
the vehicle interior	187

4-2. Maintenance

Maintenance	
requirements	190
General maintenance	192
Emission inspection and	
maintenance (I/M)	
programs	195

4-3. Do-it-yourself maintenance

Do-it-yourself service	
precautions	196
Hood	199
Positioning a floor jack	201
Replacing the tire	204
Engine compartment	210
Tires	222
Tire inflation pressure	230
Wheels	234
Air conditioning filter	236
Key battery	240
Checking and replacing	
fuses	244
Light bulbs	255

4-1. Maintenance and care

Cleaning and protecting the vehicle exterior

Perform the following to protect the vehicle and maintain it in prime condition.

 Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.

Wash the vehicle body using a sponge or soft cloth, such as a car wash mitt.

 For hard-to-remove marks, use car wash soap and rinse thoroughly with water.

• Wipe away any water.

• Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

Automatic car washes

- Fold the mirrors and remove the antenna before washing the vehicle. Start washing from the front of the vehicle. Make sure to re-install the antenna and extend the mirrors before driving.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.

High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows.
- Before car wash, check that the fuel filler door on your vehicle is closed properly.

Bumpers

Do not scrub with abrasive cleaners.

CAUTION

Caution about the exhaust pipe

Exhaust gasses cause the exhaust pipe to become quite hot.

When washing the vehicle, be careful not to touch the pipe until it has cooled sufficiently, as touching a hot exhaust pipe can cause burns.

To prevent paint deterioration and corrosion on the body and components

• Wash the vehicle immediately in the following cases:

- · After driving near the sea coast
- · After driving on salted roads
- · If you see coal tar or tree sap on the paint surface
- · If you see dead insects, insect droppings or bird droppings on the paint
- After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
- · If the vehicle becomes heavily soiled in dust or mud
- If liquids such as benzene and gasoline are spilled on the paint surface
- If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush. This may damage the surfaces of the lights.
- Do not apply wax on the surfaces of the lights.
 Wax may cause damage to the lenses.

Antenna installation and removal precautions

Before driving, ensure that the antenna is installed.

When the antenna is removed, such as before entering an automatic car wash, make sure to store it in a suitable place so as not to lose it. Also, before driving, make sure to reinstall the antenna in its original position. 4

To prevent damage to the windshield wiper arms

When lifting the wiper arms away from the windshield, pull the driver side wiper arm upward first, and repeat for the passenger side. When returning the wipers to their original position, do so from the passenger side first.

4-1. Maintenance and care

Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

Protecting the vehicle interior

Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.

Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe any excess dirt and dust with a soft cloth dampened with diluted detergent.

Use a diluted water solution of approximately 5% neutral wool detergent.

- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded ventilated area.

Cleaning the synthetic leather areas

- Remove loose dirt using a vacuum cleaner.
- Apply a mild soap solution to the synthetic leather using a sponge or soft cloth.
- Allow the solution to soak in for a few minutes. Remove the dirt and wipe off the solution with a clean, damp cloth.

Caring for leather areas

Scion recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not apply water. Excellent results are obtained when keeping the carpet as dry as possible.

Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

CAUTION

Water in the vehicle

- Do not splash or spill liquid in the vehicle. Doing so may cause the electrical components etc. to malfunction or catch fire.
- Do not get any of the SRS components or wiring in the vehicle interior wet. $(\rightarrow P. 69)$

Electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or severe injury.

Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

Cleaning detergents

- Do not use organic substances such as benzene or gasoline, acidic or alkaline solutions, dye, bleach or other detergent. Doing so may discolor the vehicle interior or cause streaks or damage to painted surfaces.
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces.

- Remove any dust or dirt on leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time.
 Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or that contain wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components under the floor of the vehicle, and may also cause the body to rust.

Cleaning the inside of the rear window

- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires.
- Be careful not to scratch or damage the heater wires.

4-2. Maintenance Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance is essential. It is the owner's responsibility to perform regular checks. Scion recommends the following maintenance.

General maintenance

Should be performed on a daily basis. This can be done by yourself or by a Scion dealer.

Scheduled maintenance

Should be performed at specified intervals according to the maintenance schedule.

For details about maintenance items and schedules, refer to the "Scheduled Maintenance Guide" or "Owner's Manual Supplement".

Do-it-yourself maintenance

You can perform some maintenance procedures yourself. Please be aware that do-it-yourself maintenance may affect warranty coverage.

The use of Scion Repair Manuals is recommended.

For details about warranty coverage, see the separate "Owner's Warranty Information Booklet", "Owner's Manual Supplement".

Repair and replacement

It is recommended that genuine Scion parts be used for repair to ensure performance of each system. If non-Scion parts are used in replacement or if a repair shop other than Scion dealer performs repairs, confirm the warranty coverage.

Resetting the maintenance required remainder light (except Canada)

After the required maintenance is performed according to the maintenance schedule, please reset the remainder light.

To reset the data, follow the procedures described below:

STEP 1 Switch the display to the trip meter A (\rightarrow P. 127) when the engine is running.

- STEP 2 Turn the engine switch to the LOCK position.
- STEP 3 While pressing the MODE button, turn the engine switch to the ON position (but do not start the engine because otherwise the reset mode will be cancelled). Continue to press and hold the button until the trip meter displays "000000".

Allow inspection and repairs to be performed by a Scion dealer

- Scion technicians are well-trained specialists and are kept up to date with the latest service information. They are well informed about the operations of all systems on your vehicle.
- Keep a copy of the repair order. It proves that the maintenance that has been performed is under warranty coverage. If any problem should arise while your vehicle is under warranty, your Scion dealer will promptly take care of it.

CAUTION

If your vehicle is not properly maintained

It could result in serious damage to the vehicle and possible serious injury or death.

Warning in handling of battery

- Engine exhaust, some of its constituents, and a wide variety of automobile components contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm. Work in a well ventilated area.
- Oils, fuels and fluids contained in vehicles as well as waste produced by component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Avoid exposure and wash any affected area immediately.
- Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. (→P. 218)

Listed below are the general maintenance items that should be performed at the intervals specified in the "Owner's warranty Information Booklet" or "Owner's Manual Supplement/Scheduled Maintenance Guide". It is recommended that any problem you notice should be brought to the attention of your Scion dealer or qualified service shop for advice.

Engine compartment

Items	Check points
Battery	Maintenance-free. $(\rightarrow P. 218)$
Brake fluid	At the correct level? $(\rightarrow P. 217)$
Engine coolant	At the correct level? $(\rightarrow P. 215)$
Engine oil	At the correct level? $(\rightarrow P. 211)$
Exhaust system	No fumes or strange sounds?
Radiator/condenser/hoses	Not blocked with foreign matter? $(\rightarrow P. 216)$
Washer fluid	At the correct level? $(\rightarrow P. 220)$

Vehicle interior

Items	Check points
Accelerator pedal	• Moves smoothly (without uneven pedal effort or catching)?
Automatic transmission "Park" mechanism	• Can the vehicle be hold securely on an incline with the shift lever in P?
Brake pedal	 Moves smoothly? Does it have appropriate clear- ance and correct amount of free play?
Brakes	 Not pull to one side when applied? Loss of brake effectiveness? Spongy feeling brake pedal? Pedal almost touches floor?
Head restraints	 Move smoothly and lock securely?
Indicators/buzzers	Function properly?
Lights	Do all the lights come on?Headlights aimed correctly?
Parking brake	Moves smoothly?Can hold the vehicle securely on an incline?
Seat belts	Does the seat belt system oper- ate smoothly?Are the belts undamaged?
Seats	• Do the seat controls operate properly?
Steering wheel	Moves smoothly?Has correct free play?No strange noises?

Vehicle exterior

Items	Check points
Doors	Operate smoothly?
Engine hood	• The lock system works properly?
Fluid leaks	 Is there any leakage after park- ing?
Tires	 Inflation pressure is correct? Tire surfaces not worn or damaged? Tires rotated according to the maintenance schedule? Wheel nuts are not loose?
Windshield wipers/rear window wiper	 The wiper blades should not show any signs of cracking, splitting, wear, contamination or deformation. The wiper blades should clear the windshield/rear window without streaking or skipping.

CAUTION

If the engine is running

Turn the engine off and ensure that there is adequate ventilation before performing maintenance checks. Some states have vehicle emission inspection programs which include OBD (On Board Diagnostics) checks. The OBD system monitors the operation of the emission control system.

If the malfunction indicator lamp comes on

The OBD system determines that a problem exists somewhere in the emission control system. Your vehicle may not pass the I/ M test and may need to be repaired. Contact your Scion dealer to service the vehicle.

Your vehicle may not pass the I/M test:

When the battery is disconnected or discharged

Readiness codes that are set during ordinary driving are erased.

Also, depending on your driving habits, the readiness codes may not be completely set.

When the fuel tank cap is loose

The malfunction indicator lamp comes on as a temporary malfunction and your vehicle may not pass the I/M test.

When the malfunction indicator lamp goes off after several driving trips

The error code in the OBD system will not be cleared unless the vehicle is driven 40 or more times.

If your vehicle does not pass the I/M test

Contact your Scion dealer to prepare the vehicle for re-testing.

4-3. Do-it-yourself maintenance Do-it-yourself service precautions

If you perform maintenance yourself, be sure to follow the correct procedures as given in these sections.

Items		Parts and tools
Battery condition	(→P. 218)	 Warm water Baking soda Grease Conventional wrench (for terminal clamp bolts)
Brake fluid level	(→P. 217)	 FMVSS No.116 DOT 3 or SAE J1703 brake fluid Rag or paper towel
Engine coolant level	(→P. 215)	 "Toyota Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non- amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology. Except Canada: "Toyota Super Long Life Coolant" is pre-mixed with 50% coolant and 50% deionized water. Canada: "Toyota Super Long Life Coolant" is pre-mixed with 55% coolant and 45% deionized water. Funnel (used only for adding cool- ant)
Engine oil level	(→P. 211)	 Toyota Genuine Motor Oil or equivalent Rag or paper towel Funnel (used only for adding oil)
Fuses	(→P. 244)	 Fuse with same amperage rating as original

Items		Parts and tools
Light bulbs	(→P. 255)	Bulb with same number and watt- age rating as originalFlathead screwdriver
Radiator and conder	nser (→P. 216)	
Tire inflation pressu	ıre (→P. 230)	Tire pressure gaugeCompressed air source
Washer fluid	(→P. 220)	 Water washer fluid containing antifreeze (for winter use) Funnel (used only for adding washer fluid)

CAUTION

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions.

When working on the engine compartment

- Keep hands, clothing, and tools away from the moving fan and engine drive belt.
- Be careful not to touch the engine, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper or rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel or the battery. Fuel and battery fumes are flammable.
- Be extremely cautious when working on the battery. It contains poisonous and corrosive sulfuric acid.

4

CAUTION

When working on the engine compartment

 Take care because brake fluid can harm your hands or eyes and damage painted surfaces.

If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, see a doctor.

When working near the electric cooling fan or radiator grille

Be sure the engine switch is in the LOCK position.

With the engine switch in the ON position, the electric cooling fan may automatically start to run if the air conditioning system is on and/or the coolant temperature is high. (\rightarrow P. 216)

Safety glasses


Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in the eyes.

NOTICE

If you remove the air cleaner


Driving with the air cleaner removed may cause excessive engine wear due to dirt in the air.

Release the lock from the inside of the vehicle to open the hood.




Pull the hood lock release lever.

The hood will pop up slightly.



Pull up the hood catch lever and lift the hood.



Hold the hood open by inserting the supporting rod into the slot.

CAUTION

Pre-driving check

Check that the hood is fully closed and locked.

If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

When opening the hood

Make sure to use the support rod to support the hood when opening it, ensuring that the rod is fixed correctly. The hood may stay open without support on slope, however, it is dangerous because the hood may suddenly close.

NOTICE

When closing the hood

Be sure to return the support rod to its clip before closing the hood. Closing the hood with the support rod up could cause the hood to bend.


4-3. Do-it-yourself maintenance **Positioning a floor jack**

a

ഹ

When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

Front




STY43AJZ16

CAUTION


When raising your vehicle

Make sure to observe the following to reduce the possibility of death or serious injury.



• Lift up the vehicle using a floor jack such as the one shown in the illustration.

- When using a floor jack, follow the instructions of the manual provided with the jack.
- Do not use the jack for tire replacement which can be purchased at Scion dealer for your vehicle.
- Do not put any part of your body or get underneath the vehicle supported only by the floor jack.
- Always use floor jack and/or automotive jack stands on a solid, flat, level surface.
- Do not start the engine while the vehicle is supported by the floor jack.
- Stop the vehicle on level firm ground, firmly set the parking brake and put the shift lever in P.
- Make sure to set the floor jack properly at the jack point.
 Raising the vehicle with an improperly positioned floor jack will damage the vehicle and may cause the vehicle to fall off the floor jack.



 Do not jack the vehicle at sections such as the rear suspension. The vehicle may be damaged.

Do not raise the vehicle while someone is in the vehicle.

A CAUTION

When raising your vehicle

 When raising the vehicle, do not place any objects on top of or underneath the floor jack.

4-3. Do-it-yourself maintenance Replacing the tire


When raising your vehicle with a jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

Jack, wheel nut wrench and wheel chocks can be purchased at your Scion dealer.

Before jacking up the vehicle


- Stop the vehicle on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P.
- Stop the engine.

Replacing a tire



Chock the tires.


Tire position		Wheel chock positions
Front Right- hand side	Behind and in front of the rear right- hand side tire	
	Behind and in front of the rear left-hand side tire	
Rear	Left- hand side	Behind and in front of the front right- hand side tire
Right- hand side	hand	Behind and in front of the front left-hand side tire



STEP 3


Slightly loosen the wheel nuts (one turn).

Check the jack point.




STY43AJZ55

Turn the jack portion "A" by hand until the notch of the jack is in contact with the jack point.




Raise the vehicle until the tire is slightly raised off the ground.



Remove all the wheel nuts and the tire.


When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.

Installing the tire



Remove any dirt or foreign matter from the wheel contact surface.


If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, and the tire may come off the vehicle. STEP 2 Install the tire and loosely tighten each wheel nut by hand by approximately the same amount.



Tighten the nuts until the tapered portion comes into loose contact with the disc wheel sheet.

STEP 3

Lower the vehicle.



STEP 5 Stow the jack and all tools.

Firmly tighten each nut two or three times in the order shown in the illustration.

Tightening torque:

76 ft-lbf (103 N·m, 10.5 kgf·m)

CAUTION

Using the jack

Improper use of the jack may lead to death or serious injuries due to the vehicle suddenly falling off the jack.

- Do not use the jack for any purpose other than replacing tires or installing and removing tire chains.
- Do not use it on other vehicles, and do not use other jacks for replacing tires on this vehicle.
- Always check that the jack is securely set to the jack point.
- Do not put any part of your body under the vehicle supported by a jack.
- Do not start or run the engine while your vehicle is supported by the jack.
- Do not raise the vehicle while someone is in it.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.

Take particular care when lowering the vehicle to ensure that no one working on or near the vehicle will be injured.


Replacing a tire

Observe the following precautions to reduce the risk of death or serious injury.

Have the wheel nuts tightened with a torque wrench to 76 ft-lbf (103 N·m, 10.5 kgf·m) as soon as possible after changing wheels.
 Failure to follow these precautions could cause the nuts to loosen and the wheel may fall off, which could lead to an accident causing death or serious injury.

 Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.

When installing the wheel nuts



Be sure to install the wheel nuts with the tapered end facing inward. Installing the nuts with the tapered end facing outward can cause wheel to break and eventually cause a wheel to come off while driving, which could lead to an accident resulting in death or serious injury.

• Never use oil or grease on the wheel bolts or wheel nuts.


Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing an accident and resulting in death or serious injury. Remove any oil or grease from the wheel bolts or wheel nuts.

Location of tools

There are no place to install the jack, wheel nut wrench and wheel chocks, so do not put it inside the vehicle.

Failure to follow the precaution could cause the interior to get damaged, the tools may fly out in events such as sudden braking, and may cause an accident.

4-3. Do-it-yourself maintenance Engine compartment




Engine oil

With the engine at operating temperature and turned off, check the oil level on the dipstick.


Checking the engine oil

STEP 1 Park the vehicle on level ground. After turning off the engine, wait more than 5 minutes for the oil to drain back into the bottom of the engine.



Hold a rag under the end and pull the dipstick out.

- STEP 3 Wipe the dipstick clean.
- STEP 4 Reinsert the dipstick fully.
- STEP 5 Holding a rag under the end, pull the dipstick out and check the oil level.



1 Low

2 Normal


3 Excessive

The shape of the dipstick may differ depending on the type of vehicle or engine.

STEP 6 Wipe the dipstick and reinsert it fully.

4

Adding engine oil



If the oil level is below or near the low level mark, add engine oil of the same type as already in the engine.

Make sure to check the oil type and prepare the items needed before adding oil.

Engine oil selection	→P. 323
Items	Clean funnel

- STEP 1 Remove the engine oil filler cap by turning it counterclockwise.
- STEP 2 Add engine oil slowly.
- STEP 3 Checking the dipstick.
- STEP 4 Reinstall the engine oil filler cap by turning it clockwise.

The approximate quantity of oil needed to raise the level between low and full on the dipstick is indicated as follows:

1.6 qt. (1.5 L, 1.3 Imp. qt.)

Engine oil consumption

A certain amount of engine oil will be consumed while driving. In the following situations, oil consumption may increase, and engine oil may need to be refilled in between oil maintenance intervals.

- When the engine is new, for example directly after purchasing the vehicle or after replacing the engine
- If low quality oil or oil of an inappropriate viscosity is used
- When driving at high engine speeds or with a heavy load, or when driving while accelerating or decelerating frequently
- When leaving the engine idling for a long time, or when driving frequently through heavy traffic

A CAUTION

Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation or skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground. Call your Scion dealer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.

🔨 NOTICE

To prevent serious engine damage


Check the oil level on regular basis.

When replacing the engine oil

- Be careful not to spill engine oil on the vehicle components.
- Avoid overfilling, as the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.

Engine coolant

The coolant level is satisfactory if it is between the FULL and LOW lines on the reservoir when the engine is cold.



1 Reservoir cap 2 FULL 3 LOW

If the level is on or below the LOW line, add coolant up to the FULL line.

If the coolant level drops within a short time after replenishing

Visually check the radiator, hoses, reservoir cap, radiator cap, drain cock and water pump.

If you cannot find a leak, have your Scion dealer pressure test the cap and check for leaks in the cooling system.

Coolant selection

Only use "Toyota Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

- Except Canada: "Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Enabled: -31°F [-35°C])
- Canada: "Toyota Super Long Life Coolant" is a mixture of 55% coolant and 45% deionized water. (Enabled: -44°F [-42°C])

For more details about engine coolant, contact your Scion dealer.

CAUTION

When the engine is hot

Do not remove the coolant reservoir cap.

The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.

When adding engine coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

If you spill coolant

Be sure to wash it off with water to prevent damage to parts or paint.

Radiator and condenser

Check the radiator and condenser and clear any foreign objects. If either of the above parts are extremely dirty or you are not sure of their condition, have your vehicle checked by your Scion dealer.


CAUTION

When the engine is hot

Do not touch the radiator or condenser, as they may be hot and may cause serious injuries, such as burns.

Brake fluid

Checking fluid level



The brake fluid level should be between the MAX and MIN lines on the reservoir.

Adding fluid

Make sure to check the fluid type and prepare the necessary items.

Brake fluid can absorb moisture from the air

Excess moisture in the fluid can cause a dangerous loss of braking efficiency. Use only newly opened brake fluid.

CAUTION

When filling the reservoir

Take care because brake fluid can harm your hands or eyes and damage painted surfaces.

If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, see a doctor.

If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, it may indicate a serious problem.


If you spill fluid

Be sure to wash it off with water to prevent damage to parts or paint.

Battery

Battery exterior

Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.



1 Terminals

2 Hold-down clamp

Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.

CAUTION

Chemicals in the battery

A battery contains poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near battery:

- Do not cause sparks by touching the battery terminals with tools.
- Do not smoke or light a match near the battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the battery.
- Keep children away from the battery.

Where to safely charge the battery

Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is not sufficient ventilation.

How to recharge the battery

Only perform a slow charge (5A or less). The battery may explode if charged at a quicker rate.

Emergency measures regarding electrolyte

If electrolyte gets in your eyes

Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.

If electrolyte gets on your skin

Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.

If electrolyte gets on your clothes

It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.

If you accidentally swallow electrolyte

Drink a large quantity of water or milk. Get emergency medical attention immediately.


4

When recharging the battery

Never recharge the battery while the engine is running. Also, be sure all accessories are turned off.

Washer fluid

If any washer does not work or the low washer fluid warning light comes on, the washer tank may be empty.



Open the lid.



Add washer fluid.

CAUTION

When refilling the washer fluid

Do not refill the washer fluid when the engine is hot or running, as the washer fluid contains alcohol and may catch fire if spilled on the engine, etc.

Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.


Diluting washer fluid

Dilute washer fluid with water as necessary. Refer to the freezing temperatures listed on the label of the washer fluid bottle.


4-3. Do-it-yourself maintenance **Tires**

Replace or rotate tires in accordance with maintenance schedules and treadwear.

Checking tires



Tire rotation



New tread
 Treadwear indicator

3 Worn tread

The location of treadwear indicators is shown by the "TWI" or " \triangle " marks, etc., molded on the sidewall of each tire.

Rotate the tires in the order shown.

To equalize tire wear and extend tire life, Scion recommends that tire rotation is carried out at the same interval as tire inspection.

The tire pressure warning system

Your Scion is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise. (\rightarrow P. 280)

Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new tire pressure warning valve and transmitter ID codes must be registered in the tire pressure warning computer and the tire pressure warning system must be initialized. Have tire pressure warning valve and transmitter ID codes registered by your Scion dealer.

Initializing the tire pressure warning system

The tire pressure warning system must be initialized when rotating the tires on vehicles differing with front and rear tire inflation pressures.

When the tire pressure warning system is initialized, the current tire inflation pressure is set as the pressure benchmark.

How to initialize the tire pressure warning system


STEP 1 Park the vehicle in safe place and turn the engine switch off.

Initialization cannot be performed while the vehicle is moving.

STEP 2 Adjust the tire inflation pressure to the specified cold tire inflation pressure level. (\rightarrow P. 327)

Make sure to adjust the tire pressure to the specified cold tire inflation pressure level. The tire pressure warning system will operate based on this pressure level.

STEP 3 Turn the engine switch to the ON position.



Push and hold the tire pressure warning reset switch until the tire pressure warning light blinks slowly 3 times.

STEP 5 Wait for a few minutes with the engine switch on, and then turn the engine switch to the ACC or LOCK position.

Registering ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code of tire pressure warning valve and transmitter. Have the ID code registered by your Scion dealer.

When to replace your vehicle's tires

Tires should be replaced if:

- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric or bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage
- If you are not sure, consult with your Scion dealer.

Replacing tires and wheels

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After driving for about 20 minutes, the tire pressure warning light blinks for 1 minute and stays on to indicate a system malfunction.

Tire life

Any tire over 6 years old must be checked by a qualified technician even if they have seldom or never been used or damage is not obvious.

If the tread wears down below 0.16 in. (4 mm) on snow tires

The effectiveness of snow tires is lost.

Maximum load of tire

Check that the maximum load of the replacement tire is greater than 1/2 of the Gross Axle Weight Ratings (GAWR) of either the front axle or the rear axle, whichever is greater.



For the GAWR, see the Certification Label. For the maximum load of the tire, see the load limit at maximum cold tire inflation pressure mentioned on the sidewall of the tire. (\rightarrow P. 332)

Tire types

1 Summer tires

Summer tires are high-speed performance tires best suited to highway driving under dry conditions. Since summer tires do not have the same traction performance as snow tires, summer tires are inadequate for driving on snow-covered or icy roads. For driving on snow-covered roads or icy roads, the use of snow tires is recommended. When installing snow tires, be sure to replace all four tires.

2 All season tires

All season tires are designed to provide better traction in snow and to be adequate for driving in most winter conditions, as well as for use year round. All season tires, however, do not have adequate traction performance compared with snow tires in heavy or loose snow. Also, all season tires fall short in acceleration and handling performance compared with summer tires in highway driving. 4

3 Snow tires

For driving on snow-covered roads or icy roads, we recommend using snow tires. If you need snow tires, select tires of the same size, construction and load capacity as the originally installed tires. Since your vehicle has radial tires as original equipment, make sure your snow tires also have radial construction. Do not install studded tires without first checking local regulations for possible restriction. Snow tires should be installed on all wheels. (\rightarrow P. 151)

Initializing the tire pressure warning system

Initialize the tires with the tire inflation pressure adjusted to the specified level.

If you push the tire pressure warning reset switch accidentally

If initialization is performed, adjust the tire inflation pressure to the specified level and initialize the tire pressure warning system again.

When the initialization of the tire pressure warning system has failed

Initialization can be completed in a few minutes. However, in the following cases, the settings has not been recorded and the system will not operate properly. If repeated attempts to record tire inflation pressure settings are unsuccessful, have the vehicle inspected by your Scion dealer.

- When operating the tire pressure warning reset switch, the tire pressure warning light does not blink 3 times.
- After carrying out the initialization procedure, the tire pressure warning light blinks for 1 minute then stays on after driving for about 20 minutes.

Routine tire inflation pressure checks

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

Tire pressure warning system certification

FCC ID: PAXPMV107J

FCC ID: HYQ13BCX

► For vehicles sold in U.S.A.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► For vehicles sold in Canada

NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAUTION

When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train, as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns. Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Scion.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle.
- Do not use tires if you do not know how they were used previously.

When initializing the tire pressure warning system

Do not operate the tire pressure warning reset switch without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.

Repairing or replacing tires, wheels, tire pressure warning valves and transmitters and tire valve caps

- When removing or fitting the wheels, tires or the tire pressure warning valves and transmitters, contact your Scion dealer as the tire pressure warning valves and transmitters may be damaged if not handled correctly.
- When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.

To avoid damaging the tire pressure warning valves and transmitters

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Scion dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire. (\rightarrow P. 223)

Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes.

These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.


If tire inflation pressures become low while driving

Do not continue driving, or your tires and/or wheels may be ruined.


4-3. Do-it-yourself maintenance Tire inflation pressure

Tire inflation pressure

The recommended cold tire inflation pressure and tire size is displayed on the tire and loading information label. (\rightarrow P. 327)



Inspection and adjustment procedure



Tire valve
 Tire pressure gauge

STEP 1 Remove the tire valve cap.

STEP 2 Press the tip of the tire pressure gauge onto the tire valve.

STEP 3 Read the pressure using the graduations of the gauge.

STEP 4 If the tire inflation pressure is not within the recommended levels, adjust inflate the tire.

If you add too much air, press the center of the valve to lower.

- STEP 5 After completing the tire inflation pressure measurement and adjustment, apply soapy water to the valve and check for leakage.
- STEP 6 Reinstall the tire valve cap.

Tire inflation pressure check interval

You should check tire inflation pressure every two weeks, or at least once a month.

Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel efficiency
- Reduced driving comfort and tire life
- Reduced safety
- Damage to the drive train

If a tire needs frequent refilling, have it checked by your Scion dealer.

Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

• Check only when the tires are cold.

If your vehicle has been parked for at least 3 hours and has not been driven for more than 1 mile or 1.5 km, you will get an accurate cold tire inflation pressure reading.

• Always use a tire pressure gauge.

The appearance of the tire can be misleading. In addition, tire inflation pressures that are even just a few pounds off can degrade ride and handling.

 Do not bleed or reduce tire inflation pressure after driving. It is normal for the tire inflation pressure to be higher after driving.

Never exceed the vehicle capacity weight.

Passengers and luggage weight should be placed so that the vehicle is balanced.

CAUTION

Proper inflation is critical to save tire performance

Keep your tires properly inflated. Otherwise, the following conditions may occur and result in an accident causing death or serious injury.

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Poor sealing of the tire bead
- Wheel deformation and/or tire separation
- A greater possibility of tire damage from road hazards

🕂 NOTICE

When inspecting and adjusting tire inflation pressure

Be sure to reinstall the tire valve caps.

Without the valve caps, dirt or moisture could get into the valve and cause air leakage, which could result in an accident. If the caps have been lost, replace them as soon as possible.

4-3. Do-it-yourself maintenance Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced.

Otherwise, the tire may separate from the wheel or cause loss of handling control.

Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width, and inset^{*}.

Replacement wheels are available at your Scion dealer.

*: Conventionally referred to as "offset".

Scion does not recommend using the following:

Wheels of different sizes or types

- Used wheels
- Bent wheels that have been straightened

When replacing wheels

The wheels of your Scion are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advance warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, tire pressure warning valves and transmitters must be installed. (\rightarrow P. 223)

CAUTION

When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.
- Be sure to install the wheel nuts with the tapered end facing inward.
 (→P. 209)

Replacing tire pressure warning valves and transmitters


- Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Scion dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Scion dealer.
- Ensure that only genuine Scion wheels are used on your vehicle. Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.


4-3. Do-it-yourself maintenance Air conditioning filter

The air conditioning filter must be cleaned or changed regularly to maintain air conditioning efficiency.

Removal method

STEP 1 Turn the engine switch to the LOCK position.





Remove the filter cover.


Remove the air conditioning filter from between the knee airbag support and dash panel insulator.

When removing the air conditioning filter, make sure that dust or dirt does not enter the air conditioning system.

Cleaning method


If the filter is dirty, clean by blowing compressed air through the filter as shown in the illustration.

► Type A



Hold the air gun 2 in. (5 cm) from the filter and blow for approximately 2 minutes at 72 psi (500 kPa, 5.0 kgf/cm² or bar).

► Type B




Hold the air gun 2 in. (5 cm) from the filter and blow for approximately 2 minutes at 72 psi (500 kPa, 5.0 kgf/cm² or bar).

If it is not available, have the filter cleaned by your Scion dealer.

Restoration method

► Type A




The " \uparrow UP" marks shown on the filter should be pointing up.

Replacement method

Replace the air conditioning filter with a new one.

► Type B



The " \uparrow UP" marks shown on the filter should be pointing up.

Checking interval

Inspect, clean and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, more frequent cleaning or early replacement may be required. (For scheduled maintenance information, please refer to the "Scheduled Maintenance Guide" or "Owner's Manual Supplement".)

If air flow from the vents decreases dramatically

The filter may be clogged.

- Type A: Check the filter and clean if necessary.
- Type B: Check the filter and replace if necessary.

NOTICE


To prevent damage to the system

- When using the air conditioning system, make sure that a filter is always installed.
- Type B: When cleaning the filter, do not clean the filter with water.

4-3. Do-it-yourself maintenance **Key battery**

Replace the battery with a new one if it is discharged. You will need the following items: • Flathead screwdriver (To prevent damage to the key, cover the tip of the screwdriver with tape.) Small flathead screwdriver Lithium battery For types A and B electronic key (\rightarrow P. 24): CR2016 For type C electronic key (\rightarrow P. 24): CR1620 Replacing the battery For types A and B electronic key (\rightarrow P. 24) Remove the cover. STEP 1 STS43AJ014 Remove the module. STEP 2


STY63AW029



Open the case cover using a coin protected with tape etc. and remove the depleted battery.


Insert a new battery with the "+" terminal facing up.

For type C electronic key (\rightarrow P. 24)



Lift the cover.


Insert the screw driver in the slot and push down.



Remove the cover.

Insert the screw driver in the bottom of the key and push down.

4



Remove the depleted battery.

Insert a new battery with the "+" terminal facing up.

If the key battery is discharged

The following symptoms may occur.

- The wireless remote control will not function properly.
- The operational range is reduced.

Use a lithium battery

- Batteries can be purchased at your Scion dealer, jewelers, or camera stores.
- Replace only with the same or equivalent type recommended by your Scion dealer.
- Dispose of used batteries according to local laws.

A CAUTION

Removed battery and other parts

These parts are small and if swallowed by a child, they can cause choking. Keep away from children. Failure to do so could result in death or serious injury.

For normal operation after replacing the battery

Observe the following precautions to prevent accidents.

- Always work with dry hands.
 Moisture may cause the battery to rust.
- Do not touch or move any other components inside the remote control.
- Do not bend either of the battery terminals.

4-3. Do-it-yourself maintenance Checking and replacing fuses


If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

STEP 1 Turn the engine switch to the LOCK position.


STEP 2 The fuses are located in the following places. To check the fuses, follow the instructions below.

Engine compartment


► Type A



Remove the cover.




► Type B




Push the tab in and lift the lid off.

► Type C




Push the tab in and lift the lid off.

Under the driver's side instrument panel



Remove the lid.


STEP 3 After a system failure, see "Fuse layout and amperage ratings" (→P. 248) for details about which fuse to check.



Remove the fuse with the pullout tool.


STEP 5 Check if the fuse has blown.

► Type A




Normal fuse Blown fuse

Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.



► Type C




Normal fuse Blown fuse

Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

Normal fuse Blown fuse

Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

► Type D




Normal fuse Blown fuse

Contact your Scion dealer.


Fuse layout and amperage ratings

Engine compartment (type A)




Fuse		Ampere	Circuit
1	ALT	120 A	Charging system, RDI, ABS NO.1, ABS NO.2, HTR-B, ACC, CIG, GAUGE, ECU-IG NO.1, HTR-IG, WIPER WASHER, AM1, DOOR NO.1, STOP, DOOR NO.2, OBD, FR FOG, DEF, TAIL, EPS, PTC NO.1, PTC NO.2, PTC NO.3, D/L NO.1, PANEL NO.1
2	MAIN	80 A	EFI MAIN, EFI NO.1, HORN, AM2 NO.1, DOME, ECU-B NO.2, TURN&HAZ, H-LP MAIN, H-LP MAIN HI, ECU-B NO.1, D/C CUT, ETCS, IG2, IGN, ALT-S

Engine compartment (type B)




	Fuse	Ampere	Circuit
1	D/C CUT	30 A	ECU-B NO.1, DOME
2	IMMOBI	7.5 A	ІММОВІ
3	TURN & HAZ	10 A	Turn signal lights, emergency flashers
4	ETCS	10 A	Electronic throttle control system
5	ECU-B NO.2	5 A	Meter, power windows, air condi- tioning system
6	H-LP MAIN	20 A	H-LP RH LO, H-LP LH LO
7	SPARE	30 A	Spare fuse
8	SPARE	20 A	Spare fuse
9	SPARE	5 A	Spare fuse
10	AM2 NO.1	30 A	Starting system
11	H-LP MAIN HI	25 A	H-LP RH HI, H-LP LH HI
12	DOME	15 A	Interior light, audio system
13	ECU-B NO.1	7.5 A	Main body ECU, power door lock system
14	MIR HTR	7.5 A	Outside rear view mirror defoggers

Fuse		Ampere	Circuit
15	DEFOGGER	30 A	Rear window defogger
16	EPS	50 A	Electric power steering
17	RDI	30 A	RDI FAN
18	ABS NO.1	50 A	Vehicle stability control system
19	HTR-B	40 A	HTR, BLR
20	ABS NO.2	30 A	Vehicle stability control system
21	HORN	10 A	Horn
22	EFI-MAIN	20 A	Multiport fuel injection system/ sequential multiport fuel injection system, EFI NO.1, Fuel pump
23	ALT-S	7.5 A	Charging system
24	IGN	15 A	Injection, igniter
25	IG2	10 A	SRS airbag system, meter
26	EFI NO.1	10 A	Multiport fuel injection system/ sequential multiport fuel injection system



Fuse		Ampere	Circuit
1	PTC NO.1	50 A	PTC heater
2	PTC NO.3	30 A	PTC heater
3	PTC NO.2	30 A	PTC heater
4	H-LP RH HI	10 A	Headlight (high beam)
5	H-LP LH HI	10 A	Headlight (high beam)
6	H-LP RH LO	10 A	Right-hand headlight (low beam)
7	H-LP LH LO	10 A	Left-hand headlight (low beam)

Under the driver's side instrument panel



	Fuse	Ampere	Circuit
1	ECU-IG NO.1	7.5 A	Vehicle stability control system, shift lock control system, electric power steering, automatic head- light system, main body ECU, tire pressure warning system
2	GAUGE	10 A	Electric cooling fan, charging sys- tem, emergency flashers, front passenger's seat belt reminder light, back-up lights, multiport fuel injection system/sequential multi- port fuel injection system, wind- shield wiper ECU
3	HTR-IG	10 A	Air conditioning system, rear win- dow defogger
4	WASHER RR	10 A	Windshield washer
5	WIPER RR	10 A	Rear window wiper
6	WIPER FR	25 A	Windshield wipers
7	WASHER FR	10 A	Windshield washer
8	OBD	7.5 A	On-board diagnosis system
9	DOOR NO.2	20 A	Power windows

Fuse Am		Ampere	Circuit
10	D/L NO.1	15 A	Power door lock system, main body ECU
11	DOOR NO.1	30 A	Power windows
12	CIG	15 A	Power outlet
13	ACC	5 A	Outside rear view mirrors, audio system, shift lock control system, main body ECU
14	PANEL NO.1	5 A	Meter
15	TAIL	10 A	Parking lights, tail lights, license plate lights, multiport fuel injection system/sequential multiport fuel injection system, instrument clus- ter, windshield wiper ECU
16	(FOG FR)	15 A	No circuit
17	AM1	7.5 A	ACC, starting system
18	STOP	10 A	Vehicle stability control system, power management ECU, shift lock control system, stop lights, multiport fuel injection system/ sequential multiport fuel injection system
19	(SEAT-HTR)	15 A	No circuit

After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P. 255)
- If the replaced fuse blows again, have the vehicle inspected by your Scion dealer.

If there is an overload in the circuits

The fuses are designed to blow, protecting the wiring harness from damage.

To prevent system breakdowns and vehicle fire

Observe the following precautions.

Failing to do so may cause damage to the vehicle, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than indicated, or use any other object in place of a fuse.
- Always use a genuine Scion fuse or equivalent.
 Never replace a fuse with a wire, even as a temporary fix.
- Do not modify the fuse or the fuse box.

Before replacing fuses

Have the cause of electrical overload determined and repaired by your Scion dealer as soon as possible.

4-3. Do-it-yourself maintenance Light bulbs


You may replace the following bulbs yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact your Scion dealer.

For more information about replacing other light bulbs, contact your Scion dealer.


Prepare a replacement light bulb.

Check the wattage of the light bulb being replaced. (\rightarrow P. 328)

Front bulb locations




4




Replacing light bulbs

Headlight low beams

► Left side



Push the tab in and lift the lid off.



STEP 3


STEP 4

Turn the cover clockwise.


Turn the bulb base counterclockwise.

Unplug the connector while depressing the lock release.


► Right side



Turn the cover counterclockwise.




Turn the bulb base counterclockwise.



Unplug the connector while depressing the lock release.


Headlight high beams and daytime running lights


► Left side




Push the tab in and lift the lid off.

Turn the cover clockwise.






Turn the bulb base clockwise.




Unplug the connector while depressing the lock release.

► Right side



Turn the cover counterclockwise.




STEP 3

Turn the bulb base counterclockwise.


Unplug the connector while depressing the lock release.



STY43AJZ45




Turn the bulb base counterclockwise.




Remove the light bulb.

Front turn signal lights




Turn the bulb base counterclockwise.




Remove the light bulb.

- Back-up lights, stop/tail and rear side marker lights and rear turn signal lights
- STEP 1 Open the back door. (\rightarrow P. 33)
- STEP 2 Folding down rear seatbacks. (\rightarrow P. 40)



Remove the cover.

Use a flathead screwdriver which is wrapped with a cloth.




Turn the bulb bases counterclockwise.

- Stop/tail and rear side marker light
- 2 Rear turn signal light
- 3 Back-up light

Remove the light bulb.


- Stop/tail and rear side marker light
- 2 Rear turn signal light
- 3 Back-up light

License plate lights




Disengage the claws.


Use a flathead screwdriver which is wrapped with a cloth.



Remove the license plate light.



Turn the bulb base counterclockwise.



Remove the light bulb.

Lights other than the above

If any of the lights listed below has burned out, have it replaced by your Scion dealer.

- Side turn signal lights
- High mounted stoplight

When replacing the left side headlight

Be sure to install the fuse cover properly.

Condensation build-up on the inside of the lens

Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction.

Contact your Scion dealer for more information in the following situations:

- Large drops of water are built up on the inside of the lens.
- Water has built up inside the headlight.

LED high mounted stoplight

The high mounted stoplight consists of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Scion dealer to have the light replaced.

CAUTION

Replacing light bulbs

 Turn off the headlights. Do not attempt to replace the bulb immediately after turning off the headlights.

The bulbs become very hot and may cause burns.

 Do not touch the glass portion of the light bulb with bare hands. When it is unavoidable to hold the glass portion, use and hold with a clean dry cloth to avoid getting moisture and oils on the bulb.

Also, if the bulb is scratched or dropped, it may blow out or crack.

Fully install light bulbs and any parts used to secure them. Failing to do so may result in heat damage, fire, or water entering the headlight unit. This may damage the headlights or cause condensation to build up on the lens.

To prevent damage or fire

Make sure bulbs are fully seated and locked.

When trouble arises

5

5-1. Essential information


Emergency flashers	268
If your vehicle needs to	
be towed	269
If you think something	
is wrong	275
Fuel pump shut off	
	276

5-2. Steps to take in an emergency

If a warning light turns on	
or a warning buzzer	
sounds	277
If you have a flat tire	288
If the engine will not	
start	305
If the shift lever cannot	
be shifted from P	307
If you lose your keys	308
If the vehicle battery	
is discharged	309
If your vehicle	
overheats	312
If the vehicle becomes	
stuck	315
If your vehicle has to	
be stopped in	
an emergency	317

5-1. Essential information **Emergency flashers**

Use the emergency flashers if the vehicle malfunctions or is involved in an accident.



Press the switch to flash all the turn signal lights. To turn them off, press the switch once again.

To prevent battery discharge

Do not leave the emergency flashers on longer than necessary when the engine is not running.

If towing is necessary, we recommend having your vehicle towed by your Scion dealer or commercial towing service, using a lift-type truck or a flatbed truck.


Use a safety chain system for all towing, and abide by all state/provincial and local laws.

Situations needs to contact dealers before towing

The following may indicate a problem with your transmission. Contact your Scion dealer or a commercial towing service before towing.

- The engine is running but the vehicle will not move.
- The vehicle makes an abnormal sound.


Towing with a sling-type truck




Do not tow with a sling-type truck to prevent body damage.

Towing with a wheel-lift type truck

From the front




From the rear




Release the parking brake.

Use a towing dolly under the front wheels.

Using a flatbed truck



If your Scion is transported by a flatbed truck, it should be tied down at the locations shown in the illustration.



If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.


Emergency towing

If a tow truck is not available in an emergency, your vehicle may be temporarily towed using a cable or chain secured to the emergency towing eyelet. This should only be attempted on hard surfaced roads for 50 miles (80 km) at low speeds.


A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.

Emergency towing procedure


STEP 1 Take out the towing eyelet. (\rightarrow P. 288)



Remove the eyelet cover by pushing outside of it.



Insert the towing eyelet into the hole and tighten partially by hand.



Tighten down the towing eyelet securely using a wheel nut wrench or hard metal bar.

STEP 5 Securely attach a cable or chain to the towing eyelet.

Take care not to damage the vehicle body.

STEP 6 Enter the vehicle being towed and start the engine.

If the engine does not start, turn the engine switch to the "ON" position.

STEP 7 Shift the shift lever to N and release the parking brake. When the shift lever cannot be shifted. (\rightarrow P. 307)

While towing

If the engine is not running, the power assist for the brakes and steering will not function, making steering and braking more difficult.


Wheel nut wrench

Wheel nut wrench can be purchased at your Scion dealer.

CAUTION

Observe the following precautions. Failure to do so may result in death or serious injury.

When towing the vehicle



Be sure to transport the vehicle with the front wheels raised or with all four wheels raised off the ground.

If the vehicle is towed with the front wheels contacting the ground, the drivetrain and related parts may be damaged.

While towing

When towing using a rope, avoid sudden starts, etc., which place excessive stress on the towing hook and rope.

The towing hook or rope may become damaged, broken debris may hit people and cause serious damage.

Do not turn the engine switch to the "LOCK" position.

There is a possibility that the steering wheel is locked and cannot be operated.

Installing towing eyelet to the vehicle

Make sure that towing eyelet is installed securely. If not securely installed, towing eyelet may come loose during towing.

To prevent damage to the vehicle when towing using a wheel-lift type truck

When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.

To prevent body damage when towing with a sling-type truck

Do not tow with a sling-type truck, either from the front or rear.

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Scion dealer as soon as possible.

Visible symptoms

- Fluid leaks under the vehicle (Water dripping from the air conditioning system after use is normal.)
- Flat-looking tires or uneven tire wear
- High engine coolant temperature warning light flashes or comes on
- Low engine coolant temperature indicator comes on or does not come on continuously

Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

Operational symptoms

- Engine missing, stumbling or running rough
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

5-1. Essential information Fuel pump shut off system

To minimize the risk of fuel leakage when the engine stalls or an airbag inflates upon collision, the fuel pump shut off system stops supplying fuel to the engine.

Follow the procedure below to restart the engine after the system is activated.

STEP 1 Turn the engine switch to the ACC or LOCK position.

STEP 2 Restart the engine.

Before starting the engine

Inspect the ground under the vehicle.

If you find that fuel has leaked onto the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

5-2. Steps to take in an emergency If a warning light turns on or a warning buzzer sounds...

Calmly perform the following actions if any of the warning lights turn on or flash. If a light turns on or flashes, but then turns off, this does not necessarily indicate a malfunction in the system.

Stop the vehicle immediately. Continuing to drive the vehicle may be dangerous.

The following warning indicates a possible problem in the brake system. Immediately stop the vehicle in a safe place and contact your Scion dealer.

Warning light	Warning light/Details	
BRAKE (except Canada)	 Brake system warning light (warning buzzer)* Low brake fluid Malfunction in the brake system This light also comes on when the parking brake is not released. If the light turns off after the parking brake is fully released, the system is operating nor- 	
(Canada)	mally.	

*: Parking brake engaged warning buzzer:

The buzzer sounds to indicate that parking brake is still engaged (with the vehicle having reached a speed of approximately 3 mph [5 km/h])

Stop the vehicle immediately.

The following warnings indicate the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact your Scion dealer.

Warning light	Warning light/Details	
	Charging system warning light Indicates a malfunction in the vehicle's charging sys- tem.	
۹ <u>۳</u> ۰،	Low engine oil pressure warning light Indicates that the engine oil pressure is too low.	
(Flashes or comes on)	High engine coolant temperature warning light Indicates the engine is almost overheating. $(\rightarrow P. 312)$	

Have the vehicle inspected immediately.

Failing to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by your Scion dealer immediately.

Warning light	Warning light/Details	
(except Canada) (Canada)	 Malfunction indicator lamp Indicates a malfunction in: The electronic engine control system; The electronic throttle control system; The electronic automatic transmission control system; or The emission control system. 	
*	 SRS warning light Indicates a malfunction in: The SRS airbag system; The front passenger occupant classification system; or The seat belt pretensioner system. 	
ABS (except Canada) (Canada)	ABS warning light Indicates a malfunction in: • The ABS; or • The brake assist system.	
. !	Electric power steering system warning light Indicates a malfunction in the EPS (Electric Power Steering) system.	
	 Slip indicator The indicator comes on to indicates a malfunction in: The VSC system; or The TRAC system. 	

Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Warning light	Warning light/Details	Correction procedure
	Open door warning light Indicates that a door is not fully closed.	Check that all doors are closed.
(Flashes)	Low fuel level warning light ^{*1} Indicates that remaining fuel is about 1.6 gal. (5.9 L, 1.3 Imp.gal.) or less.	Refuel the vehicle.
(On the instrument cluster)	Driver's seat belt reminder light (warning buzzer)* ² Warns the driver to fasten his/her seat belt.	Fasten the seat belt.
(On the center panel)	Front passenger's seat belt reminder light (warning buzzer)* ³ Warns the front passen- ger to fasten his/her seat belt.	Fasten the seat belt.

Warning light	Warning light/Details	Correction procedure
	Tire pressure warning light	
(!)	 When the light comes on: Low tire inflation pressure such as Natural causes (→P. 284) Flat tire (→P. 288) 	Adjust the tire inflation pressure to the specified level. The light will turn off after a few minutes. In case the light does not turn off even if the tire inflation pressure is adjusted, have the system checked by your Scion dealer.
	When the light comes on after blinking for 1 minute: Malfunction in the tire pressure warning system. $(\rightarrow P. 285)$	Have the system checked by your Scion dealer.
	Low washer fluid warn- ing light Low level of washer fluid	Fill the tank.

Warning light	Warning light/Details	Correction procedure
	Maintenance required reminder light Indicates that mainte- nance is required accord- ing to the driven distance on the maintenance schedule.*4	
MAINT REQD (except Canada)	Illuminates for about 3 seconds and then flashes for about 15 seconds approximately 4500 miles (7200 km) after the remainder light has been reset.	If necessary, perform maintenance.
	Comes on and remains on if the distance driven exceeds 5000 miles (8000 km) after the main- tenance data has been reset. (The indicator will not work properly unless the remainder light has been reset.)	Perform the necessary maintenance. Please reset the remain- der light after the mainte- nance is performed. $(\rightarrow P. 190)$

- ^{*1}: When filled with less than 2.6 gal. (10 L, 2.2 Imp.gal.) per refueling, the fuel gauge may not display accurately.
- *2: Driver's seat belt reminder:

The driver's seat belt reminder sounds to alert the driver that his or her seat belt is not fastened. Once the engine switch is turned to the ON or START position, the buzzer sounds for 6 seconds. If the vehicle has reached a speed of at least 12 mph (20 km/h), the buzzer sounds intermittently for approximately 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for approximately 20 more seconds.

*³: Front passenger's seat belt reminder:

The front passenger's seat belt reminder sounds to alert the front passenger that his or her seat belt is not fastened. The buzzer sounds intermittently for approximately 10 seconds after the vehicle has reached a speed of at least 12 mph (20 km/h). Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for approximately 20 more seconds.

*4: Refer to the separate "Scheduled Maintenance Guide" or "Owner's Manual Supplement" for the maintenance interval applicable to your vehicle.

SRS warning light

This warning light system monitors the airbag sensor assembly, front airbag sensors, side and curtain shield airbag sensors, curtain shield airbag sensors, rear airbag sensors, driver's seat position sensor, driver's seat belt buckle switch, front passenger occupant classification system (ECU and sensors), AIR BAG ON indicator light, AIR BAG OFF indicator light, front passenger's seat belt buckle switch, seat belt pretensioner assemblies, airbags, interconnecting wiring and power sources. (\rightarrow P. 69)

Key reminder buzzer

The buzzer indicates that the key has not been removed with the engine switch in the ACC or LOCK position and the driver's door opened.

Electric power steering system warning light

When the battery charge becomes insufficient or the voltage temporarily drops, the electric power steering system warning light may comes on.

If the malfunction indicator lamp comes on while driving

First check the following:

- Is the fuel tank empty?
 If it is, fill the fuel tank immediately.
- Is the fuel tank cap loose?
 - If it is, tighten it securely.

The malfunction indicator lamp will go off after taking several driving trips. If the malfunction indicator lamp does not go off even after several trips, contact your Scion dealer as soon as possible.

Front passenger detection sensor and passenger seat belt reminder

If luggage or other load is placed on the front passenger seat, depending on its weight, the reminder light to flash and buzzer to sound.

When the tire pressure warning light comes on

Check the tire inflation pressure and adjust to the appropriate level. Pushing the tire pressure warning reset switch does not turn off the tire pressure warning light.

The tire pressure warning light may turn on due to natural causes

The tire pressure warning light may turn on due to natural causes such as natural air leaks or tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

If the tire pressure warning system is inoperative

The tire pressure warning system will be disabled in the following conditions:

(When the condition becomes normal, the system will work properly.)

- If tires not equipped with tire pressure warning valves and transmitters are used.
- If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
- If the tire inflation pressure is 73 psi (500 kPa, 5.1 kgf/cm² or bar) or higher.

The tire pressure warning system may be disabled in the following conditions:

(When the condition becomes normal, the system will work properly.)

- If electronic devices or facilities using similar radio wave frequencies are nearby.
- If a radio set at similar frequencies is in use in the vehicle.
- If a window tint that affects the radio wave signals is installed.
- If there is a lot of snow or ice on the vehicle, in particular around the wheels or wheel housings.

- If non-genuine Scion wheels are used. (Even if you use Scion wheels, the tire pressure warning system may not work properly with some types of tires.)
- If tire chains are used.
- If emergency tire puncture repair kit is used.

If the tire pressure warning light frequently comes on after blinking for 1 minute

If the tire pressure warning light frequently comes on after blinking for 1 minute when the engine switch is turned to the ON position, have it checked by your Scion dealer.

Customization that can be configured at Scion dealer

The vehicle speed linked seat belt reminder buzzer can be disabled. (Customizable features \rightarrow P. 343)

CAUTION

When the electric power steering system warning light comes on

The steering wheel may become extremely heavy.

If the steering wheel becomes heavier than usual when operating, hold firmly and operate using more force than usual.

If the tire pressure warning light comes on

Be sure to observe the following precautions. Failure to do so could cause loss of vehicle control and result in death or serious injury.

 Stop your vehicle in a safe place as soon as possible. Adjust the tire inflation pressure immediately.

If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires.
 If the tire is flat, temporary repair it with liquid sealants and have the flat tire repaired or replaced by the nearest Scion dealer as soon as possible.

Avoid abrupt maneuvering and braking. If the vehicle tires deteriorate, you could lose control of the steering wheel or the brakes.

If a blowout or sudden air leakage should occur

The tire pressure warning system may not activate immediately.

CAUTION

Maintenance of the tire

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (tire and load information label). (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label [tire and load information label], you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS-tire pressure warning system) that illuminates a low tire pressure telltale (tire pressure warning light) when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale (tire pressure warning light) illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS (tire pressure warning system) is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale (tire pressure warning light).

Your vehicle has also been equipped with a TPMS (tire pressure warning system) malfunction indicator to indicate when the system is not operating properly. The TPMS (tire pressure warning system) malfunction indicator is combined with the low tire pressure telltale (tire pressure warning light). When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

CAUTION

TPMS (tire pressure warning system) malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS (tire pressure warning system) from functioning properly. Always check the TPMS (tire pressure warning system) malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS (tire pressure warning system) to continue to function properly.

To ensure the tire pressure warning system operates properly

Do not install tires with different specifications or makers, as the tire pressure warning system may not operate properly.


5-2. Steps to take in an emergency If you have a flat tire


A puncture caused by a nail or screw passing through the tire tread can be repaired temporarily using the emergency tire puncture repair kit. (The kit contains a bottle of sealant. The sealant can be used only once to temporarily repair one tire without removing the nail or screw from the tire.) After temporarily repairing the tire with the kit, have the tire repaired or replaced by your Scion dealer.

Before repairing the tire


- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P.
- Stop the engine.
- Turn on the emergency flashers.

Location of the emergency tire puncture repair kit






Emergency tire puncture repair kit components Bottle



Taking out the emergency tire puncture repair kit

STEP 1 Fold down the rear seat seatbacks. (\rightarrow P. 40)



1 Turn the knobs and remove them.


2 Remove the luggage box.

STEP 3 Emergency tire puncture repair kit

Take out the emergency tire puncture repair kit.

Before performing emergency repair

Check the degree of the tire damage.




A tire should only be repaired with the emergency tire puncture repair kit if the damage is caused by a nail or screw passing through the tire tread.


- Do not remove the nail or screw from the tire. Removing the object may widen the opening and prevent emergency repair with the repair kit.
- To avoid sealant leakage, move the vehicle until the area of the puncture, if known, is positioned at the top of the tire.
- In the following cases, the tire cannot be repaired with the emergency tire puncture repair kit. Contact your Scion dealer.
 - When the tire is damaged due to driving without sufficient air pressure
 - When there are any cracks or damage at any location on the tire, such as on the side wall, except the tread
 - When the tire is visibly separated from the wheel
 - When the cut or damage to the tread is 0.16 in. (4 mm) long or more
 - When the wheel is damaged
 - When two or more tires have been punctured
 - When more than 2 sharp objects such as nails or screws have passed through the tread on a single tire
 - When the sealant has expired

Emergency repair method

STEP 1 Take out the repair kit from the plastic bag.



Remove the valve cap from the valve of the punctured tire.





Remove the air release cap from the hose.

You will use the air release cap again. Therefore keep it in a safe place.


Connect the hose to the valve.

Screw the end of the hose clockwise as far as possible.







Make sure that the compressor switch is off.



Remove the rubber stopper from the compressor.



Connect the power plug to the power outlet socket. (\rightarrow P. 177)




Connect the bottle to the compressor.

Make sure that the bottle is securely connected.


Attach the 2 stickers as shown.

Remove any dirt and moisture from the wheel before attaching the label.




STEP10 Check the specified tire inflation pressure.


Tire inflation pressure is specified on the label on the driver's side pillar as shown. (\rightarrow P. 327)



STEP11 Start the vehicle's engine.



To inject the sealant and inflate the tire, turn the compressor switch on.



Inflate the tire until the specified air pressure is reached.

- The sealant will be injected and the pressure will spike to 44 psi (300 kPa, 3.1 kgf/cm² or bar) or 58 psi (400 kPa, 4.1 kgf/cm² or bar), and then gradually decrease.
- The air pressure gauge will display the actual tire inflation pressure about 1 minute (15 minutes at low temperature) after the switch is turned on.


3 Inject to specified air pressure.

- Turn the compressor switch off and then check the tire inflation pressure. Being careful not to over inflate, check and repeat the inflation procedure until the specified tire inflation pressure is reached.
- If the tire inflation pressure is still lower than the specified point after inflation for 10 minutes (40 minutes at low temperature) with the switch on, the tire is too damaged to be repaired. Turn the compressor switch off and contact your Scion dealer.
- If the tire inflation pressure exceeds the specified air pressure, let out some air to adjust the tire inflation pressure. (→P. 301, 327)

STEP14 With the compressor switch off, disconnect the hose from the valve on the tire and then pull out the power plug from the power outlet socket.

Some sealant may leak when the hose is removed.

STEP 15 Install the valve cap onto the valve of the emergency repaired tire.




Attach the air release cap to the end of the hose.


If the air release cap is not attached, the sealant may leak and the vehicle may get dirty.

STEP17 Temporarily store the bottle in the luggage room while it is connected to the compressor.

STEP18 To spread the liquid sealant evenly within the tire, immediately drive safely for about 3 miles (5 km) below 50 mph (80 km/h).




After driving for about 3 miles (5 km), stop your vehicle in a safe place on a hard, flat surface and remove the air release cap from the hose before reconnecting the repair kit.



Turn the compressor switch on and wait for several seconds, and then turn it off. Check the tire inflation pressure.

- If the tire inflation pressure is under 19 psi (130 kPa, 1.3 kgf/cm² or bar): The puncture cannot be repaired. Contact your Scion dealer.
- If the tire inflation pressure is 19 psi (130 kPa, 1.3 kgf/cm² or bar) or higher, but less than the specified air pressure: Proceed to STEP 21.
- **3** If the tire inflation pressure is the specified air pressure: Proceed to STEP 22.

STEP 21 Turn the compressor switch on to inflate the tire until the specified air pressure is reached. Drive for about 3 miles (5 km) and then perform STEP 19.



Attach the air release cap to the end of the hose.

If the air release cap is not attached, the sealant may leak and the vehicle may get dirty.


- STEP 23 Store the bottle in the luggage room while it is connected to the compressor.
- STEP 24 Taking precautions to avoid sudden braking, sudden acceleration and sharp turns, drive carefully at under 50 mph (80 km/h) to the nearest Scion dealer.

Emergency tire puncture repair kit

- The sealant stored in the emergency tire puncture repair kit can be used only once to temporarily repair a single tire. If the sealant has been used and needs to be replaced, contact your Scion dealer.
- The sealant can be used when the outside temperature is from -40°F (-40°C) to 140°F (60°C).
- The repair kit is exclusively designed for size and type of tires originally installed on your vehicle. Do not use it for tires that a different size than the original ones, or for any other purposes.
- The sealant has a limited lifespan. The expiration date is shown on the bottle. The sealant should be replaced before the expiration date. Contact your Scion dealer.
- If the sealant gets on your clothes, it may stain.
- If the sealant adheres to a wheel or the surface of the vehicle body, the stain may not be removable if it is not cleaned at once. Immediately wipe away the sealant with a wet cloth.
- During operation of the repair kit, a loud operation noise is produced. This does not indicate a malfunction.
- Do not use to check or to adjust the tire pressure.

If the tire is inflated to more than the specified air pressure

STEP 1 Disconnect the hose from the valve.



Install the air release cap to the end of the hose and push the protrusion on the air release cap into the tire valve to let some air out.

- STEP 3 Disconnect the hose from the valve, remove the air release cap from the hose and then reconnect the hose.
- STEP 4 Turn the compressor switch on and wait for several seconds, and then turn it off. Check that the air pressure indicator shows the specified air pressure.

If the air pressure is under the designated pressure, turn the compressor switch on again and repeat the inflation procedure until the specified air pressure is reached.

The valve of a tire that has been repaired

After a tire is repaired with the emergency tire puncture repair kit, the tire pressure warning valve and transmitter should be replaced.

Note for checking the emergency tire puncture repair kit

Check the sealant expiration date occasionally. The expiry date is shown on the bottle.

CAUTION

Do not drive the vehicle with a flat tire

Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair.

Driving with a flat tire may cause a circumferential groove on the side wall. In such a case, the tire may explode when using a repair kit.

Caution while driving

 Store the repair kit in the luggage room.
 Otherwise, the repair kit may fly out and break in events such as sudden braking, and may cause an accident.

- The repair kit is exclusively only for your vehicle.
 Do not use repair kit on other vehicles, which could lead to an accident causing death or serious injury.
- Do not use repair kit for tires that are different size than the original ones, or for any other purpose. If the tires have not been completely repaired, it could lead to an accident causing death or serious injury.

Precautions for use of the sealant

- Ingesting the sealant is hazardous to your health. If you ingest sealant, consume as much water as possible, and then immediately consult a doctor.
- If sealant gets in eyes or adheres to skin, immediately wash it off with water. If discomfort persists, consult a doctor.

When fixing the flat tire

- Stop your vehicle in a safe and flat area.
- Do not touch the wheels or the area around the brakes immediately after the vehicle has been driven.

After the vehicle has been driven, the wheels and the area around the brakes may be extremely hot. Touching these areas with hands, feet or other body parts may result in burns.

 Connect the valve and hose securely with the tire installed on the vehicle. If the hose is not properly connected to the valve, air leakage may occur as sealant may be sprayed out.

CAUTION

When fixing the flat tire

- If the hose comes off the valve while inflating the tire, there is a risk that the hose will move abruptly due to air pressure.
- After inflation of the tire has completed, the sealant may splatter when the hose is disconnected or some air is let out of the tire.
- Follow the operation procedure to repair the tire. If the procedures not followed, the sealant may spray out.
- Keep back from the tire while it is being repaired, as there is a chance of it bursting while the repair operation is being performed. If you notice any cracks or deformation of the tire, turn off the compressor switch and stop the repair operation immediately.
- The repair kit may overheat if operated for a long period of time. Do not operate the repair kit continuously for more than 60 minutes.
- Parts of the repair kit become hot during operation. Be careful handling the repair kit during and after operation. Do not touch the metal part connecting the bottle and the compressor. It will be extremely hot.
- Do not attach the vehicle speed warning sticker to an area other than the one indicated. If the sticker is attached to an area where an SRS airbag is located, such as the pad of the steering wheel, it may prevent the SRS airbag from operating properly.

Driving to spread the liquid sealant evenly

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in a loss of vehicle control and cause death or serious injury.

- Drive the vehicle carefully at a low speed. Be especially careful when turning and cornering.
- If the vehicle does not drive straight or you feel a pull through the steering wheel, stop the vehicle and check the following.
 - Tire condition. The tire may have separated from the wheel.
 - Tire inflation pressure. If the tire inflation pressure is 19 psi (130 kPa, 1.3 kgf/cm² or bar) or less, the tire may be severely damaged.

When performing an emergency repair

 A tire should only be repaired with the emergency tire puncture repair kit if the damage is caused by a sharp object such as nail or screw passing through the tire tread.

Do not remove the sharp object from the tire. Removing the object may widen the opening and disenable emergency repair with the repair kit.

- The repair kit is not waterproof. Make sure that the repair kit is not exposed to water, such as when it is being used in the rain.
- Do not put the repair kit directly onto dusty ground such as sand at the side of the road. If the repair kit vacuums up dust etc., a malfunction may occur.

Precautions for the emergency tire puncture repair kit

- The repair kit power source should be 12 V DC suitable for vehicle use. Do not connect the repair kit to any other source.
- If gasoline splatters on the repair kit, the repair kit may deteriorate. Take care not to allow gasoline to contact it.
- Place the repair kit in a storage to prevent it from being exposed to dirt or water.
- Store the repair kit in the luggage room out of reach of children.
- Do not disassemble or modify the repair kit. Do not subject parts such as the air pressure indicator to impacts. This may cause a malfunction.

To avoid damage to the tire pressure warning valves and transmitters

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Scion dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire. (\rightarrow P. 223)

If the engine still does not start after following the correct starting procedure (\rightarrow P. 113) or releasing the steering lock (\rightarrow P. 114), confirm the following points.


The engine will not start even when the starter motor operates normally.

One of the following may be the cause of the problem.

- There may not be sufficient fuel in the vehicle's tank. Refuel the vehicle.
- The engine may be flooded. Try to restart the engine once more following correct starting procedures. (→P. 113)
- Vehicles with engine immobilizer system: There may be a malfunction in the engine immobilizer system. (→P. 62)
- The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem.

- The battery may be discharged. (\rightarrow P. 309)
- The battery terminal connections may be loose or corroded.



One of the following may be the cause of the problem.

• One or both of the battery terminals may be disconnected.

• The battery may be discharged. (\rightarrow P. 309)

Contact your Scion dealer if the problem cannot be repaired, or if repair procedures are unknown.


If the shift lever cannot be shifted with your foot on the brake, there may be a problem with the shift lock system (a system to prevent accidental operation of the shift lever). Have the vehicle inspected by your Scion dealer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted.


STEP 1 Set the parking brake.

STEP 2 Turn the engine switch to the ACC position.

STEP 3 Depress the brake pedal.



Pry the cover up with a flathead screwdriver or equivalent.



Press the shift lock override button.

The shift lever can be shifted while the button is pressed.


5-2. Steps to take in an emergency If you lose your keys

New genuine keys can be made by your Scion dealer using the key number stamped on your key number plate. Vehicles with engine immobilizer system, the dealer will also need the master key. (\rightarrow P. 25)

The following procedures may be used to start the engine if the vehicle's battery is discharged.

You can call your Scion dealer or qualified repair shop.

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your Scion following the steps below.



Connect the jumper cables.

- 1 Positive (+) battery terminal on your vehicle
- 2 Positive (+) battery terminal on the second vehicle

3 Negative (-) battery terminal on the second vehicle

- Connect the jumper cable to ground on your vehicle as shown in the illustration.
- STEP 2 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- STEP 3 Maintain the engine speed of the second vehicle and start the engine of your vehicle.

STEP 4 Once the vehicle's engine has started, remove the jumper cables in the exact reverse order in which they were connected.

Once the engine starts, have the vehicle checked at your Scion dealer as soon as possible.

Starting the engine when the battery is discharged

The engine cannot be started by push-starting.

Avoiding a discharged battery

- Turn off the headlights and the audio system while the engine is turned off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic, etc.

Charging the battery

The electricity stored in the battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the battery may discharge, and the engine may be unable to start. (The battery recharges automatically during driving.)

CAUTION

Avoiding battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the battery.

- Make sure the jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any part other than the intended terminal.
- Do not allow the jumper cables to come into contact with the "+" and "-" terminals.
- Do not smoke, use matches, cigarette lighters or allow open flame near the battery.

A CAUTION

Battery precautions

The battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the battery.

- When working with the battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention. Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the battery.

NOTICE

When handling jumper cables

Be careful that the jumper cables do not become tangled in the cooling fan or any of the belts when connecting or disconnecting them.

5-2. Steps to take in an emergency If your vehicle overheats

The following may indicate that your vehicle is overheating.


- The high engine coolant temperature warning light (→P. 278) comes on or flashes, or a loss of engine power is experienced. (For example, the vehicle speed does not increase.)
- Steam comes out from under the hood.


Correction procedures

- STEP 1 Stop the vehicle in a safe place and turn off the air conditioning system, and then stop the engine.
- STEP 2 If you see steam:

Carefully lift the hood after the steam subsides.

If you do not see steam: Carefully lift the hood.





After the engine has cooled down sufficiently, inspect the hoses and radiator core (radiator) for any leaks.

Radiator

2 Cooling fan

If a large amount of coolant leaks, immediately contact your Scion dealer.


The coolant level is satisfactory if it is between the FULL and LOW lines on the reservoir.

Reservoir

2 FULL

3 LOW

4 Radiator cap



Add coolant if necessary.

Water can be used in an emergency if coolant is unavailable.

STEP 6 Start the engine and turn the air conditioning system on to check that the radiator cooling fan operates and to check for coolant leaks from the radiator or hoses.

> The fan operates when the air conditioning system is turned on immediately after a cold start. Confirm that the fan is operating by checking the fan sound and air flow. If it is difficult to check these, turn the air conditioning system on and off repeatedly. (The fan may not operate in freezing temperatures.)

STEP 7 If the fan is not operating:

Stop the engine immediately and contact your Scion dealer.

If the fan is operating:

Have the vehicle inspected at the nearest Scion dealer.

CAUTION

To prevent an accident or injury when inspecting under the hood of your vehicle

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot, causing serious injuries such as burns.
- Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fan and belts. Failure to do so may cause the hands or clothing to be caught, resulting in serious injury.
- Do not loosen the radiator cap and the coolant reservoir cap while the engine and radiator are hot.

Serious injury, such as burns, may result from hot coolant and steam released under pressure.

When adding engine coolant

Wait until the engine has cooled down before adding engine coolant. When adding coolant, do so slowly. Adding cool coolant to a hot engine too quickly can cause damage to the engine.

To prevent damage to the cooling system

Observe the following precautions:


- Avoid contaminating the coolant with foreign matter (such as sand or dust etc.).
- Do not use any coolant additive.

Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt, or snow.

- STEP 1 Stop the engine. Set the parking brake and put the shift lever in P.
- STEP 2 Remove the mud, snow, or sand from around the stuck tire.
- STEP 3 Place wood, stones or some other material to help provide traction under the tires.
- STEP 4 Restart the engine.
- STEP 5 Shift the shift lever to D or R and carefully apply the accelerator to free the vehicle.

Turn off the TRAC and/or VSC systems if it is difficult to get out because of TRAC and/or VSC operation. (\rightarrow P. 142)

Emergency hook



When your vehicle becomes stuck and cannot move, the emergency hook is used for another vehicle to pull your vehicle out in an emergency.

Your vehicle is not designed to tow another vehicle.

CAUTION

When attempting to free a stuck vehicle

If you choose to rock the vehicle back and forth to free it, make sure the surrounding area is clear, to avoid striking other vehicles, objects or persons. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

NOTICE

To avoid damaging the transmission and other components


- Avoid spinning the wheels and do not rev the engine.
- If the vehicle remains stuck after trying these procedures, the vehicle may require towing to be freed.

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

STEP 1 Steadily step on the brake pedal with both feet and firmly depress it.

Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.

- STEP 2 Shift the shift lever to N.
- ▶ If the shift lever is shifted to N
- STEP 3 After slowing down, stop the vehicle in a safe place by the road.
- STEP 4 Stop the engine.
- ▶ If the shift lever cannot be shifted to N
- STEP 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.



Stop the engine by turning the engine switch to the ACC position.

When trouble arises

STEP 5 Stop the vehicle in a safe place by the road.

CAUTION

If the engine has to be turned off while driving

Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the engine.

• Never attempt to remove the key, as doing so will lock the steering wheel.

6

6-1. Specifications

Maintenance data

(fuel, oil level, etc.)	320
Fuel information	329
Tire information	332

6-2. Customization

Customizable features	343
Items to initialize	345

6-1. Specifications Maintenance data (fuel, oil level, etc.)

Dimensions and weight


Overall length		120.0 in. (3050 mm)
Overall width		66.1 in. (1680 mm)
Overall height*		59.0 in. (1500 mm)
Wheelbase		78.7 in. (2000 mm)
Tread	Front	58.3 in. (1480 mm)
neau	Rear	57.5 in. (1460 mm)
Vehicle capacity weight (Occupants + luggage)		660 lb. (295 kg)

*: Unladen vehicles

Vehicle identification


Vehicle identification number


The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Scion. It is used in registering the ownership of your vehicle.



This number is stamped on the top left of the instrument panel.

This number is stamped under the front passenger seat.






This number is also on the Certification Label.

Engine number

The engine number is stamped on the engine block as shown.



Engine

Model	1NR-FE	
Туре	4-cylinder in line, 4-cycle, gasoline	
Bore and stroke	2.85 × 3.17 in. (72.5 × 80.5 mm)	
Displacement	81.1 cu.in. (1329 cm ³)	
Valve clearance (engine cold)	Automatic adjustment	
Drive belt tension	67 — 89 lbf (300 — 398 N, 31 — 41 kgf)* Generator Water pump Crankshaft Air conditioning compressor *: Drive belt tension measured with Boroughs drive belt tension gauge No. BT-33-73F when the engine is cold (used belt)	

Fuel			

Fuel type	Unleaded gasoline only
Octane rating	87 (Research Octane Number 91) or higher
Fuel tank capacity (Reference)	8.5 gal. (32.0 L, 7.0 Imp.gal.)

Lubrication system

Oil capacity (Drain and refill -reference [*])	
With filter	3.7 qt. (3.5 L, 3.1 Imp.qt.)
Without filter	3.5 qt. (3.3 L, 2.9 Imp.qt.)


*: The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.

Engine oil selection

"Toyota Genuine Motor Oil" is used in your Scion vehicle. Use Scion approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: ILSAC GF-5 multigrade engine oil

Recommended viscosity: SAE 0W-20




SAE 0W-20 is the best choice for good fuel economy and good starting in cold weather.

If SAE 0W-20 is not available, SAE 5W-20 oil may be used. However, it must be replaced with SAE 0W-20 at the next oil change. Oil viscosity (0W-20 is explained here as an example):

- The 0W in 0W-20 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 20 in 0W-20 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

How to read oil container label:

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is added to some oil containers to help you select the oil you should use.



Cooling system

Capacity (Reference)	5.2 qt. (4.9 L, 4.3 Imp.qt.)
Coolant type	 Use either of the following. "Toyota Super Long Life Coolant" Similar high-quality ethylene glycol-based non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology Do not use plain water alone.

Ignition system

Spark plug Make	DENSO SC16HR11
Mare	
Gap	0.043 in. (1.1 mm)

Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust gap when tuning engine.

Electrical system

Battery	
Open voltage [*] at 68°F (20°C):	12.6 — 12.8 V Fully charged 12.2 — 12.4 V Half charged 11.8 — 12.0 V Discharged (*: Voltage checked 20 minutes after the engine and all the lights are turned off)
Charging rates	5 A max.

Automatic transmission

Fluid capacity*	6.5 qt. (6.2 L, 5.4 Imp.qt.)
Fluid type	TOYOTA Genuine CVT Fluid FE

*: The fluid capacity is the quantity of reference. If replacement is necessary, contact your Scion dealer.

🔨 NOTICE

Automatic transmission fluid type

Using transmission fluid other than "TOYOTA Genuine CVT Fluid FE" may cause deterioration in shift quality, locking up of your transmission accompanied by vibration, and ultimately damage the transmission of your vehicle.

Brakes

Pedal clearance ^{*1}	3.58 in. (91 mm) Min.
Pedal free play	0.04 — 0.24 in. (1 — 6 mm)
Brake pad wear limit	0.04 in. (1.0 mm)
Brake lining wear limit	0.04 in. (1.0 mm)
Parking brake lever travel*2	6 — 9 clicks
Fluid type	FMVSS No. 116 DOT 3 or SAE J1703

*1: Minimum pedal clearance when depressed with a force of 66 lbf (300 N, 30 kgf) while the engine running

*2: Parking brake lever travel when pulled up with a force of 44 lbf (200 N, 20 kgf)

Steering

Free play

Less than 1.2 in. (30 mm)

Tires and wheels

Tire size	175/60R16 82H
Tire inflation pressure (Recommended cold tire inflation pressure)	Driving under normal conditions Front tires: 33 psi (230 kPa, 2.3 kgf/cm ² or bar) Rear tires: 32 psi (220 kPa, 2.2 kgf/cm ² or bar)
Wheel size	16 × 5 J
Wheel nut torque	76 ft·lbf (103 N⋅m, 10.5 kgf⋅m)

CAUTION

When replacing tires and wheels

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to the peripheral parts of the tires, as well as dangerous handling characteristics, which may lead to fatal or injury accidents.

Do not use tire sizes or wheel sizes other than those recommended by Scion.

6

Light bulbs

	Light Bulbs	Bulb No	W	Туре
	Headlights High beam Low beam	9005 —	60 55	A B
	Parking/front side marker lights		5	С
	Front turn signal lights		21	С
Exterior	Side turn signal lights		5	С
	Rear turn signal lights	7440A	21	С
	Stop/tail and rear side marker lights	7443	21/5	D
	Back-up lights		16	D
	License plate light	_	5	D

- A: HB3 halogen bulbs
- B: H11 halogen bulbs
- C: Wedge base bulbs (amber)
- D: Wedge base bulbs

6-1. Specifications Fuel information

You must only use unleaded gasoline in your vehicle.

Select octane rating 87 (Research Octane Number 91) or higher. Use of unleaded gasoline with an octane rating lower than 87 may result in engine knocking. Persistent knocking can lead to engine damage.

At minimum, the gasoline you use should meet the specifications of ASTM D4814 in the U.S.A.

Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your Scion has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

Gasoline quality

In very few cases, driveability problems may be caused by the brand of gasoline you are using. If driveability problems persist, try changing the brand of gasoline. If this does not correct the problem, consult your Scion dealer.

Gasoline quality standards

- Automotive manufacturers in the U.S.A., Europe and Japan have developed a specification for fuel quality called World-Wide Fuel Charter (WWFC), which is expected to be applied worldwide.
- The WWFC consists of four categories that are based on required emission levels. In the U.S., category 4 has been adopted.
- The WWFC improves air quality by lowering emissions in vehicle fleets, and improves customer satisfaction through better performance.

Recommendation of the use of gasoline containing detergent additives


- Scion recommends the use of gasoline that contains detergent additives to avoid build-up of engine deposits.
- All gasoline sold in the U.S.A. contains minimum detergent additives to clean and/or keep clean intake systems, per EPA's lowest additives concentration program.
- Scion strongly recommends the use of Top Tier Detergent Gasoline. For more information on Top Tier Detergent Gasoline and a list of marketers, please go to the official website www.toptiergas.com.

Recommendation of the use of cleaner burning gasoline

Cleaner burning gasoline, including reformulated gasoline that contains oxygenates such as ethanol or MTBE (Methyl Tertiary Butyl Ether) is available in many areas.

Scion recommends the use of cleaner burning gasoline and appropriately blended reformulated gasoline. These types of gasoline provide excellent vehicle performance, reduce vehicle emissions and improve air quality.

Non-recommendation of the use of blended gasoline



• Use only gasoline containing up to 15% ethanol.

DO NOT use any flex-fuel or gasoline that could contain more than 15% ethanol, including from any pump labeled E30, E50, E85 (which are only some examples of fuel containing more than 15% ethanol).

- If you use gasohol in your vehicle, be sure that it has an octane rating no lower than 87.
- Scion does not recommend the use of gasoline containing methanol.

Non-recommendation of the use of gasoline containing MMT

Some gasoline contains an octane enhancing additive called MMT (Methylcyclopentadienyl Manganese Tricarbonyl).

Scion does not recommend the use of gasoline that contains MMT. If fuel containing MMT is used, your emission control system may be adversely affected.

The malfunction indicator lamp on the instrument cluster may come on. If this happens, contact your Scion dealer for service.

If your engine knocks

- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.
- Consult your Scion dealer.

NOTICE

Notice on fuel quality

- Do not use improper fuels. If improper fuels are used the engine will be damaged.
- Do not use leaded gasoline.

Leaded gasoline can cause damage to your vehicle's three-way catalytic converters causing the emission control system to malfunction.

Do not use gasohol other than the type previously stated.
 Other gasohol may cause fuel system damage or vehicle performance problems.

 Using unleaded gasoline with an octane number or rating lower than the level previously stated will cause persistent heavy knocking. At worst, this will lead to engine damage.

Fuel-related poor driveability


If poor driveability is encountered after using a different type of fuel (poor hot starting, vaporization, engine knocking, etc.), discontinue the use of that type of fuel.

When refueling with gasohol

Take care not to spill gasohol. Otherwise, it can damage your vehicle's paint.

6-1. Specifications Tire information

Typical tire symbols



4 Tire ply composition and materials

Plies are layers of rubber-coated parallel cords. Cords are the strands which form the plies in a tire.

5 Uniform tire quality grading

For details, see "Uniform Tire Quality Grading" that follows.

- 6 Load limit at maximum cold tire inflation pressure (→P. 337)
- 7 Maximum cold tire inflation pressure

(→P. 337)

This means the pressure to which a tire may be inflated.

B TUBELESS or TUBE TYPE

A tubeless tire does not have a tube and air is directly put into the tire. A tube type tire has a tube inside the tire and the tube maintains the air pressure.

Radial tires or bias-ply tires


A radial tire has RADIAL on the sidewall. A tire not marked RADIAL is a bias-ply tire.

10 Summer tires or all season tires

```
(→P. 225)
```

An all season tire has M+S on the sidewall. A tire not marked M+S is a summer tire.

Typical DOT and Tire Identification Number (TIN)



1 DOT symbol*

- 2 Tire Identification Number (TIN)
- 3 Tire manufacturer's identification mark
- 4 Tire size code
- Manufacturer's optional tire type code (3 or 4 letters)
- 6 Manufacturing week
- 7 Manufacturing year
 - *: The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle Safety Standards.

Tire size

Typical tire size information

The illustration indicates typical tire size.

P <u>175/60R16</u>	82H 6 7
	STY61AJZ05


- Tire use
 (P = Passenger car, T = Temporary use)
- 2 Section width (millimeters)
- Aspect ratio (tire height to section width)
- Tire construction code
 (D = D = dial = D = Diagonal
 - (R = Radial, D = Diagonal)
- 5 Wheel diameter (inches)
- 6 Load index (2 digits or 3 digits)
- Speed symbol (alphabet with one letter)

I I I I I I I STY61AJZ06

Tire dimensions

- 1 Section width
- 2 Tire height
- 3 Wheel diameter

Tire section names



Uniform Tire Quality Grading

This information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S. Department of Transportation.

It provides the purchasers and/or prospective purchasers of Scion vehicles with information on uniform tire quality grading.

Your Scion dealer will help answer any questions you may have as you read this information.

DOT quality grades

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades. Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200 Traction AA Temperature A

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and a half (1 - 1/2) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use. Performance may differ significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B and C, and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete.

A tire marked C may have poor traction performance.

Warning: The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include cornering (turning) traction.

Temperature A, B, C

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.

Grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.

Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning: The temperature grades of a tire assume that it is properly inflated and not overloaded.

Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

Glossary of tire terminology

Tire related term	Meaning
Cold tire inflation pres- sure	Tire pressure when the vehicle has been parked for three hours or more, or has not been driven more than 1 mile or 1.5 km under that condition
Maximum inflation pressure	The maximum cold inflated pressure to which a tire may be inflated, shown on the sidewall of the tire
Recommended infla- tion pressure	Cold tire inflation pressure recommended by a manufacturer
Accessory weight	The combined weight (in excess of those stan- dard items which may be replaced) of trans- mission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory- installed equipment (whether installed or not)
Curb weight	The weight of a motor vehicle with standard equipment, including the maximum capacity of fuel, oil and coolant, and if so equipped, air conditioning and additional weight optional engine
Maximum loaded vehi- cle weight	The sum of: (a) Curb weight (b) Accessory weight (c) Vehicle capacity weight (d) Production options weight
Normal occupant weight	150 lb. (68 kg) times the number of occupants specified in the second column of Table 1* that follows

Tire related term	Meaning
Occupant distribution	Distribution of occupants in a vehicle as speci- fied in the third column of Table 1* below
Production options weight	The combined weight of installed regular pro- duction options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim
Rim	A metal support for a tire or a tire and tube assembly upon which the tire beads are seated
Rim diameter (Wheel diameter)	Nominal diameter of the bead seat
Rim size designation	Rim diameter and width
Rim type designation	The industry manufacturer's designation for a rim by style or code
Rim width	Nominal distance between rim flanges
Vehicle capacity weight (Total load capacity)	The rated cargo and luggage load plus 150 lb. (68 kg) times the vehicle's designated seating capacity
Vehicle maximum load on the tire	The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight, and dividing by two
Vehicle normal load on the tire	The load on an individual tire that is determined by distributing to each axle its share of curb weight, accessory weight, and normal occu- pant weight (distributed in accordance with Table 1 [*] below), and dividing by two
Weather side	The surface area of the rim not covered by the inflated tire

Tire related term	Meaning
Bead	The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim
Bead separation	A breakdown of the bond between components in the bead
Bias ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the cen- terline of the tread
Carcass	The tire structure, except tread and sidewall rubber which, when inflated, bears the load
Chunking	The breaking away of pieces of the tread or sidewall
Cord	The strands forming the plies in the tire
Cord separation	The parting of cords from adjacent rubber compounds
Cracking	Any parting within the tread, sidewall, or inner- liner of the tire extending to cord material
СТ	A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire
Extra load tire	A tire designed to operate at higher loads and at higher inflation pressures than the corre- sponding standard tire
Groove	The space between two adjacent tread ribs
Innerliner	The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire
Innerliner separation	The parting of the innerliner from cord material in the carcass

Tire related term	Meaning
Intended outboard sidewall	 (a)The sidewall that contains a whitewall, bears white lettering, or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or (b)The outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle
Light truck (LT) tire	A tire designated by its manufacturer as prima- rily intended for use on lightweight trucks or multipurpose passenger vehicles
Load rating	The maximum load that a tire is rated to carry for a given inflation pressure
Maximum load rating	The load rating for a tire at the maximum per- missible inflation pressure for that tire
Maximum permissible inflation pressure	The maximum cold inflation pressure to which a tire may be inflated
Measuring rim	The rim on which a tire is fitted for physical dimension requirements
Open splice	Any parting at any junction of tread, sidewall, or innerliner that extends to cord material
Outer diameter	The overall diameter of an inflated new tire
Overall width	The linear distance between the exteriors of the sidewalls of an inflated tire, including eleva- tions due to labeling, decorations, or protective bands or ribs
Passenger car tire	A tire intended for use on passenger cars, mul- tipurpose passenger vehicles, and trucks, that have a gross vehicle weight rating (GVWR) of 10,000 lb. or less
Ply	A layer of rubber-coated parallel cords

Tire related term	Meaning
Ply separation	A parting of rubber compound between adja- cent plies
Pneumatic tire	A mechanical device made of rubber, chemi- cals, fabric and steel or other materials, that, when mounted on an automotive wheel, pro- vides the traction and contains the gas or fluid that sustains the load
Radial ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread
Reinforced tire	A tire designed to operate at higher loads and at higher inflation pressures than the corre- sponding standard tire
Section width	The linear distance between the exteriors of the sidewalls of an inflated tire, excluding ele- vations due to labeling, decoration, or protec- tive bands
Sidewall	That portion of a tire between the tread and bead
Sidewall separation	The parting of the rubber compound from the cord material in the sidewall
Snow tire	A tire that attains a traction index equal to or greater than 110, compared to the ASTM E- 1136 Standard Reference Test Tire, when using the snow traction test as described in ASTM F-1805-00, Standard Test Method for Single Wheel Driving Traction in a Straight Line on Snow-and Ice-Covered Surfaces, and which is marked with an Alpine Symbol () on at least one sidewall
Test rim	The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire

Tire related term	Meaning
Tread	That portion of a tire that comes into contact with the road
Tread rib	A tread section running circumferentially around a tire
Tread separation	Pulling away of the tread from the tire carcass
Treadwear indicators (TWI)	The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread
Wheel-holding fixture	The fixture used to hold the wheel and tire assembly securely during testing

*:Table 1 — Occupant loading and distribution for vehicle normal load for various designated seating capacities

Designated seating capacity, Number of occupants	Vehicle normal load, Number of occupants	Occupant distribution in a normally loaded vehicle
2 through 4	2	2 in front
5 through 10	3	2 in front, 1 in second seat
11 through 15	5	2 in front, 1 in second seat, 1 in third seat, 1 in fourth seat
16 through 20	7	2 in front, 2 in second seat, 2 in third seat, 1 in fourth seat

Your vehicle includes a variety of electronic features that can be personalized to suit your preferences. Programming these preferences requires specialized equipment and may be performed by your Scion dealer.

Some function settings are changed simultaneously with other functions being customized. Contact your Scion dealer for further details.

Item	Function	Default setting	Customized setting
Wireless remote control (→P. 26)	Wireless remote control	ON	OFF
	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Automatic door lock function to be activated if door is not opened after being unlocked	ON	OFF
	Time elapsed before automatic door lock function is activated if	60 seconds	30 seconds
	door is not opened after being unlocked		120 seconds
	Operation signal (Emergency flashers)	ON	OFF
	Panic function	ON	OFF
Door lock (→P. 30)	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step

Item	Function	Default setting	Customized setting
Automatic light off system $(\rightarrow P. 132)$	Light sensor sensitivity	Level 3	Level 1 to 5
	Time elapsed before headlights automati- cally turn off after doors are closed	30 seconds	0 seconds
			60 seconds
			90 seconds
Illumination (→P. 169)	Time elapsed before lights turn off	15 seconds	7.5 seconds
			30 seconds
	Operation after the engine switch is turned to the LOCK position	ON	OFF
	Operation when the doors are unlocked	ON	OFF
Seat Belt Reminder Buzzer (→P. 280)	Vehicle speed linked seat belt reminder buzzer	ON	OFF

6-2. Customization Items to initialize

The following items must be initialized for normal system operation after such cases as the battery being reconnected, or maintenance being performed on the vehicle.

Item	When to initialize	Reference
Maintenance required remainder light	After the maintenance is per- formed	P. 190
Tire pressure warning system	 When rotating the tires on vehicles with differing front and rear tire inflation pressures When changing the tire size 	P. 223

For owners

Reporting safety defects	o 4 o
for U.S. owners	348
Seat belt instructions	
for Canadian owners	
(in French)	349
SRS airbag instructions	
for Canadian owners	
(in French)	351

Reporting safety defects for U.S. owners

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Scion, a marque of Toyota Motor Sales, U.S.A., Inc. (Toll-free: 1-866-707-2466).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Scion, a marque of Toyota Motor Sales, U.S.A., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to *http://www.safercar.gov*, or write to: Administrator, NHTSA, 1200 New Jersey Ave, S.E., Washington, DC 20590. You can also obtain other information about motor vehicle safety from *http://www.safercar.gov*. The following is a French explanation of seat belt instructions extracted from the seat belt section in this manual.

See the seat belt section for more detailed seat belt instructions in English.

Utilisation correcte des ceintures de sécurité



- Déroulez la sangle diagonale de manière à ce qu'elle passe bien sur l'épaule, sans pour autant être en contact avec le cou ou glisser de l'épaule.
- Placez la sangle abdominale le plus bas possible sur les hanches.
- Réglez la position du dossier de siège. Asseyez-vous le dos le plus droit possible et calezvous bien dans le siège.
- Ne vrillez pas la ceinture de sécurité.

Entretien et soin

Ceintures de sécurité

Nettoyez avec un chiffon ou une éponge humectée d'eau savonneuse tiède. Profitez de l'occasion pour vérifier régulièrement que les ceintures ne sont pas effilochées, entaillées ou ne paraissent pas exagérément usées.

ATTENTION


Endommagement et usure des ceintures de sécurité

Inspectez les ceintures de sécurité périodiquement. Contrôlez qu'elles ne sont pas entaillées, effilochées, et que leurs ancrages ne sont pas desserrés. N'utilisez pas une ceinture de sécurité défectueuse avant qu'elle ne soit remplacée. Une ceinture de sécurité endommagée n'apporte aucune garantie de protection de l'occupant contre d'éventuelles blessures qui peuvent s'avérer graves, voire mortelles.

SRS airbag instructions for Canadian owners (in French)

The following is a French explanation of SRS airbag instructions extracted from the SRS airbag section in this manual.

See the SRS airbag section for more detailed SRS airbag instructions in English.




- ► Sacs de sécurité gonflables frontaux
- Sacs de sécurité gonflables SRS conducteur/passager avant Participent à la protection de la tête et du thorax du conducteur et du passager contre les chocs avec les éléments de l'habitacle.
- Sacs de sécurité gonflables SRS de genoux Participent à la protection du conducteur et du passager avant.
- Sacs de sécurité gonflables SRS d'assise de siège
 Peuvent contribuer à retenir le conducteur et le passager avant.

- Sacs de sécurité gonflables latéraux et rideaux
- Sacs de sécurité gonflables SRS latéraux Participent à la protection du haut du corps des occupants aux places avant.
- Sacs de sécurité gonflables SRS rideaux
 Participent principalement à la protection de la tête des occupants.

Sac de sécurité gonflable SRS rideau de lunette arrière Participe principalement à la protection de la tête des occupants arrière.

Composition du système de sacs de sécurité gonflables SRS



- Capteurs de sac de sécurité gonflable arrière
- Capteurs de sacs de sécurité gonflables rideaux
- Sacs de sécurité gonflables rideaux
- 4 Témoins AIR BAG ON et AIR BAG OFF
- 5 Sacs de sécurité gonflables latéraux
- Sac de sécurité gonflable coussin de siège du passager
- Sac de sécurité gonflable passager avant
- Sacs de sécurité gonflables de genoux
- Prétensionneurs et limiteurs d'effort de ceintures de sécurité
- Capteurs de sacs de sécurité gonflables latéraux et rideaux

- Système de classification d'occupant du siège passager avant (ECU et capteurs)
- Capteurs de sacs de sécurité gonflables frontaux
- Boîtier électronique de sacs de sécurité gonflables
- Contacteur de boucle de ceinture de sécurité passager avant
- Sac de sécurité gonflable rideau de lunette arrière
- 16 Voyant d'alerte SRS
- **17** Sac de sécurité gonflable conducteur
- Contacteur de boucle de ceinture de sécurité conducteur
- Capteur de la position du siège conducteur
- Sac de sécurité gonflable coussin de siège du conducteur

Votre véhicule est équipé de SACS DE SÉCURITÉ GONFLABLES INTELLIGENTS (ADVANCED AIRBAGS) conçus selon les normes de sécurité américaines applicables aux véhicules à moteur (FMVSS208). L'ensemble de capteurs des sacs de sécurité gonflables (ECU) contrôle le déploiement des sacs de sécurité gonflables en fonction des informations obtenues des capteurs, etc. figurant sur le schéma de composition du système ci-dessus. Ces informations comprennent des informations sur la gravité de la collision et les occupants. Le déploiement rapide des sacs de sécurité gonflables est obtenu au moyen d'une réaction chimique dans les dispositifs pyrotechniques, qui produit un gaz inoffensif permettant d'amortir le mouvement des occupants.

Précautions à prendre avec les sacs de sécurité gonflables SRS

Prenez les précautions suivantes avec les sacs de sécurité gonflables. Sinon, des blessures graves, voire mortelles, pourraient s'ensuivre.

 Le conducteur et tous les passagers à bord du véhicule doivent porter leur ceinture de sécurité correctement.

Les sacs de sécurité gonflables SRS sont des dispositifs de protection complémentaires aux ceintures de sécurité.

Le sac de sécurité gonflable SRS conducteur se déploie avec une violence considérable, qui peut être très dangereuse voire mortelle si le conducteur se trouve très près du sac de sécurité gonflable. L'autorité fédérale chargée de la sécurité routière aux États-Unis, la "NHTSA" (National Highway Traffic Safety Administration) conseille:

Sachant que la zone à risque du sac de sécurité gonflable conducteur se trouve dans les premiers 2 à 3 in. (50 à 75 mm) de déploiement, vous disposez d'une confortable marge de sécurité en vous plaçant à 10 in. (250 mm) du sac de sécurité gonflable conducteur. Cette distance est à mesurer entre le moyeu du volant de direction et le sternum. Si vous êtes assis à moins de 10 in. (250 mm), vous pouvez changer votre position de conduite de plusieurs façons:

- Reculez votre siège au maximum qui vous permet encore d'atteindre les pédales.
- Inclinez légèrement le dossier du siège.
 Bien que les véhicules puissent être différents les uns des autres, la plupart des conducteurs peuvent s'asseoir à une distance de 10 in. (250 mm), même avec le siège conducteur complètement avancé, simplement en inclinant un peu le dossier de siège. Si vous avez des difficultés à voir la route après avoir incliné votre siège, utilisez un coussin ferme et antidérapant pour vous rehausser ou, si votre véhicule est équipé du réglage en hauteur du siège, remontez-le.
- Si votre volant de direction est réglable, inclinez-le vers le bas. Cela a pour effet d'orienter le sac de sécurité gonflable en direction de votre poitrine plutôt que de votre tête et de votre cou.

Réglez votre siège selon ces recommandations de la NHTSA, tout en conservant le contrôle des pédales, du volant de direction et la vue des commandes du panneau d'instruments.

For owners

Précautions à prendre avec les sacs de sécurité gonflables SRS



Si vous attachez une rallonge de ceinture de sécurité aux boucles des ceintures de sièges avant, mais pas au pêne de la ceinture de sécurité proprement dite, les sacs de sécurité gonflables SRS frontaux déterminent que le conducteur et le passager avant portent leur ceinture de sécurité, alors même qu'elle n'est pas attachée. Dans ce cas. les sacs de sécurité gonflables SRS frontaux risquent de ne pas se déplover correctement en cas de collision. causant des blessures graves, voire mortelles. Veillez donc à porter la ceinture de sécurité avec la rallonge de ceinture de sécurité.

- Le sac de sécurité gonflable SRS passager avant se déploie également avec une violence considérable, qui peut être très dangereuse voire mortelle, si le passager avant se trouve très près du sac de sécurité gonflable. Éloignez le siège passager avant au maximum du sac de sécurité gonflable, et réglez le dossier de siège de sorte à être assis bien droit sur le siège.
- Les bébés et les enfants qui ne sont pas correctement assis et/ou protégés peuvent être grièvement blessés ou tués par le déploiement d'un sac de sécurité gonflable. Installez les bébés ou les enfants trop jeunes pour pouvoir utiliser la ceinture de sécurité sur un siège de sécurité enfant. Scion recommande vivement d'installer tous les bébés et enfants aux sièges arrière du véhicule et de prévoir pour eux des systèmes de retenue adaptés. Les sièges arrière sont plus sûrs pour les nourrissons et les enfants que le siège passager avant.
- N'installez jamais un siège de sécurité enfant type dos à la route sur le siège passager avant, même si le témoin AIR BAG OFF est allumé. En cas d'accident, par la violence et la vitesse de son déploiement, le sac de sécurité gonflable SRS passager avant peut blesser grièvement, voire tuer l'enfant si vous l'avez installé sur un siège de sécurité enfant type dos à la route monté sur le siège du passager avant.

Précautions à prendre avec les sacs de sécurité gonflables SRS











- Veillez à ce que personne ne soit assis sur le bord du siège et appuyé contre la planche de bord.
- Ne laissez pas un enfant rester debout devant le sac de sécurité gonflable SRS passager avant ou bien s'asseoir sur les genoux du passager avant.
- Ne pas laisser les occupants des sièges avant voyager avec un objet sur les genoux.
- Ne vous appuyez pas contre la porte, contre le rail latéral de toit ou contre les montants avant, latéraux et arrière.
- Interdisez à quiconque de s'agenouiller sur le siège passager et tourné vers la porte ou de sortir la tête ou les mains à l'extérieur du véhicule.


Précautions à prendre avec les sacs de sécurité gonflables SRS







- Ne fixez ni ne posez aucun objet sur la planche de bord, la garniture centrale du moyeu de volant de direction et la partie inférieure du panneau d'instruments.
 - Au déploiement des sacs de sécurité gonflables SRS conducteur, passager avant et genoux, tout objet risque de se transformer en projectile.
- Ne fixez rien aux portes, au pare-brise, aux vitres latérales, aux montants avant et arrière, au rail latéral de toit ou à la poignée de maintien.
- Évitez d'attacher au porte-clés de la clé des objets lourds, pointus ou très durs. Ces objets risquent d'entraver le déploiement des sacs de sécurité gonflables SRS de genoux ou d'être projetés vers le siège conducteur par la force de déploiement, constituant ainsi un danger potentiel.



Précautions à prendre avec les sacs de sécurité gonflables SRS

- Si un cache en vinyle est mis dans la zone où les sacs de sécurité gonflables SRS de genoux se déploient, assurez-vous de l'enlever.
- N'utilisez aucun accessoire de siège venant recouvrir les zones de déploiement des sacs de sécurité gonflables SRS latéraux et du sacs de sécurité gonflables SRS d'assise de siège, car il risquerait de gêner le déploiement des sacs de sécurité gonflables. De tels accessoires peuvent empêcher les sacs de sécurité gonflables latéraux et les sacs coussins de siège de fonctionner correctement, neutraliser le système ou provoquer le déploiement accidentel des sacs de sécurité latéraux et des sacs coussins de siège, provoquant ainsi des blessures graves, voire mortelles.
- Évitez de faire subir des chocs ou des pressions excessives aux parties renfermant les composants des sacs de sécurité gonflables SRS.
 En effet, cela pourrait entraîner un fonctionnement anormal des sacs de sécurité gonflables SRS.
- Ne touchez aucun composant du système immédiatement après le déclenchement (déploiement) des sacs de sécurité gonflables SRS car ils sont alors encore très chauds.
- Si vous avez des difficultés à respirer après le déploiement d'un sac de sécurité gonflable SRS, ouvrez une porte ou une vitre pour faire entrer de l'air frais, ou bien descendez du véhicule si cela ne présente pas de danger. Essuyez tout résidu dès que possible afin d'éviter d'éventuelles irritations de la peau.
- Si les parties renfermant les sacs de sécurité gonflables SRS, telles que la garniture du moyeu de volant et les garnitures de montants avant et arrière, apparaissent abîmées ou craquelées, faites-les remplacer par votre concessionnaire Scion.

Modification et mise au rebut des éléments du système de sacs de sécurité gonflables SRS

Consultez impérativement votre concessionnaire Scion si vous avez besoin d'intervenir sur votre véhicule ou de procéder à l'une des modifications suivantes.

Les sacs de sécurité gonflables SRS risquent de ne pas fonctionner correctement ou de se déployer (gonfler) accidentellement, provoquant ainsi des blessures graves, voire mortelles.

 Installation, dépose, démontage et réparations des sacs de sécurité gonflables SRS.

Réparation, modification, démontage ou remplacement du volant, du panneau d'instruments, de la planche de bord, des sièges ou de leur revêtement, des montants avant, latéraux et arrière ou du rail latéral de toit.

- Réparation ou modification de l'aile avant, du bouclier avant ou du côté de l'habitacle.
- Installation de chasse-neige, de treuils, etc. sur la calandre (pare-buffle, pare-kangourou, etc.).
- Installation de porte-bagages, etc. sur le hayon (porte-bagages à sangles, porte-bicyclettes, etc.).
- Modification des suspensions du véhicule.
- Installation d'appareils électroniques, tels que radio émetteur/récepteur ou lecteurs CD.
- Aménagements apportés au véhicule pour une personne atteinte d'un handicap physique.



Abbreviation list	362
Alphabetical index	363
What to do if	372

Abbreviation list Abbreviation/Acronym list

ABBREVIATIONS	MEANING	
ABS	Anti-Lock Brake System	
ACC	Accessory	
ALR	Automatic Locking Retractor	
CRS	Child Restraint System	
ECU	Electronic Control Unit	
EDR	Event Data Recorder	
ELR	Emergency Locking Retractor	
EPS	Electric Power Steering	
GAWR	Gross Axle Weight Ratings	
GVWR	Gross Vehicle Weight Rating	
I/M	Emission inspection and maintenance	
LATCH	Lower Anchors and Tethers for Children	
LED	Light Emitting Diode	
LT	Light truck	
M + S	Mud + Snow	
MMT	Methylcy clopentadienyl Manganese Tricarbonyl	
MTBE	Methyl Tertiary Butyl Ether	
OBD	On Board Diagnostics	
SRS	Supplemental Restraint System	
TIN	Tire Identification Number	
TPMS	Tire Pressure Warning System	
TRAC	Traction Control	
TWI	Treadwear Indicators	
VIN	Vehicle Identification Number	
VSC	Vehicle Stability Control	

Alphabetical index Alphabetical index

Α	A/C 158
	ABS
	ABS 141
	Warning light 279
	Air conditioning filter 236
	Air conditioning system
	Air conditioning filter 236
	Air conditioning
	system 158
	Airbags
	Airbag operating conditions 70
	Airbag precautions for your
	child76
	Curtain shield airbag
	operating conditions71
	Curtain shield airbag
	precautions76
	Front passenger occupant
	classification system 81
	General airbag precautions 76
	Indicators
	Knee airbag precautions 76
	Locations of airbags 67
	Modification and disposal of
	airbags
	Proper driving posture 65, 76
	Rear window curtain
	shield airbag operating
	conditions71 Rear window curtain
	shield airbag precautions 76 Seat cushion airbag
	precautions
	Side airbag operating
	conditions
	Side airbag precautions
	SRS airbags
	Warning light 279
	Anti-lock brake system
	Anti-lock brake system 141
	Warning light 279

В

Assist grips178 Audio input167 Audio system
Audio input167
AUX port/USB port167
Portable music player167
Steering wheel audio
switch168
Automatic light control
system132
Automatic transmission
Automatic transmission116
Fluid326
If the shift lever cannot be
shifted from P307
Indicators116
Shift lock system307
AUX port167
Auxiliary box174
Back-up lights
Replacing light bulbs263
Wattage328
Back door33
Battery

Checking2	18
If the vehicle battery is	
discharged3	09
Voltage	25
Warning light2	78
Bottle holders1	73
Brake assist1	41
Brakes	
Fluid2	17
Parking brake1	18
Specifications3	26
Warning light2	
Break-in tips1	06

C Care

Exterior184
Interior187
Seat belts188
Cargo capacity146
Chains152
Child restraint system
Booster seats, definition87
Booster seats, installation92
Convertible seats, definition87
Convertible seats,
installation92
Front passenger occupant
classification system81
Infant seat, definition87
Infant seats, installation92
Installing CRS with LATCH
system94
Installing CRS with seat
belts95
Installing CRS with top
tether straps99
Child safety
Airbag precautions76
Battery precautions219, 311
Child restraint system87
How your child should wear
the seat belt46
Installing child restraints92
Power window lock switch55
Power window precautions57
Removed key battery
precautions242
Seat belt extender
precautions48
Seat belt precautions47

Cleaning

Exterior	184
Interior	187
Seat belts	188
Clock121, 126	6, 130
Condenser	216
Cooling system	
Engine overheating	312
CRS	87
Cup holders	172
Curtain shield airbags	67
Customizable features	343

D Daytime running light

system13	34
Defogger	
Rear window164, 16	35
Side mirrors16	35
Dimension32	20
Do-it-yourself maintenance 19) 6
Doors	
Back door	33
Door glasses	55
Door lock	30
Side doors	30
Side mirrors	52
Warning light28	30
Driver's seat belt reminder	
light28	30
Driving	
Break-in tips10)6
Correct posture6	35
Procedures10)4
Winter driving tips15	51

Eco driving indicator	
light 105, 124,	129
Electric power steering	
Electric power steering	141
Warning light	279
Emergency flashers	
Switch	268
Emergency, in case of	
If the engine will not start	305
If the shift lever cannot be	
shifted from P	307
If the vehicle battery is	
discharged	309
If the warning buzzer	
sounds	277
If the warning light turns	
on	277
If you have a flat tire	
If you lose your keys	
If you think something is	
wrong	275
If the vehicle becomes	
stuck	315
If your vehicle has to be	
stopped in an emergency	317
If your vehicle needs to be	
towed	269
If your vehicle overheats	
Emergency tire puncture	
repair kit	288
Engine	
Compartment	210
Engine switch	
Hood	
How to start the engine	199
Identification number	113
Identification number	113 321
Identification number If the engine will not start	113 321 305
Identification number If the engine will not start Ignition switch	113 321 305 113
Identification number If the engine will not start	113 321 305 113 . 62

Warning light2	322 279
Engine coolant	
Capacity	324
Checking	
Indicator	
Preparing and checking	
before winter	151
Туре	
Warning light	
Engine immobilizer system	
Engine oil	.02
0	
Capacity	
Checking2	
Grade	323
Preparing and checking	
before winter	151
Resetting the maintenance	
required remainder light1	
Warning light278, 2	
Engine switch1	113
EPS	
EPS	
Warning light2	279
Event data recorder	.19
Floor mat	170
Fluid	
Automatic transmission	226
Automatic transmission	
Brake	217
Brake2 Warning light277, 2	217 280
Brake2 Warning light277, 2 Washer2	217 280
Brake2 Warning light	217 280 220
Brake	217 280 220
Brake	217 280 220 280
Brake	217 280 220 280
Brake	217 280 220 280 280
Brake	217 280 220 280 280 .37
Brake	217 280 220 280 280 .37 261 132

F

Front	turn	signal	lights

Indicator	124
Lever	117
Replacing light bulbs	262
Switch	117
Wattage	328
Fuel	
Capacity58	, 323
Fuel pump shut off system	276
Gas station information	376
Gauge	121
Indicator	126
Information	329
Refueling	58
Туре	, 323
Fuel door	58
Fuel filler door	58
Fuel gauge	126
Fuel pump shut off system	
Fuses	
Gas station information	376
Gauges	
ouugoo	

H Hazard lights

G

Switch	268
Headlights	
Replacing light bulbs256, 2	259
Switch	132
Wattage	328
Hood	199
Horn	120

I	I/M test195 Identification
	Engine
	Tire
	Vehicle
	Ignition switch113
	Illuminated entry system169
	Immobilizer system62
	Indicator lights123
	Initialization
	Items to initialize345
	Inside rear view mirror50
	Instrument panel light
	control122
	Interior light
	Switch170

J Jack

K Keys

Electronic key	24
Engine switch	113
If you lose your keys	308
Ignition switch	113
Key battery	240
Key number plate	24
Keys	24
Wireless remote control	26

L	License	plate	lights
---	---------	-------	--------

Replacing light bulbs	4
Switch	
Wattage 328	8
Light bulbs	
Replacing 25	5
Wattage 328	8
Lights	
Emergency flashers	
switch	8
Hazard lights switch 268	8
Headlights switch 132	2
Instrument panel lights	
switch 122	2
Interior light switch 170	C
License plate lights switch 132	2
Parking lights switch 132	2
Replacing light bulbs 25	5
Side marker lights switch 132	2
Tail lights switch 132	2
Turn signal lights switch 11	7
Wattage 328	8
Load capacity 150	D
Lock steering column 114	4
Luggage box 18	1
Luggage compartment	
features18	1

Μ

Maintenance

Do-it-yourself
maintenance 196
Emission inspection and
maintenance (I/M)
programs 195
General maintenance 192
Maintenance data 320
Maintenance requirements 190
Vehicle exterior 184
Vehicle interior 187

Meter

	Instrument panel light
	control122
	Meters121
	Mirrors
	Inside rear view mirror50
	Side mirror heaters165
	Side mirrors52
	Vanity mirrors176
	Multi-information display126
Ν	Noise from under vehicle17
0	Odometer127
	Odometer 127 Oil
	Engine oil211
	Warning light278, 280
	Opener
	Back door
	Fuel door58 Fuel filler door58
	Hood199 Outside rear view mirrors
	Adjusting
	Defogger
	Folding
	Overheating, Engine312
Ρ	Parking brake118
	Parking lights
	Replacing light bulbs261
	Switch132
	Wattage328
	Power outlet177
	Power windows55

R	Radiator	216
	Rear seat	
	Folding down	40
	Rear side marker lights	
	Replacing light bulbs	263
	Switch	132
	Wattage	328
	Rear turn signal lights	
	Indicator	124
	Lever	117
	Replacing light bulbs	263
	Switch	117
	Wattage	328
	Rear window defogger	164
	Rear window wiper	139
	Replacing	
	Key battery	240
	Fuses	244
	Light bulbs	255
	Tires	204, 222
	Reporting safety defects	
	for U.S. owners	348
	Resetting the maintenance	e
	required remainder light	: 190

Seat belts

S

ALR4	5
Automatic Locking Retractor 4	5
Child restraint system	
installation87, 9	2
Cleaning and maintaining18	8
ELR4	5
Emergency Locking	
Retractor 4	5
How to wear your seat belt 4	3
How your child should wear	
the seat belt4	6
Pregnant women, proper	
seat belt use4	-
Reminder light28	0
Seat belt extenders4	6
Seat belt pretensioners4	5

Seats

Adjustment	37
Adjustment precautions	39
Child seats/child restraint	
system installation87	7, 92
Cleaning	. 187
Front seat adjustment	37
Front seat adjustment	
precautions	39
Properly sitting in the seat	65
Service reminder	
indicators	.123
Shift lever	
Automatic transmission	.116
If the shift lever cannot be	
shifted from P	. 307
Shift lock system	. 307
Side airbags	67
Side marker lights	
Replacing light bulbs 261,	263
Switch	. 132
Wattage	. 328
Side mirror	
Adjusting	52
Defogger	. 165
Folding	53
Spark plug	.325
Specifications	.320
Speedometer	.121
Steering wheel	
Adjustment	49
Column lock release	
Electric power steering	
EPS	
Specification	
Warning light	.279

Stop lights
Replacing light bulbs 263
Wattage 328
Storage features
Auxiliary boxes 171, 174
Bottle holders 171, 173
Cup holders 171, 172
Storage precautions 148
Stuck
If the vehicle becomes
stuck 315
Sun visors 175
Switch
Emergency flashers
switch 268
Engine switch 113
Hazard lights switch
Headlights switch 132
Ignition switch 113
Instrument panel light
control 122
Light switch 132
Outside rear view mirror
switch52
Power door lock switch
Power window switch 55
Turn signal lights 117
VSC OFF switch 143
Window lock switch 55
Wiper and washer 136, 139

Tachometer	.121
Tail lights	
Replacing light bulbs	.263
Switch	
Wattage	.328
Theft deterrent system	
Engine immobilizer system	62
Theft prevention labels	64
Theft prevention labels	64
Tire inflation pressure	.230
Tire information	
Glossary	.337
Size	
Tire identification number	.333
Uniform tire quality	
grading	.335
Tires	
Chains	.152
Checking	.222
If you have a flat tire	
Identification number	.332
Inflation pressure230,	327
Inflation pressure sensor	.223
Information	
Replacing204,	
Rotating tires	.222
Size	.327
Snow tires	.151
Tire pressure warning	
system222,	
Warning light	
Tools	
Total load capacity	.150
Towing	
Dinghy towing	
Emergency towing	
Trailer towing	.155

Т

	Traction control	141
	TRAC	141
	Trip information	127
	Trip meter	
	Turn signal lights	
	Indicator	124
	Lever	
	Replacing light bulbs26	2, 263
	Switch	
	Wattage	
	5	
U	USB port	167
0		107
V	Maatte	470
V	Vanity mirrors	
	Vehicle data recordings	18
	Vehicle identification	
	number	
	Vehicle stability control	
	VSC	141
10/		
W	Warning buzzers	
	Brake system	
	Seat belt reminder	280
	Warning lights	
	ABS	
	Airbag system	
	Anti-lock brake system	
	Brake system	
	Charging system	278
	Driver's seat belt	280
	Electric power steering	
	system	279
	Electronic engine control	
	system	
	Engine oil replacement	280
	EPS system	279

Front passenger occupant	
classification system27	9
Front passenger's seat belt28	0
High engine coolant	
temperature27	8
Low brake fluid27	
Low engine oil pressure27	
Low fuel level	
Low tire inflation pressure28	
Low washer fluid28	
Malfunction27	9
Open door28	0
Seat belt28	0
Seat belt pretensioner	
system27	9
SRS27	
SRS airbag system27	9
Tire pressure28	0
Tire pressure warning	
system28	0
TRAC27	9
VSC27	9
Washer	
Checking22	0
Preparing and checking	
before winter15	1
Switch136, 13	9
Warning light 28	0
Washing and waxing18	4
Weight	
Cargo capacity14	6
Load limits15	0
Weight32	0
Wheels23	4
Window	
glasses55, 164, 184, 18	
Window lock switch5	5


Windows

Cleaning and
protecting 184, 187
Power windows 55
Rear window
defogger 164, 165
Washer 136, 139
Windshield wipers 136
Wireless remote control key
Replacing the key battery 240
Wireless remote control 26


What to do if... What to do if...

A tire punctures	P. 288	If you have a flat tire
The engine does not start	P. 305 P. 62 P. 309	Engine immobilizer system
The shift lever cannot be moved out	P. 307	If the shift lever cannot be shifted from P
The engine coolant temperature warning light flashes or comes on Steam can be seen coming from under the hood		If your vehicle overheats
The key is lost	P. 308	If you lose your keys
The battery runs out	P. 309	If the vehicle battery is discharged
The doors cannot be locked	P. 30	Side doors
The vehicle is stuck in mud or sand	P. 315	If the vehicle becomes stuck
The warning light or indicator light comes on	P. 277	If a warning light turns on

Instrument cluster



Center panel



■Warning lights

BRAKE	Brake system warning		Γ		Electric power steering system	
DHARE	light			8	warning light	P. 279
or	т		F		1	
		D 4777			Slip indicator	5
		P. 277		~~		P. 279
	Charging system warning		Γ		Open door warning light	
- +	light	P. 278				P. 280
			L			
	Low engine oil pressure		Г		Low fuel level	warning
95%	warning light	P. 278		-jije -	light	P. 280
			L			
F	High engine coolant tempera-		Γ	21	Driver's seat belt	
∼€∽	ture warning light	P. 278		$\langle \mathbf{A} \rangle$	reminder light	P. 280
CHECK Or	Malfunction indicator lamp			PASSENGER	Front passenger's seat belt reminder light	
ŕ		P. 279		Ä		P. 280
SRS warning light						
	Give warning i	P. 279		(!)	light	P. 281
		1.213		Trinf	ingint	1.201
ABS warning light					uid warn-	
ABS	g.	3			ing light	P. 281
				-		
or						
]		Γ	MAINT	Maintenance r	equired

Memo

