

SECTION I

ENGINE AND EXHAUST SYSTEMS

00100079

	Page
Description...	3
General data...	3
Lubrication system	
Description ...	19
Pressure relief valve... Removing and refitting pressure relief valve...	24
Adjusting the oil pressure...	26
Maintenance ...	26
Engine oil ...	27
Changing the oil ...	27
Oil filter (full-flow type)	
Description ...	28
Servicing (Ferodoite) ...	29
Servicing (Vokes) ...	29
External oil cooler ...	30
Internal oil cooler	
Description ...	32
Installing ...	34
Removing and refitting ...	37
Oil pump	
Description ...	39
Removing and refitting ...	39
Stemming ...	40
Inspection and re-assembling ...	40
Cylinder head	
Description ...	41
Removing and refitting ...	44
Valve clearance ...	47
Dismantling ...	48
Inspection and re-assembling ...	49
Replacing valve guides ...	51
Replacing rocker bushes ...	52
Re-assembling ...	52
Cylinder block	
Description ...	53
Refitting ...	53

	Page
Crankshaft	
Description	56
Removing and refitting	57
Inspection	59
Main bearings	60
Fitting main bearings	60
Re-grinding	61
Flywheel and starter ring	63
Flywheel	63
Connecting rods and pistons	
Description	64
Removing and refitting	64
Inspection	65
Replacing big-end bearings	67
Replacing piston-pin bushes	67
Overseas pistons	68
Camshaft	
Description	68
Removing and refitting	69
Inspection	70
Replacing bearings	70
Timing	71
Oil pump	
Description	72
Removing and refitting	73
Ignition system	
Description	74
Distributor maintenance	
General	75
Lubrication	75
Cleaning contact breaker	76
Setting contact breaker gap	76
Replacements	78
Replacing contact breaker	79
Replacing condenser	79
Removing and refitting distributor and drive	80
Ignition timing	81
Spark plug	81
Exhaust system	
Removing and installing the engine	
Type 400 cars	83
Type 401 and 402 cars	87
Engine run-up	93
Running faults	92
Special tools	95

新编民族学词典·历史与社会学类

BBC 03-08 8月刊

S N E E Z E A N D W I L R A U T E S Y S T E M

DESCRIPTION

The engines fitted to types 406, 407 and 410 cars are basically identical with the exception of the carburetors, see the General lists of Section 1. Figs. 1 and 2 illustrate the constructional features.

The cylinder block is a one-piece casting, the crankshaft being supported by four main bearings of the steel-bushed replaceable type. Bearings of a similar type are employed for the big ends of the connecting rods, the small end bearings for the crankpin pin being bronze bushes. A chain drive is employed for the auxiliary shaft which is supported in four bronze bush bearings on the left-hand side of the cylinder block; an integral helical gear mounted centrally on the shaft operating the distributor and oil pump drive pinion. The oil pump is bolted to the base of the cylinder block within the sump. An adjustable relief valve located in the cylinder block immediately above the oil filter, controls the pressure of the oil delivered to the bearings.

The distinctive light-alloy cylinder head accommodates hardened valve seats which are shrink-fitted. Bronze valve guides locate the exhaust valves on the right-hand side of the head and the inlet valves on the left-hand side. The overhead rocker system is operated by push rods, auxiliary push rods being used to transmit the movement of the exhaust push rods (via auxiliary rockers mounted on the inlet rocker spindle) to the exhaust valves.




FIG. 1. Lateral section showing the details of a longitudinal transverse.




Fig. 7. Transverse section view of the 1920 model.

The engine and gearbox unit is flexibly mounted on four headed-rubber blocks, those at the front being bolted between the engine bracket attached to the cylinder block and chassis frame, and those at the rear being secured between the gearbox extension and chassis cross member. Torque buffers are fitted on the left-hand side of the flywheel housing.

GENERAL DATA

Type...	Overhead valves, push-rod operated.
No. of cylinders...	6 in line.
Bore...	2.536 in. (64 mm.).
Stroke...	3.770 in. (95 mm.).
Compression ratio...	7.5 to 1.
Cubic capacity (cylinders)				
Displacement...	130.3 cu. in. (1,971 c.c.).
Rated horse-power...	12.2 (H.A.C. rating).
Maximum B.H.P.				
Type 25...	75 at 4,200 r.p.m. (76.00 h.p.).
Type 25A...	80 at 4,200 r.p.m. (81.10 h.p.).
Type 25C...	85 at 4,200 r.p.m. (86.10 h.p.).
Weight of engine (less gearbox).				
Type 25...	350 lb. (158.8 kg.).
Type 25A...	370 lb. (167.7 kg.).
Type 25C...	366 lb. (157.1 kg.).
Oil pump...	Gear type.
Oil tank capacity...	10 pints (5.68 litres).
Oil filter...	"Valent" or "Tefaloid".
Oil pressure...	60 p.s.i. (4.20 kg./cm. ²) at 10% and 3,000 r.p.m.

Capacity of external oil sump (optional fitting) 1. pint (0.56 litres) approx.

© 2014 Kuta Software LLC

Type... None other than. Late-type 193 engines had all-type 85% magnet fitted with dry-type cylinder liners.

Total variation fit between linear and best 0.0097 fm. to 0.1017 fm.

806

Driving and drafting gear, Inc. Model A-1. \$40.00-\$10.00

One junction done. to jump writing... 0.001 hr. (+0.0005 sec.)
28,479 min. (+0.013 sec.)

Reduced nitrogen at 100°C in mmol/m³ ... 0.001 hr. 20 min. 60 min.
 (0.023 min., 20 min. 0.051 min.)

Driving and drivers may general size . . . 0.3765 lbs. (-0.0005 lbs.)
9.512 in.m. (-0.013 in.m.)

During clearance of your
journals it seems D.0003 fm. to Q.DD13 fm.
(0.013 m.m. to 0.038 m.m.)

Journal location dist. to pump center 0.975 in. (+0.0005 in.)
0.975 in. (+0.013 in.)

End-point of gear 0.0005 in. to 0.0015 in.

Cylinder Head

Type	Detachable.
Material	Aluminum alloy with phenyl valve seats and phosphor-bronze valve guides.
Valves and fittings						
Fuel valves	Disclosed and closed.
Exhaust exhaust	Supports, push rods and valves.
Exhaust fitting	
Inlet open	10° Before cap dead center.
Inlet closure	30° After valve dead center.
Exhaust open	30° Before bottom dead center.
Exhaust closure	10° After top dead center.
Inlet valves	
Cupped diameter solid	0.03 in. (0.08 mm.).
Valve seat angle	Valve = 25° Inlet = 45°
Valve face diameter	0.3105 in. (7.887 mm.)
Valve guide bore diameter	0.3125 in. (7.895 mm.)
Valve stem and guide dashed clearance (solid)	0.012 in. to 0.002 in. (0.031 mm. to 0.051 mm.)
Valve guide outside dia.	0.305 in. (7.747 mm.)
Valve guide location form	0.005 in. (0.013 mm.)
Temperature fit of valve guides						
In cylinder head	0.003 in. to 0.007 in. (0.033 mm. to 0.058 mm.)
Outer spring - free length (approx.)	0.172 in. (4.370 mm.)
Length when loaded to 47.5 lb (21.1 kg)	1.021 in. (26.0 mm. (1.8 kg)).
Length when loaded to 20.0 kg (44.1 lb)	26.111 mm.

Outer spring - free length (approx.) ... 1.697 in. (43.100 mm.)

Length when loaded to 5 lb. (+ 4 lb.) ... 1.225 in.
24.5 kg. (+ 1.0 kg.) ... 26.117 mm.

Rocker bush bore dia. 0.510 in. (12.954 mm.)

Rocker arm dia. 0.505 in. (12.839 mm.)

Rocker bush and spindle -
desired clearance 0.001 in. to 0.003 in.
(0.025 mm. to 0.080 mm.)

Valve valves

Poppet clearance 0000 0.002 in. (0.051 mm.)

Valve stem height Valve = 85% Throat = 85%

Valve stem dia. 0.9103 in. (7.187 mm.)

Valve guide bore dia. 0.5125 in. (7.895 mm.)

Valve stem and guide -
desire clearance (gold) 0.002 in. to 0.003 in.
(0.051 mm. to 0.080 mm.)

Valve guide outside dia. 0.451 in.
11.417 mm. (-0.011 mm.)

Valve guide location bore 0.4707 in.
12.000 mm. (-0.006 in.)

Interference fit of valve guides
in cylinder head 0.0003 in.
(0.008 mm. to 0.012 mm.)

Tension spring - free length (approx.) ... 1.621 in. (41.175 mm.)

Length when loaded to 67.5 lb. (+ 5 lb.) ... 1.035 in.
29.6 kg. (+ 4.5 kg.) ... 26.417 mm.

Outer spring - free length (approx.) ... 1.547 in. (39.260 mm.)

Length when loaded to 54 lb. (+ 4 lb.) ... 1.035 in.
24.5 kg. (+ 3.5 kg.) ... 26.417 mm.

Breakaway

No. of main bearings	Front	Middle	Rear	Front	Middle	Rear	Front	Middle	Rear
Bearing type									
Ball bearing journal dia. (in.)000000000	Steel lined	Steel lined	Lead lined	Steel lined	Steel lined	Steel lined
Ball bearing journal dia. (in.) (after 1st re-grind)000000000	1.000 in.	1.000 in.	1.000 in.	(+0.0000 in.)	(+0.0000 in.)	(+0.0000 in.)
Ball bearing journal dia. (in.) (after 2nd re-grind)000000000	1.000 in.	1.000 in.	1.000 in.	(+0.0000 in.)	(+0.0000 in.)	(+0.0000 in.)
Front bearing overall length									
Front bearing000000000000	1.464 in.	1.464 in.	1.464 in.	(+0.002 in.)	(+0.001 in.)	(+0.000 in.)
Mid-front bearing000000000000	1.781 in.	1.781 in.	1.781 in.	(+0.000 in.)	(+0.000 in.)	(+0.000 in.)
Mid-rear bearing000000000000	1.191 in.	1.191 in.	1.191 in.	(+0.000 in.)	(+0.000 in.)	(+0.000 in.)
Rear bearing000000000000	1.412 in.	1.412 in.	1.412 in.	(+0.000 in.)	(+0.000 in.)	(+0.000 in.)
Breakage dia. (in.)									
Breakage dia. (initial)000000000000	1.721 in.	1.721 in.	1.721 in.	(+0.000 in.)	(+0.000 in.)	(+0.000 in.)
Breakage dia. (initial) (after 1st re-grind)000000000000	1.721 in.	1.721 in.	1.721 in.	(+0.000 in.)	(+0.000 in.)	(+0.000 in.)
Breakage dia. (after 2nd re-grind)000000000000	1.721 in.	1.721 in.	1.721 in.	(+0.000 in.)	(+0.000 in.)	(+0.000 in.)
Breakage length (in.)									
Breakage length000000000000	30.016 in.	30.016 in.	30.016 in.	(+0.001 in.)	(+0.001 in.)	(+0.001 in.)
During hardness									
Thrust value in breakaway									
End-of-cone force000000000000	0.102 in.	0.102 in.	0.102 in.	(+0.000 in.)	(+0.000 in.)	(+0.000 in.)

Standard Deviation				0.002 in. to 0.012 in. (0.002 mm. to 0.030 mm.)
Maximum error of standard deviation				0.002 in. (0.002 mm.) (not indicated 0.01 in. (0.025 mm. (not indicated error reading))
Suspending clearance of crankshaft to main bearing				0.01 in. to 0.025 in. (0.025 mm. to 0.062 mm.)

Comparing rule and gage

Pivoting rule

Type				Sliding stem, PIP model
Plated or unpolished				0.007 in. (0.018 mm.)
Unplated pin bush location				0.010 in. (0.025 mm.)
Side clearance vs. pin slippage				0.008 in. to 0.010 in. (0.020 mm. to 0.025 mm.)

Dig-and-measure

Type				Steel backed, 100 ft. from center line.
Wall thickness				0.0725 in. (1.84 mm.) (-0.005 in.)
Bottom clearance of journal				0.0012 in. (0.031 mm.) to 0.002 in. (0.051 mm.)

Gauge pin holes

Outer dia.				0.7036 in. (17.819 mm.) (+0.011 in.)
Inside dia.				0.6932 in. (17.073 mm.) (-0.013 in.)
Dimension (1) is supporting rod				0.001 in. (0.025 mm.) to 0.002 in. (0.051 mm.)

SECTION 1.

- 14 -

Bushing pins

Bushing pins,	++	++	++	0.0003 in. (+0.017 mm.)	0.0003 in. (+0.009 mm.)
Cleavage in piston pins break.,	++	++	++	0.0001 in. (+0.005 mm.) 0.0005 in. (+0.030 mm.) 0.0002 in. (+0.013 mm.) 0.0007 in. (+0.040 mm.)	0.0005 in. (+0.030 mm.) 0.0002 in. (+0.013 mm.) 0.0007 in. (+0.040 mm.)

Pins in piston pins	++	++	++	0.0001 in. (+0.005 mm.) 0.0002 in. (+0.013 mm.) 0.0003 in. (+0.017 mm.)	0.0001 in. (+0.005 mm.) 0.0002 in. (+0.013 mm.) 0.0003 in. (+0.017 mm.)
---------------------	----	----	----	--	--

Pistons

Skirted pins,	++	++	++	0.0002 in. (+0.010 mm.)	0.0003 in. (+0.013 mm.)
Bushing pins worn.,++	++	++	++	0.0003 in. (+0.013 mm.)	0.0003 in. (+0.013 mm.)

Piston clearance in cylinder bore, skirted solid and on skirted side	++	++	++	0.0022 in. (+0.056 mm.)	0.0005 in. (+0.013 mm.) 0.0006 in. (+0.017 mm.)
Oversize piston.,++	++	++	++	+0.010 in. in cylinder size.	(0.250 mm.)

Piston rings

Diesel engines (0.11 ring),++	++	++	0.001 in. (+0.027 mm.)	0.0005 in. (+0.013 mm.)
Radial pressure (engines),++	++	++	20.6 lb. / 29.9 mm.² (1,463 kg./dm.²)	20.6 lb. / 29.9 mm.² (1,463 kg./dm.²)

Radial pressure (engines)++	++	++	35.0 lb. / 40.0 mm.² (2,465 lb. / 2,813 kg./dm.²)	35.0 lb. / 40.0 mm.² (2,465 kg./dm.²)
Width of ring (expander),++	++	++	0.0002 in. (+0.005 mm.)	0.0001 in. (+0.003 mm.)

Width of ring (expander),++	++	++	0.0002 in. (+0.005 mm.)	0.0001 in. (+0.003 mm.)
Ring clearance in groove (expander),++	++	++	0.0001 in. (+0.003 mm.)	0.0002 in. (+0.005 mm.)

Ring clearance in groove (expander),++	++	++	0.0001 in. (+0.003 mm.)	0.0002 in. (+0.005 mm.)
Ring clearance in groove (expander),++	++	++	0.0001 in. (+0.003 mm.)	0.0002 in. (+0.005 mm.)
Ring gap when fitting in cylinder,++	++	++	0.0001 in. (+0.003 mm.)	0.0001 in. (+0.003 mm.)

* - Indicates that selection already in assembly.

Shaft									
Shaft									
No. of journals ...									4
Bearings ...									Pumpax-bronze.
Bearing journal diameter									
Front	1.450 in.	(-0.0005 in.)	
							37.033 m.m.	(-0.013 m.m.)	
Mid-front	1.450 in.	(-0.0005 in.)	
							37.033 m.m.	(-0.013 m.m.)	
Mid-rear	1.415 in.	(-0.0005 in.)	
							35.997 m.m.	(-0.003 m.m.)	
Rear	1.275 in.	(-0.0005 in.)	
							32.003 m.m.	(-0.013 m.m.)	
Shaft-shaft distance ...									
Front	Front		
Bearing clearance in bearings	0.005 in.	to	0.005 in.
							(0.05 m.m.)	to	(0.076 m.m.)
Mid-front	0.005 in.	to	0.005 in.
							(0.102 m.m.)	to	(0.132 m.m.)
Mid-rear mid-clearance of journals	0.000 in.	(0.002 in. mid indicator reading).	
							0.005 m.m.	(0.001 mid-indicator reading).	
Gen. lift	0.0066 in.	(0.017 m.m.)	
Mid-front of distributor drive gear	0.0066 in.	to	0.006 in.
							(0.168 m.m.)	to	(0.136 m.m.)
Bushings between gear and sunshaft gear	0.005 in.	to	0.005 in.
							(0.076 m.m.)	to	(0.121 m.m.)
Bimetallic clearance of gear in bush	0.000 in.	to	0.0018 in.
							(0.015 m.m.)	to	(0.046 m.m.)
Sunshaft bearings									
Pore size									
Front	1.450 in.	(-0.001 in.)	
							37.032 m.m.	(-0.012 m.m.)	
Mid-front	1.450 in.	(-0.001 in.)	
							37.032 m.m.	(-0.012 m.m.)	

Mid-rear... +0.000 in. +0.000 in. 1.620 in. (+0.001 in.)
36.000 m.m. (-0.025 m.m.)

Rear... +0.000 in. +0.000 in. 1.200 in. (+0.001 in.)
30.000 m.m. (-0.025 m.m.)

Bearing surfaces, flat.

Front... +0.000 in. +0.000 in. 1.6738 in. (+0.0001 in.)
42.000 m.m. (-0.015 m.m.)

Mid-front... +0.000 in. +0.000 in. 1.6738 in. (+0.0001 in.)
42.000 m.m. (-0.015 m.m.)

Mid-rear... +0.000 in. +0.000 in. 1.7172 in. (+0.0001 in.)
43.000 m.m. (-0.015 m.m.)

Rear... +0.000 in. +0.000 in. 1.7305 in. (+0.0001 in.)
43.000 m.m. (-0.015 m.m.)

Bearing location in cylinder block

Front... +0.000 in. +0.000 in. 1.177 in. (+0.0007 in.)
42.500 m.m. (+0.010 m.m.)

Mid-front... +0.000 in. +0.000 in. 1.507 in. (+0.0007 in.)
43.000 m.m. (+0.010 m.m.)

Mid-rear... +0.000 in. +0.000 in. 1.713 in. (+0.0001 in.)
43.000 m.m. (-0.015 m.m.)

Rear... +0.000 in. +0.000 in. 1.733 in. (+0.0001 in.)
43.000 m.m. (+0.010 m.m.)

**Interferometer tilt of bearing
in cylinder block**

Front... +0.000 in. +0.000 in. 0.0076 in. to 0.029 in.
(0.001 m.m. to 0.071 m.m.)

Mid-front... +0.000 in. +0.000 in. 0.0076 in. to 0.028 in.
(0.001 m.m. to 0.071 m.m.)

Mid-rear... +0.000 in. +0.000 in. 0.0076 in. to 0.025 in.
(0.001 m.m. to 0.071 m.m.)

Rear... +0.000 in. +0.000 in. 0.0076 in. to 0.031 in.
(0.001 m.m. to 0.077 m.m.)

Jazz Age




Fig. 3. Diagram of Type 85 and 86 Engine Lubrication System - Side View.

INJECTION SYSTEM

Description

The injection system of the engine is shown diagrammatically in Figs. 1 to 6. A plow unit is attached to the pump unit at the bottom of the pump casting cover and is completely submerged in the oil tank. Pressure oil is delivered through the pump body and a suction internal gallery in the cylinder block to the head of a filter unit mounted externally on the left-hand side of the cylinder block. A branch duct from the main delivery passage to the filter links the plow to the cylinder pressure-oil valves. Pressure oil may be used direct into the pump.

If the unit is fitted with an external oil cooler in front of the unitary, flexible rubber pipes are connected to external cooler connections on the inlet side of the "Toke" filter-unit to circulate the oil through the cooler prior to entering the filter; a spring-loaded valve in the foot of the filter permits the oil to bypass the cooler in cold weather to assure immediate flow of oil to the bearings, see page 16. If an external cooler is not fitted, the main bearing oil line is fitted. A pipe is also arranged in the filter to water for the possibility of a damaged filter canister assembly. After passing through the filter, the oil enters the cylinder block by the main gallery "Quick exhaust" longitudinally through the left-hand cylinder block wall immediately below each shaft, an annular groove around the distributor and oil pump driving pinion bush linking the front and rear portions of the gallery. A drilling from the




Fig. 5. Diagram of Type 15 and 16 Engine Lubrication system - front view.




Fig. 5. Diagnostic Test NYC: *Cochlear Ichthyomias exstema* - side view.




FIG. 2. Diagram of Type 177 Marine Lubricating Pump - front view.

Each bearing to the rear provides pressure lubrication to the bearing of the distributor and oil pump driving pinion. Lubrication from the gallery supply the crankshaft bearings and the transhaft main bearing, turns in the crankshaft connecting the flow to the connecting rod big end bearing. A duct drilled through each rod provides an intermittent feed from the big end bearing to the engine gear bushes.

Note:- On type 25 and 30 engines, the oil leaving the filter is sent to a transfer housing located on the right-hand side of the front of the cylinder block before entering the main gallery. This housing was designed to accommodate an external oil cooler. Where this has been removed, the location is blanked. See page 22. On these engines, the front main bearing is lubricated through a branch duct from the return passage from the oil transfer housing to the main gallery, see Fig. 3.

The crankshaft front main bearing journal incorporates an additional dust shield terminating in the front face of the journal; oil flowing from the bearing through this dust shield emerges through the annular space between the thrust plate and the shaft from sprout and enters a drilling in the bearing main arm opposed to lubricate the shaft. An external connection from the main gallery connects the pipe to the oil pressure gauge.

An intermittent feed to the cylinder liner system is obtained from a transverse drilling in the rear crankshaft bearing journal which rotates every 17° revolution with an orifice in the rear wall of the cylinder block. This is the by an external pipe to a duct in the cylinder head. Branch ducts from cylinder head orifice terminate in each cylinder within rear bearing. The feed being continued through the cylinder to the piston. A further intermittent feed (from the mid-front crankshaft bearing) is connected by an external pipe to

the temperature drops in the distributor drive housing. The temperature of the oil is recorded by means of a thermometer bulb inserted in the left-hand side of the oil sump. The cylinders, piston and connecting rod are lubricated by splash or spray oil.

Pressure relief valve

Located at the left-hand side of the cylinder block, see Fig. 7, the relief valve is interposed in the supply from pump to filter. The assembly consists of the body which houses the relief valve, spring and adjusting screw. The assembly is mounted onto the cylinder block where it is secured by a lock-nut, the cap covering the other end.

The types of valve have been too manufactured. The earlier type has four equally spaced $\frac{7}{16}$ in. relief holes, while the latest type has three equally spaced holes, two being $\frac{3}{8}$ in. and one $\frac{1}{2}$ in. This eliminates all possibility of valve flutter.

Removing and refitting pressure relief valve

If the operation of the valve is suspect, remove and inspect the assembly as follows. Block the lock-nut, then tighten it against the cap and extract the assembly from the cylinder block. Holding the lock-nut, loosen the cap, then remove the cap, lock-nut and adjusting screw. Extract the exterior retaining pin, unscrew the adjusting screw and withdraw the valve and spring. Clean all components thoroughly.

Check that the oil holes in the body are unobstructed. Inspect the valve for picking-up and burr bearing. If necessary, draw each area by light scraping. Reinsert the valve in the body. It should be an easy sliding fit.




FIG. 7. 801 pressure relief valve.




FIG. 8. Relief valve assembly.




FIG. 9. "Tessolini" oil separator.




FIG. 10. "Tessolini" oil separator.

Re-assemble the valve, spring and adjuster to the body, screwing in the adjusting screw until the retaining pin can be inserted. Fit the lock-nut and cap, packing them together, and screw the assembly into the cylinder block. Make sure that the valve body is correctly fitted to its seating at 100% of oil pressure may result. Separate and remove the lock-nut and cap.

Step 24 An elastomer washer fitted to the cylinder block forms a sealing for the body. If there is evidence of oil leakage, renew this oil pressure washer.

Fit a new packing washer over the body and pack the assembly in position from the cylinder.

Adjusting the oil pressure

After removal of the relief valve assembly or if the pressure is incorrect, proceed as follows. Run the engine until the oil is at 30°C. and revs up to 3,000 r.p.m. Remove the cap and retaining pin, then turn out the adjusting screw to decrease the pressure or turn it to increase the pressure. Replace the retaining pin, fit a new packing washer then move on and normally tighten the cap.

Maintenance

Check periodically that the cap retaining set-screws are secure and that there is no oil leakage from the impeller-cylinder block joint. Check also that all external oil pipes and the filter unit retaining set-screws are secure and that the pipes are not kinked or fractured. Should oil leakage at the filter-cylinder block joint be detected and the set-screws are secure, renew the filter unit as described on page 29 or 30, clean the joint faces and refit the unit, using a new gasket. Do not use jointing compound.

BOILING OIL

It is most important to use the correct grade of oil according to the weather and the climatic conditions. Approved oils for various conditions are given in the "Approved Lubricants" on page 37. When measuring the oil level, make sure the car is level and wipe off the dipstick to obtain an accurate reading. Allow time for the oil to drain to the sump. This will ensure that the dipstick is inserted fully when measuring the level. Maintain the level at or near full and never the upper mark. Avoid overfilling as this will result in high oil temperatures.

Draining the oil

It is recommended that this should be done every 100 miles (2,000 Kilometers) and preferably after an engine run, i.e. when the engine is hot. To drain the oil, remove the drain plug on the left underside of the sump and sump. If fitted, the plug in the base of the oil filter. If a plug is not fitted, remove the filter causing to drain the filter. Fit a new filter element as described on page 29 or 30. If the sump is on a level surface, jack up the right-hand side of the car slightly to assist the sump base; this will assist drainage. After thorough draining, replace the drain plugs to the filter and sump. If used with an external oil cooler, disconnect the two flexible oil pipes at the base of the oil filter, and allow the oil to drain into a suitable container. Drain the cooler completely by applying a blast of clean, dry compressed air through the upper flexible pipe. This will also wash any obstruction so as to be dislodged; in this event, remove the unit as described on page 17 and clear the obstruction with a suitable object.

This drainage is completed, re-fill the tank with approved oil through the oil filler on the inlet rocker box cover; prime the oil filter as described on page 29 or 30 before any attempt is made to turn or start the engine.

Oil Filter (Two Types)

Description

Early type D2 and 41A engines are fitted with a "Ficelotit" filter and all later engines with a "Tork" filter, both types being secured by two nuts onto the bottom side of the cylinder block.

The filter consists of a casting in which is located a replaceable element. On "Tork" filters, the element is retained in a perforated steel frame, the unit being known as the "insert assembly". The casting is attached to a baffle which provides the attachment point to the cylinder block, and which is formed such an orifice which removes the oil from the pipe and one which passes the filtered oil to the engine cavity.

On "Ficelotit" filters, oil enters the casting and passes from the base of the element. A spring-loaded valve links the outlet passage in the baffle to the interior of the casting, enabling the oil to bypass the element should it become clogged.

The filter is secured on "Tork" filters, the oil entering the base of the insert assembly and emerging into the casting. A spring located beneath the assembly holds the upper end cap against a setting on the baffle thus providing a by-pass in the event of the assembly becoming clogged. A later type of baffle also incorporates a spring-loaded valve in the inlet passage and two external connections for use when an external cooler is fitted to the car. The valve

enables the oil to bypass the valve in the event of sticking. When an external cover is not fitted, the valve location are blanked.

Reversing (Front)

Remove the locking plunger, twist the casting, withdraw it clear of the head and withdraw the element. The element should be discarded after 5,000 miles, and a new one fitted. Do not attempt to clean an element, since foreign matter will transfer from the inside to the outside and vice versa. Brush the condition of the rubber seating ring in the casting of the body. Fit a replacement if damaged or sprung. Check that the bypass valve operates satisfactorily. If it is desired to renew the head, release the two retaining set-bolts and washers, and withdraw the head. After cleaning, ensure the joint faces are unbroken and refit the head, using a new joint, do not over-tighten provided.

Before refitting the element and casting, it is advisable to fill the casting with clean approved engine oil, thereby ensuring an immediate supply to the engine system when the engine is started. Ensure that the casting is seated squarely into the head and that the locking plunger returns to its position.

Reversing (Rear)

Remove the drain plug from the bottom of the casting and allow the oil to drain. Block up the access hole at the top of the base, then take the casting into the air compressor, remove the casting complete. Withdraw the seating washer, insert assembly and spring from the casting. The seating assembly must be discarded after 5,000 miles and a new one fitted. Do not attempt to clean the casting assembly.

If the head is to be removed, disconnect the pipes to the external cooler (if fitted), remove the two retaining bolts and washers and withdraw the head. If an external cooler option is fitted, a by-pass valve is fitted to the head and should be removed for cleaning by unscrewing the blank and withdrawing the valve and spring. After cleaning, ensure that the spring is not bent and that the valve operates freely in its location in the head before rejoining the valve assembly. Discard the joint ring and fit a new ring. Ensure that the joint faces are clean then refit the head, using a new joint; do not use ~~greasing compound~~. Reconnect the cooler pipes (if fitted).

Check the condition of the spring, seating washer and the joint washers for the drain plug and sleeve nut. Before refitting the insert assembly and casing, it is advisable to fill the casing with clean approved engine oil to ensure an immediate supply to the engine system when the engine is started. Check that the seating ring rests squarely on the insert assembly, then offer up the assembly and casing, and secure with the sleeve nut; tighten the nut firmly. Refit the drain plug.

INTERCOOL OIL COOLER

No external oil cooler is fitted to some Type 35 and 35A engines, and is located in a chamber on the right-hand side of the cylinder block.

It is recommended that the cooler is removed and discarded at the first available opportunity and the location blanked off. The oil cooler body must be retained and refitted, unmodified subsequently, to serve as an oil transfer block.

To avoid damaging the cylinder, withdraw the oil cooler, proceed as follows:-

1. Open the capset.
2. Remove the four 3 in. H.S.P. nuts and sprung washers, and the lower nut and its retaining washer, keeping the unit in the hands at the front of the cylinder block; withdraw the tube and washer.
3. Withdraw the oil cooler as far as possible (taking care not to damage the cylinder casting), and cut through the tube with pliers and retain the oil cooler body and the retaining portion of the tube. Leave the retaining portion of the oil cooler tube integrity withdrawing it as far as possible and again cutting through the tube.

After the cooler has been removed, carry out the following blanking operations; the blanking plate KPS.150, together with the two gauges K.36030 will be required. Proceed as follows:-

4. Hold the oil cooler body in a soft-jaw vice and remove the retaining cap and washer, followed by the relief valve retainer and the escape washer, see Fig. 12.
5. Reverse the body in the vice and remove the tube portion of tube unit from the body with a spanner applied to the flat in the tube.
6. Release the body from the vice and withdraw the relief valve, and the two oil cooler nut washers, then re-positions the body in the vice and retain the retaining cap and the washers.
7. Clean the blanking plate, take up some of the wire length, check that enough threads are available to provide full engagement with the unit. If this is not so, lightly spotface the oil cooler body unit before fitting.
8. Make sure that the joint faces of the cylinder block, blanking plate and oil cooler body are perfectly clean and dry, then complete one of the two gauges over the measuring stock, followed by the blanking plate.
9. Fit the remaining washer, the nozzle to the oil cooler body to the tube and secure with the four sprung washers and 3 in. H.S.P. nuts and the retaining washer and lower nut. The latter washer and nut should be fitted to the internal stud.




Fig. 10. Exploded internal cooler.




Fig. 11. Internal cooler valve assembly.




Fig. 12. Exploded internal air cooler assembly.




Fig. 13. Section of support plate and valve.

tighten all nuts securely and alone the hoses. It is important to make sure that the damper nut is tightened in the oil cooler body and not on the coil itself. This is a common fault and results in coil leakage.

10. Run the engine until warm thoroughly, then stop and check the tightness of the nuts.

MATERIAL AND METHODS

Description

An external oil cooler can be fitted as an after to all types of "fire-disk" cars. In all cases, it is necessary to use a "Tubular" oil filter with brackets adapted for the purpose. On all type 400, early 401, and 402 cars, it will be necessary to remove the radiator cap drill and tap four holes in the radiator side plates to receive the securing nuts-bolts of the oil cooler support brackets. In addition, on type 400 cars fitted with narrow front wing valances, the valances and the radiator side dampers will require modification. Indicators already drilled and tapped have been installed in some type 401 cars. As yet no plans have been made, when installing an external oil cooler on a type 401 car, to examine the sides of the radiator. If the holes have already been drilled, it will not be necessary to remove the radiator.

The oil cooler consists of a rectangular closely-spaced grid-shaped tube which is mounted in front of the radiator. The ends of the tube are connected by flexible rubber pipes to the engine oil filter; pressure oil from the engine pump is circulated through the cooler before passing through the filter.

Installing

The following paragraphs describe the work necessary to install the external oil cooler system. Two methods are described. The first method is applicable to all type 200 and 400 cars and to type 400 cars in which the radiator has not been drilled and tapped to receive the securing nut-bolts of the external oil cooler support jigsaw. The second method covers type 400 cars which already a radiator already drilled and tapped for the nut-bolts.

Before commencing to install the external oil cooler system in any type 400 car, first examine the radiator for the presence (see above) of four 1 in. B.S.R. holes in each side plate (see Fig. 14).

Type 400, 402 cars, and type 401 cars
with un-modified radiator

1. Remove the bonnet (see Section 14).
2. Drain the engine cooling system and remove the radiator (see Section 2).
3. Referring to Fig. 14, mark off the positions of the four holes in each radiator side plate, then drill and tap 1/4 in. D.E.F. holes.

Turning : - Due to the small clearance between the radiator side plates and the heat tank, great care must be taken when drilling the holes to prevent the drill breaking through with force and puncturing the tank.

4. Type 400 only. If the front wing valances fit closely around the radiator shell, the left and right-hand valances and the radiator side flaps/hinges must be modified to provide clearance for the oil cooler side plates. This may be done in the following manner with the component "in situ".
 - (a) Cut through the mating flanges of the left and right-hand valances and the side flap/hinges midway between the two uppermost mounting bolt locations.

- (a) Remove the four lower set-screws and snake-proof washers from each side. Flatten your release fingers forward so that they fit into the slingspares. Then flatten each slingspare flange rearwards to line with the surfaces.
 - (c) Repeat both releases and slingspares extrusion until the bolt holes in the releases align with the captive nuts and/or neck slingspares. Insert each line assembly and snake-proof washer.
3. While the radiator is removed, prepare the oil cooler for installation by assembling the right and left-hand support plates to the cooler, securing them with the four 1/2 in. B.S.F. bolts, snake-proof washers and nuts, and interposing three plastic washers between the support plates and cooler at each bolt location.
4. Remove the blanks from the oil cooler pipe connection and make sure that the diameter of the cooler is correct and undiminished by applying a smear of clean dry oil through one of the connections, then connect the two flexible pipes to the cooler connections. Secure the oil cooler temporarily in position, keeping it as far forward as possible to provide sufficient clearance when installing the radiator.
5. Refit the radiator, connecting up all relevant hoses etc., as described in Section 2, then align the bolt holes in the support brackets with the tapped holes in the sides of the radiator and secure the brackets with 4 in. B.S.F. nuts, bolts and snake-proof washers. If necessary, regulate the angle of pitch by interposing washers between the support brackets and the oil cooler to obtain correct alignment.
6. Transportive of the type, reuse the oil filter bolt complete with mounting bolts and gasket.
7. (a) If the oil filter is a "Prestolite" type, discard the unit and its mounting bolts, substituting a "Yokes" filter (see the Food catalogue or order book subsequently under (e)), complete with new mounting bolts and joints.
 - (b) If the filter unit is an early (pre-Yokes? i.e. plain band), discard the unit but retain the mounting bolts for use with the standard filter unit to be fitted as described under (e).
- (e) Fit the oil filter to the inlet "Yokes" type with a bypass valve housing and the union housing and integral with the body, remove the three blanks from the housing. Fit the bypass valve into its housing, retained by the spring, see Fig. 10, then fit the bypassing plug supplied in the modification set, together with one of the three sealing washers. Tighten the

pling naturally, then assemble the two union adapters and the two remaining sealing washers to the union housing in the head. In addition, the adapter unit K-26120D must be fitted to the union adapters if the car has left-hand drive.

10. Prime the modified filter unit (see page 30) and fit to the engine using a new joint. On right-hand drive cars, pass the two flexible oil pipes under the engine flexible mounting, then prime the cooler by pouring clean engine oil through the upper pipe until the oil comes from the lower pipe; connect the pipes to the union adapters in the oil filter head. The pipe from the oil cooler upper connection should be coupled to the union, nearest the cylinder block. On left-hand drive cars, the flexible pipes must be passed over the engine flexible mounting.
11. Make sure that all union connections are tight, then assemble the halves of the support clip around the portion of the flexible pipes immediately to the rear of the oil cooler connections. Secure the clip with a 1 in. B.B.F. bolt, slate-proof washer and nut.
12. Refit the bonnet.

Type 401 cars with modified radiator

1. Remove the bonnet (see Section 1).
2. Remove the radiator grille (see Section 2), and the stay at the top of the radiator.
3. Remove the left and right-hand centre support plates to the radiator side plates with $\frac{1}{2}$ in. B.B.F. nut-bolts and slate-proof washers.
4. Remove the blanking from the oil cooler pipe connections and make sure that the cooler is clean and unobstructed by applying a band of silicon, dry compressed air through one of the connections, then connect the two flexible pipes to the cooler.
5. manoeuvre the oil cooler, with the attached pipes, between the radiator and its shell then working through the radiator grille aperture, secure the oil cooler between the support plates with 1 in. B.B.F. bolts, slate-proof washers and nuts, interposing blank washers between the support plates and cooler at each bolt location to centralise the oil cooler.
6. Refit the radiator grille and the radiator stay.
7. Remove the "Vokes" oil filter, complete with sealing bolts and joints, from the left-hand side of the cylinder block; discard the joints.

8. (a) If the filter unit has a plastic case, bend it toward the unit, but retain the mounting bolts. For use with the modified filter unit no filter case is supplied unless (b).
(b) Purchase an oil filter in the below "Napa" type with a bypass valve housing and two upper bearings and integral with the body between the lower bearing from the bearings. Fit the bypass valve into the housing, followed by the spring, see Fig. 10 then fit the clutching plug assembly in the modification sets, together with one or three washers washers. Tighten the plug securely, then assemble the two upper supports and the two remaining and the bottom to the main bearing in the rear. In addition, the engine unit R-71726 must be fitted to the main supports. The rear has individual sites.
9. Prime the modified filter unit (see page 20) and fit to the engine, using a new gasket.
10. Go plain-end drive gear, pass the two flexible oil pipe under the engine flexible mounting. Prime the oil cooler by pouring clean engine oil through the upper pipe into the oil cooler from the lower pipe, then connect the pipe to the union adapter in the oil filter base. The pipe from the oil cooler union connection should be strapped to the union behind the engine block. On left-hand drive gear, the flexible pipes must be passed over the engine flexible mounting.
11. Make sure that all union connections are tight, then assemble the support clip around the flexible pipe. Secure immediately to the front of the oil cooler connection. Secure the clip with a 1 in. R.R.F. bolt, lock-proof nut and nut.
12. Refit the bonnet.

REMOVING AND FITTING

The method of removing the external cooler differs with the type of gear, and the following sequence is recommended. In all cases, however, disconnect the feed and return pipes from their connection at the front of the cooler, and break off the pipe ends.

Type 490 with reverse ring released

1. Drain the cooling system as described in Section 2.
2. Remove the four semi-circular top shake-proof washers which secure the cooler support plates to the radiators.

3. Remove the water pump and radiator as described in Section 2.
4. Remove and drain the cooler.

To refit the cooler, reverse the dismantling procedure, but before connecting the pipes to the filter, prime the cooler as described on page 37.

Note :- On right-hand drive cars, the pipes pass under the engine flexible mounting, and over the mounting on left-hand drive cars. The upper pipe is coupled to the filter union nearest the cylinder block.

Type 400 with side ring valances

1. Remove the radiator grille.
2. Working through the grille aperture, remove the cooler from the support plates, taking care not to lose the spacing washers.
3. manoeuvre the cooler with its attached pipes through the grille aperture.
4. Drain the cooler.

To refit the cooler, reverse the dismantling procedure, but before connecting the pipes to the filter, prime the cooler as described on page 37.

Note :- On right-hand drive cars, the pipes pass under the engine flexible mounting, and over the mounting on left-hand drive cars. The upper pipe is coupled to the filter union nearest the cylinder block.

Type 401 and 402 cars

1. Remove the radiator grille and the grille. In some cases, it may also be necessary to remove the bonnet.
2. Remove the cooler support plate completely, taking care not to lose the spacing washers.

3. Release the retaining plate from the radiator and remove the cooler with its attached pipes, disconnecting it between the radiator and shell.
4. Drain the cooler.

To refit the cooler, reverse the dismantling procedure, but before connecting the pipes to the filter, prime the cooler as described on page 37.

Note : - On right-hand drive cars, the pipes pass under the engine flexible mounting, and not the mounting on left-hand drive cars. The upper pipe is coupled to the filter union nearest the cylinder-block.

Oil Pump

Dismantling

The pump is illustrated in Fig.15. Attached at the lower end of the oil pump casting, the gear-shaft is closed by the gear-cover cover. Bearings for the gears are provided in the casting and cover. The squared end of the driving gear projecting out of the casting to receive the driving shaft.

An extension on the casting cover provides the inlet to the pump and carries a filter unit which screens the inlet. Pressure oil is discharged through a port in the pump casting which terminates in the attachment flange where the duct meets with the main oil passage in the cylinder-block.

Removing and Refitting

Drain and remove the sump as described on page 37, then release the retaining bolts, remove the two nuts and withdraw the pump, together with the driving shaft unit. Detach the driving shaft unit from the pump-driving gear and remove the joint washer from the pump casting. Remove the major,

To outfit the pump-to-the-pistons block, first fit the driving shaft unit to the driving gear, then assemble a new joint washer to the attachment flange, offer up the prop, engaging the square upper end of the driving shaft unit with the distributor drive shaft; the two attachment can screws can now lightly "lop" the retaining nuts. Turn the engine through at least one complete revolution to align the drive shaft unit and nuts in place before finally tightening the retaining nuts. Alignment is satisfactory if the end float of the drive shaft unit can be felt by hand. Lock the nuts with the lockwashers.

Brassitting

To dismantle the prop, proceed as follows:-

1. Extract the locking pins and remove the lockplate securing the drive shaft, then remove the locking plate, sleeve and sleeve cover, disassemble the two joint washers.
2. Tap the locking pins and remove the bolts securing the oil pressure casting cover, then remove the cover and withdraw the driving and driven gears.
3. Clean and dry the components, paying particular attention to the aluminums and sleeves unit.

Suspension and re-assembling

Examine the gears for condition of the teeth, then check that the journal and bearing diameters conform to the limits quoted in the General Data, and are not scored. Check also the fit of the drive shaft unit on the driven gear and verify that it is not bent or damaged. Examine the pump casting and cover for general serviceability, and that the joint washers are undamaged; check the faces with marking compound on a surface plate. If the joint faces are distorted or damaged, rectify by tapping them on alapping plate, or to each other. There

the gears have scored the engine cover, correct this by lapping on a lapping plate. Make sure that all traces of lapping compound are removed, then assemble the joint. Lubricate both in the cover and re-produce the shims if necessary. Drive any seating on the walls or set faces of the gear chamber by scraping. When this is satisfactory, fit the gears to the housing and check the alignment with a straight-edge and feeler gauge. If the adjustment is excessive, lap the mating joint face as necessary to a lapping plate. It is important that the joint faces have an all-over contact after lapping. Check the drive gears and never fit condition and cleanliness.

Ensure that all components are thoroughly clean, that lubricates the driving and driven gears and assemble them with liberal torque of gear to the pinion housing; note that the driving gear must be fitted to the housing which allows for floatation of the driving shaft axis. Next, fit the engine cover, washers and retaining screws. Then tighten the bolts evenly, not star-lock; no anchor or locking compound is used. Finally, assemble the joint washer, cover cover, another joint washer, sleeve and locking plate; retain this assembly with the two bolts, then tighten the bolts evenly and bend the ends of the plates to lock the bolt heads.

DRIVEN END

Description

The light alloy detachable cylinder head is fitted with shrink-fit, hardened valve seats and bronze valve guides. The exhaust valves, fitted on the right-hand side of the head, are the larger diameter inlet valves on the left-hand side are retained with split steel retainers and double springs. Type BBC engines are




Fig. 15. Oil pump.




Fig. 16. Cylinder head assembly with rocker box covers removed.



Fig. 17. Sequence for tightening or loosening cylinder head nuts.

fitted with variable pitch outer valve springs, being close-coiled at one end; these springs can also be used on earlier type engines. It is essential that the outer springs are fitted the correct way up, i.e. the closest-coiled end to the bottom. The overhead rockers are bushes and mounted on a spindle located on each side of the head. Each spindle is carried in seven split bearings and is located by a dowel in the front housing. A compression spring fitted between each exhaust rocker and a spindle bearing locates the rocker longitudinally. On the inlet rocker spindle, a shorter compression spring locates each pair of inlet and auxiliary rockers. The inlet rockers are operated by push rods applying a direct vertical thrust from the tappets, while a transverse thrust for the exhaust rockers is applied via a short auxiliary push rod through the auxiliary rocker mounted on the inlet rocker spindle. Thus three types of push rods are employed. The inlet rods are provided with a ball at the lower end and a cap at the upper, while the exhaust rods have the ball ends. The auxiliary rods are shorter and are fitted with the ball end towards the inlet rockers and the cap towards the exhaust rockers. Two single-piece exhaust manifolds, bolted to the right-hand side of the head each comprise three branch pipes merging into a single screened outlet. On type 85 engines, the single carburetor is attached to the head via an induction manifold. On type 85A engines, the carburetors are bolted directly to the head; on type 85C engines, the control brackets are interposed between the carburetors and the head. A water circulating pump and fan assembly is situated to the front of the cylinder head and is driven by a belt from the crankshaft pulley. The engine breather is situated on the inlet rocker box cover (front unit) and is connected by a short hose to the air filter.

Removal and refitting

Remove the bonnet as described in Section 1A. Then disconnect the negative terminal from the battery. Detach the cooling system as described in Section 2.

If carburetors are fitted, disconnect the vacuum take-off pipe, see Section 3. Detach the lower pipe and remove the body from the water pipe and cylinder. Disconnect the sparking plug lead adaptors from the plugs. Detach the Jubilee clips from the three hoses between the air filter, air filter manifold and inlet rocker box cover. Remove the two bolts and spring washers securing the air filter unit and distributor drive housing to the cylinder head and remove the filter unit, segregate the clip fitted between the drive casing and cylinder head. Detach the evaporator drive belt, fuel pipe from the distributor drive casing, and disconnect the manual ignition control from the distributor cover. Detach the low tension lead from the side of the distributor and the high tension lead from the centre of the distributor. Remove the nuts and washers securing the distributor drive casing to the cylinder head and lift away the main distributor unit drive shaft; remove the joint washer from the securing flange.

Remove the carburetors as described in Section 3.

When the carburetors have been removed, continue as follows. Disconnect and remove the oil transfer pipe from the base of the cylinder block and cylinder head. Remove the rocker box cover together with their joint washers. Fit the locking wire and insert each exhaust pipe ring nuts with the essential "U" spacer (P.P. 9053) or otherwise fitted. Remove the nuts and washers securing the exhaust manifolds to the head and remove the manifolds and gaskets. Slacken the screws adjusting and securing belts to release the tension of the fan belt, then

remove the head. Use the special spanners supplied in the tool kit to remove the fourteen cylinder head retaining nuts; these should be slackened in the sequence shown in Fig. 17. Carefully remove the cylinder head off the studs, ensuring that the push rods remain in position in the cylinder block; the rods may be damaged if caught in the head. Mark the push rods to facilitate re-assembly, then twist the rods to free them. Turn the tappet holder and withdraw it.

Warning: If the push rods are not freed, the tappet holder may be lifted out of their location in the cylinder block. This will damage several of the tappet stems.

To replace the head, proceed as follows. Lubricate both ends of the vertical push rods and fit them in their previously marked order in the cylinder block. Make sure that the rods are refitted in reverse order since they are fitted together by sleeves, and check that they are correctly in their tappet holes. Make sure that the idle and idle rods are fitted with the open end in the upper ends. Insert a new cylinder head gasket tightly with pliers and place in position over the existing studs. Hold the cylinder head firmly against the exhaust manifolds and lower the cylinder head carefully over the studs, ensuring that the vertical push rods are not bent or damaged as the head is lowered into position.

Bolt on and "clip" the twelve cylinder head retaining nuts. Next, tighten each nut one eighth of a turn at a time in the sequence shown in Fig. 17 until all the nuts are tightened firmly.

Set the engine camshafts as described on page 41.

Fit the cylinder head assembly. Tie the main manifold to the cylinder head; tighten the eight vertical pipe bolts. Fit the exhaust pipe, tightening the

ring nuts with the special "C" spanner; wire-lock securely after tightening. No gaskets are used at this joint.

Fit the belt to the engine, fan and soft pulley and adjust the tension of the belt as described in Section 2.

Re-connect the oil-transfer pipe between the rear of the cylinder block and cylinder head; tighten the union connections. Refit the carburettors as described in Section 3.

Refit the distribution valve and raise the distributor as described later in this Section under the heading "Tighten", but omitting the air filter on Type 15A engines.

Fit the washers to the cleaned oil gapped sparking plugs and fit the plugs to the cylinder head; tighten the plugs with the special spanner supplied in the tool kit, then connect the distributor R.T. lead insulators to the plugs. Connect the negative terminal to the battery.

Refit the hoses to the radiator and water pump and tighten the jubilee clips securely. Ensure that the cylinder block and radiator water taps are closed and refill the system with water.

Note:- If your booters are fitted, it will be necessary to close the drain taps and disconnect the relevant water pipes. See Section 2.

Check the valve clearances and clean the carburetors as described under the heading "Valve Clearances" and in Section 3 respectively.

After setting the valve clearances, replace the rocker covers using new joint washers and rubber seals; make sure that there is at least $3\frac{1}{2}$ in. clearance between the bearing cap and gasket at the inlet rocker cover as shown in Fig. 13. When tuning is completed, fit the air filter, ensuring that the shim behind the distributor drive casting is not displaced. Tighten the bolts securely. Refit the rubber hose between the air filter unit and manifold and secure with the Jubilee clips; replace the small tube between the air filter and breather unit on the inlet rocker cover. Ensure that the L.T. connection on the distributor does not foul the filter.

Valve clearances

The correct clearance between the rocker arms and the valve heads is most important. Valve clearances should be set to 0.002 in. (0.05 mm.) when COLD. This setting will give a clearance of approximately 0.008 in. (0.205 mm.) when the engine has attained an indicated temperature of 70°C . to 75°C .

Tune the engine with the starting handle until No. 6 inlet valve is fully open; No. 1 inlet valve will thus be fully closed. Slacken the lock-nut on No. 1 inlet valve rocker adjusting screw and, with a 0.002 in. feeler gauge inserted between the rocker and the valve head, adjust the rocker adjusting screw to the correct clearance; it should just be possible to move the feeler gauge at the correct setting. Hold the adjusting screw, tighten the lock-nut, re-tighten the nut and then remove the feeler gauge. Check the remaining valves in a similar manner; the valves open and closed positions are as follows.

Injet.		Balancé	
Valve open	Valve closed	Valve open	Valve closed
No. 6	No. 1	No. 6	No. 1
No. 5	No. 2	No. 5	No. 2
No. 4	No. 3	No. 4	No. 3
No. 3	No. 4	No. 3	No. 4
No. 2	No. 5	No. 2	No. 5
No. 1	No. 6	No. 1	No. 6

Dismantling

Remove the sprung plug using the special wrench supplied in the tool kit. Remove the valve parts as described in Section 2. Make each rocker spindle ring, then dislodge the ball and remove the ring. Holding the rockers at each end of the spindle, lift out each spindle then rotate the main rocker half a pin inserted through the hole in the end of the spindle. Mark the auxiliary push rods and remove them from the head. Compress the valve springs with the valve lifter (Part T-88,502) then remove the valve seats and release the springs. Detach the upper valve stop seating, springs, lower valve spring washers and valve; segregate these assemblies to facilitate reassembly.

The rockers are seated to facilitate reassembly. If the rockers are not interchangeable mark them with their cylinder number. Remove the temporarily fixed pins from the bottoms of the spindles and recover the components.

During the process of carbon removal, mark off all apertures in the cylinder head. Clean the valve guides with a brush to break up carbon, then polish the valves.

Temperature and transpiration

Remove the cylinder head and valve case inserts for general condition; check that all studs are correct and unbroken and trial-fit the nuts to the studs. Check the bases of the valve guides and the stems of the valves; if worn, they should be machined. The valve seating will be checked after grinding in the valves. Check the face of the cylinder head carefully, then check it with marking compound on a surface plate. An all-cover mark-up should be obtained. If necessary, lap the face lightly on a lapping plate to obtain the required surface.

Spanner tip. Please opinions for identification of the damage and check that the rocker bearings on the spindle and the bushes in the rockers are not worn; the bushes can be renewed if necessary. Check that the rocker compression springs are undamaged and that their end notches have not fractured the spacing washers. Remove the ball-end of the rocker adjusting screws for wear or file up as required. Fit the lock-nuts. There must be a good fit in the threads. Inspect the spherical ends of the rockers and push rods and check that the rods are not bent or otherwise damaged.

Examine the valve springs and their settings for fracturing and check the length of the springs when suspended to the loading tested in the "General".

After adjusting the valves to their settings in the tool, check that the "land" of the valve stands clear of the insert. If the "land" of the valve "pockets" in the insert, a new valve should be fitted or the insert cut back to restore the valve position.




Fig. 18. Sectional view of joint
construction.



Fig. 19. Adjusting valve clearance.



Fig. 20. Intake rocker assembly.

Replacing valve guides

To repair a rejected valve guide, it is suggested that the bore be drilled out to reduce the wall thickness and the guide then pressed out or removed with a stepped drift and hammer. Replacement valve guides are supplied in the standard sizes on the outside diameter up to 0.010 in. on the outside diameter. In many cases, a standard valve guide will prove satisfactory particularly if the old guide was removed carefully. Then fitting an oversize guide, is not attempting to坐着 the bore in the cylinder head by overexpansion will result. Measure the bore in the head, — the guide. The oversize valve guides to fit the interference fit listed in the "General Data". It is recommended that replacement guides are driven by the "dry-fit" process prior to fitting; when this process is adopted, the bore should provide the desired clearance with the valve stem.

Replacing rocker bushes

Rejected rocker bushes should be pressed out. After pressing the replacement bush into the rocker, trial-fit it to the spindle and, if necessary, ream to produce the required clearance.

Reassembling

Make sure that all components are clean when fitted and valve, followed by the lower valve spring seating, inner and outer valve springs and the upper spring seating. It is essential to make sure that the variable-pitch outer springs on type 627 engines are fitted correctly, i.e. close-coiled end towards.

Using the valve lifter tool 204.5027, compress the springs, then fit the valve collets and release the lifter. Insert the auxiliary push rods in their locations

With the newest ends of the rods towards the exhaust rocker, lubricate the rockers and suspension springs and fit them with their washers to the rocker spindles.

The sequence in which the rockers, springs and washers should be fitted to the rocker spindles is detailed below; in each case the sequence starts at the front end (No. 1 cylinder) of the spindle.

Front :- L.H. auxiliary rocker, thick washer, L.H. inlet rocker, two short compression springs with one per stroke interposed, R.H. inlet rocker, thick washer, R.H. and L.H. auxiliary rockers, thick washer, L.H. inlet rocker, two short compression springs with one per stroke interposed, R.H. inlet rocker, thick washer, R.H. and L.H. auxiliary rockers, thick washer, L.H. inlet rocker, two easy compression springs with two washers interposed, R.H. inlet rocker, thick washer and a R.H. auxiliary rocker (see Fig. 20).

Rearwest :- L.H. exhaust rocker, two long compression springs with two per stroke washers interposed, R.H. and L.H. exhaust rockers, two long compression springs with two per stroke washers interposed, R.H. and L.H. exhaust rockers, two long compression springs with two per stroke washers interposed and, finally, a R.H. exhaust rocker (see Fig. 21).

Fig. 22 illustrates the manner in which the assembly tool T.176895 is fitted to the exhaust-rocker assembly to assist fitting to the cylinder head.

On assembling the inlet rockers, the disposition of the arms of the tool is as follows:-




Fig. 21. Exhaust rocker spindle assembly.




Fig. 22. Exhaust rocker spindle in assembly tool.




Fig. 23. Exhaust rocker spindle assembly to head.

- Arm 1. Between the first auxiliary rocker.
- Arm 2. Between the first pair of rockers.
- Arm 3. Between the second and third auxiliary rockers.
- Arm 4. Between the second pair of rockers.
- Arm 5. Between the fourth and fifth auxiliary rockers.
- Arm 6. Between the third pair of rockers.
- Arm 7. After the sixth auxiliary rocker.

If this tool is not available, six assembly plates may be constructed finally to the dimensions shown in Fig.24 and used as shown in Fig.25 to separate the components in a similar manner. Insert the bolt in the front end of the cylinder over the dowel in the front bracket of the base that carries the assembly tool. Fit the seven rocker spacers caps and screw on the nuts; tighten the nuts evenly and firmly.

Assemble and fit the inlet rocker spindle in a similar manner.

Using new gaskets, fit the water pipe to the head as described in Section 2.

CYLINDER BLOCK

Description

The cylinder bores are bore-finished and the joint face for the head is surface-ground. Dry-type cylinder liners are fitted to later type engines. The block houses the camshaft and tappets on the left-hand side together with the bearing for the ignition driving gear.

External machined faces provide location for the oil filter, fuel pump, distributor and adjustable oil pipe relief valves.




Fig. 24. Assembly plate for rocker spindle.




Fig. 25. Showing use of assembly plates.




Fig. 26. Crankshaft assembly.

Re-boring

Supplemental piston B.901.L. and B.910 have oversize are available. It should be noted that later type RSC and all type RSC engines are fitted with cylinder liners; early type RSC and all type RS engines have no liners. Therefore, when one of the cylinder bores of the later type engines is too great to permit the fitting of the oversize piston, use liners and oversize pistons needs to be fitted. The liners are fitted in accordance with standard practice. In the case of the early engines, it will be necessary to bore out the cylinder block to fit liners and oversize pistons. After re-boring, it is recommended that the liners are bored and finish-honed to give the piston clearance quoted in the "General Data". If re-boring machine with the "Block and Cylinder" type is employed, the provision is made that boring may not be required.

After re-boring, the cylinder block should be skin-ground to make sure that the liners do not touch any of the cylinder head surfaces. It is also essential to make sure that all oil passages are completely clean. To ensure this, the passages under pressure and dry with compressed air.

SHIFTER

Description

The chrome molybdate steel shifter is supported by four short-backed, lead-tin bronze lined, rectangular anti-wearings and is nitrogen hardened all over with the exception of the front extension, which houses the thrust plate drive splasher, engine lower seal and starter box. The rear end of the shaft is flanged to accommodate the flywheel and is fitted to resist the full bearing of the gearbox drive shaft, the housing being retained in position by a screw-up.

between the flywheel attachment flange and the rear main bearing journal, an oil return thread machine in the shaft is screened by an integral oil baffle; this serves to prevent oil loss from the rear bearing. At the front end of the shaft, oil loss is prevented by an oil baffle at each side of the crankshaft drive gear assembly bolt and fitted in the base of the cover.

Bearing and retiming

Remove the gearbox and clutch units from the engine and cylinder block (described in Sections 3 and 4 respectively), then remove the engine from the chassis in the manner described later in this section and the cylinder head from the engine. Remove the starter dog and the engine driver and carrier units from the front end of the crankshaft, then remove the oil-baffles and take off the crankshaft flywheel cover, followed by the oil baffle. Release the inner bearing and remove the oil screening the crank steel to the crankshaft, then withdraw the chain-wheel and drive sprocket (complete with shaft) from the crankshaft and crankshaft. Withdraw the thrust plates. Remove the cap in the manner described subsequently then remove the set-bolts and detach the flywheel from the crankshaft.

Remove the big-end bearing caps from the connecting rods. Remove the main bearing caps in a similar manner, detach the lower halves of the thrust plates fitted to the front main bearing caps, then withdraw the crankshaft from the cylinder block. Remove the circlip then withdraw the ball bearing from the rear end of the crankshaft with the extractor 9.17766. Remove the keys from the shaft and upper halves of the thrust plates from the front bearing location. Keep the correct halves together.

When the crankshaft has been re-positioned, it should be refitted to the engine in the following manner. Using a soft metal drift, tap the ball bearing

into position on the rear side of the crankshaft. Take care to avoid tapping the inner face of the bearing or damage may result. Fit the flywheel in its groove to protect the bearing and check that the flywheel is secured fully.

Fit the correct half bearing shells to their locations in the cylinder block, ensuring that their locking surfaces are located correctly and that, if the shaft has been re-ground, they are of the correct size. Fit the upper half of each thrust plate to the recess on each side of the front main bearing location, then assemble the crankshaft to the cylinder block, fit the bearing caps complete with the correct bearing shells in the main bearing locations, fit the lower half of each thrust plate to the rear bearing cap. Tighten the bearing cap retaining nuts temporarily and fit the thrust plates, drive spanner, damper carrier bolt and washer dog to the front end of the shaft. Tighten the washer dog on the shaft, then check the shaft rotation and that the end float is within the desired limit. If the end float is incorrect, adjustment should be made by selective assembly of the front bearing thrust plates. These are available in three sizes, i.e. thickness = 0.010 in, thickness = + .005 in, thickness = -.005 in. After check has been made, remove the components from the front end of the shaft and the retaining nuts from the bearing caps. Fit a new tubular bar to each main bearing cap fitted, then refit the caps and tighten them to a torque setting of 28 to 30 lb. ft. (3,890 to 4,206 kg.). Check that the shaft will rotate freely then secure each nut with the tubular bar.

Fit the uppermain bearing shells to the big-end of the connecting rods, check that they are locked correctly, then fit the rods to the crankshaft journals so that the identification numbers face towards the crankshaft, and assemble the main end bearing caps, complete with bearing shells, to the

appropriately held. Fit a shoulder-to-push bearing cap and fit and tighten the nuts to a torque setting of 38 to 39 lb. in. (5,950 to 6,140 m. kg); secure each nut with the lockwasher.

Note:—If the big-end journals of the crankshaft have been reground, the connecting rod must be removed and checked for alignment (in the manner described subsequently in this section) before proceeding to the engine.

Refit the flywheel to the flange of the crankshaft, breaking it over the two webs and fit the three locking plates and the set-screws. Tighten the nuts bolts to a torque setting of 10 lb. in. (1,420 m. kg.), then secure them with the tabs of the locking plates. Fit the timing plate to the front end of the crankshaft, then assemble the top and drive gearsets to the crankshaft and the chain gear and key to the crankshaft, coupling with their chain. Secure the engine as detailed subsequently in this section. Fit the oil baffle to the shaft then assemble the timing cover and jets to the cylinder block and assure its positive fit with set-bolts, plain and spring washers. Fit the engine diaper and cooler units in the shaft followed by a new lockwasher and the washer ring. Tighten the washer ring and secure it with the lockwasher. Assemble the sump and cylinder head to the engine and the engine to the chassis in the manner described in this section and refit the clutch and gearbox units as described in Sections 4 and 7 respectively.

Inspection

Inspect the crankshaft for cracks with standard magnetic and ultrasonic test equipment. The ultrasonic test would be performed at 100 amperes and 150 volts. If satisfactory, check all crankshaft journals for wear, blue and

wear and ensure that any ovality is not excessive. Inspect the threads, keyways and straightness for condition and the thrust plate and ball bearing location for straightness. Mount the shaft on "V" blocks in the front and rear main bearing journals and using a dial indicator, check the alignment of the shaft. If the misalignment exceeds the maximum permitted, i.e., 0.002 in. (0.005 cm. dial reading) the shaft must be straightened. Great care must be exercised in straightening or cracks may develop in the journals. It is essential that any straightening which may be necessary be carried out before regrinding the shaft journals.

REGRINDING

Each main-bearing cap is secured to the cylinder block with two alloy-steel studs and nuts, and is located by dowels. The front main bearing cap is drilled to permit drain oil from the crankshaft drive cover to return to the sump and the rear cap is fitted with a drain pipe which directs drain oil from the rear-side of the rear main bearing to the sump. Each half of the shell-type main bearing has a locking notch which locates in a slot in the bearing cap or cylinder block location, thereby locking and preventing movement of the bearing. Three sizes of bearings are available, standard (nominal) size, 0.010 in. undersize and 0.020 in. undersize. It should be noted that the bearing shells for the two centre bearings are identical but differ from those for the front and rear bearing which also are identical to each other.

FITTING MAIN BEARINGS

When crankshaft main bearings are to be replaced it is recommended that a complete set of new bearings be fitted and that no attempt be made to fit individual bearings. Remove the old bearings from the caps and cylinder block,

ensure that their locations are clear and unchanged, then fit the new bearings into position, ensuring that the locking notches are located correctly. The bearings are supplied ready for use; never no circumstances should the caps be forced together, i.e., forced, or any over-tightening be carried out.

De-grinding

When it is necessary to re-grind either the nose or the big-end bearing journals of a crankshaft, all four main bearing journals or all the big-end bearing journals must be ground to the same size. Re-grinding individual bearing journals is not recommended. No attempt should be made to re-grind the crankshaft unless suitable re-machining facilities are available for re-milling. Where such facilities do not exist, the crankshaft should be returned to the Gas Division of the British Aeroplane Company Limited.

Warning: Do not attempt to re-grind the crankshaft if the end-clearance exceeds the permissible maximum, i.e., 0.005 in. (0.025 in. dial indicator reading), until the shaft has been straightened.

If necessary, straighten the crankshaft to a suitable press, then check and magna-flux and electro-flux test the shaft to inspect for cracks. If satisfactory, have the shaft to a suitable grinding machine and re-grind the bearing journals. Fit the bushing cap TPN 7861 to the front-end of the crankshaft so positioned that surfaces which are not to be machined, (Fig. 77 illustrates suitable blocks which may be used locally for this purpose) bear against the shaft. Heat to 450° Fahrenheit (232°C).

After heating, lightly polish all bearing journals to remove the oxide film and then re-check the alignment of the shaft. If necessary, straighten the




FIGURE 27. BLOCK (OF STEPPED PROFILE).

Fig. 27. Block (of stepped profile).




Fig. 28. Mounting ring.

shaft and repeat the alignment check. Then the alignment check after straightening is satisfactory, magna-flux and electro-flux test the shaft for cracking. Finally, make sure that all oil ports in the shaft are cleaned thoroughly.

Flywheel and starter ring

The steel starter ring is shrunk on the flywheel and the flywheel is secured to the crankshaft flange by six set-screws and locked by a lock. If the teeth of the starter ring are removable, split the ring with a chisel or drive it from the flywheel with a suitable drift and hammer. Examine the ring dovetail of the flywheel for condition and, if necessary, remove burrs or de-burring. The recommended method of fitting a replacement ring is to heat it in oil at 160°C. for at least 10 minutes, then place it in position on the flywheel and allow to cool. This operation should be completed as rapidly as possible to ensure that the ring is located correctly and does not tighten on the flywheel before it is in the correct position. The ring is machined to extremely fine limits; it is therefore necessary to re-align the flywheel unit.

Note: — It is essential that the groove in the starter ring bears smoothly on the flywheel.

Flywheel

In the event of the face of the flywheel being scored by the use of a badly worn clutch driven plate it should be lightly ground, taking off the minimum amount. The normal overall thickness of the flywheel is 1.723 and either no compensation should this dimension become less than 1.672. Then, it will be seen, that a 0.050 inch (1.27 mm) will be gained off the flywheel if this amount is used with care a number of clamping operations can take place before the flywheel is turned in position.

CONNECTING RODS AND PISTONS

Description

The all-precision "H" piston connecting rods are fitted with shell-type, steel-backed, lead-tin-lead bimetal big-end bearings and with phosphor-bronze, carbon-backed, aluminum-silicon piston pin bushings. The big-end bearings are lubricated under pressure through holes drilled in the crankshaft journals. Oil is also drilled through each connecting rod provides an intermittent supply of pressure oil to the piston pin.

The piston is of pressed aluminum alloy to S.T.D. specification T2 and taper fits the bore of the skirt on the top of the piston, the bottom skirt being 0.012 in. greater in diameter than the upper. Each piston is secured to the skirt in position as follows: an ovality of 0.0035 in. to 0.015 in. Three compression rings and one scraper ring are fitted to each piston, the top compression ring being chrome-plated all over; the remaining two are unchromed, the lower being chamfered on the upper edge. The alloy-skirt fully floating piston pin is hollow and is retained in the bore of the piston by two split pins.

Removal and fitting

If the engine has been removed from the car and its crankshaft secured, withdraw the assembly piston and connecting rod from the cylinder. Remove the oiling hole from the base of each piston, withdraw the piston pin and remove the piston and connecting rod; remove the piston rings.

If the engine is in the car, remove the cylinder and oil cup or breather in this position, then remove the big-end bearing caps. Push the connecting rods

up into the cylinder bore with the rest who located in the cylinder slots. Remove the star caps, withdraw the piston pin and detach the piston; remove the piston rings. Withdraw the connecting rods through the bottom of the cylinders.

To reassemble the connecting rods and pistons in an engine from which the crankshaft has been removed, adopt the following procedure. Heat the piston in boiling water for approximately two minutes, then fit each to the connecting rod and insert the selected gauge pin (see "Inspection"); retain the pin by fitting a wire circlip in each groove in the piston-bore. Check the gauge for a set of piston rings, then fit them to the piston; ensure that the exposed band compression ring (No. 3) is fitted with the small diameter towards the piston crown and that the skirt-piston ring is fitted to the big groove. Check the side clearances. Assemble the piston-connecting rod units to their respective cylinders with the connecting rod identification numbers facing towards the crankshaft; this will ensure correct positioning of the left-hand end of the rods. Complete the re-assembly as described in page 50 of this Section.

When the crankshaft has not been removed, ensure that all partitions have cleared to ascertain that the various dimensions will permit an assembly; then insert the connecting rods in the relevant cylinder bores with the pins located in the cylinder slots and their identification numbers facing towards the crankshaft; heat the piston plates as described previously, then fit a new set of piston rings. Push the piston down into the cylinder and locate the big-end of the connecting rods on the appropriate crankpins. Refit the bearing caps complete with bearings that keep tight and minimise the run-out. (See fig. 12, p. - 1,550 to 1,650 n.s.p.h.).

Check the side clearance of clearance of the cylinder base reasonable by pump and cylinder head units.

Preparation

Using suitable materials gradually fit the piston pin bush and the big-end of the connecting rod (without bearing fitted), mount the connecting rods, in turn, in "T" blocks and check them for wear and alignment. The maximum permissible error of alignment is 0.002 in. per six inch length of mandrel and 0.0005 in. twist per six inch length of mandrel.

The connecting rods should also be subjected to magna-flux test to guard against cracking. Check the various pin bush for wear and quality of manufacture, inspect the bush. Examine the piston pins for wear and check the pin, piston pin bush and piston body dimension to determine whether the fit of the pin will be satisfactory for reassembly.

Examine the piston for general condition. Check the clearance of a set of new rings in the ring grooves and clean the gage. Assemble the piston to the cylinder base and check that the clearance between the edge of the piston thrust shoulder, the cylinder wall is within the desired limit.

If it is not permissible to obtain the correct fit (piston pin or piston), if oversize pistons are to be fitted, or if any of the three mating parts have been rejected, replacement parts should be obtained and checked thoroughly before assembly.

Inspect the big-end bearings for condition and then bearing surfaces for damage. Assemble the bearings, reduced bearing caps to their journals and check that the running clearance on the crankshaft is satisfactory.

Replacing big-end bearings

Check that the bearing locations of the connecting rods and caps are clean and undamaged, then fit the new bearings into position, ensuring that the locking shoulders are fitted correctly. The bearings are supplied ready for use; no fitting of any sort should be carried out.

Note :- Bearings are available in three sizes : 0., standard, 0.010 in. undersize and 0.020 in. undersize. It is essential that a drive is used to ensure that only the correct bearings are fitted to the rods. Undersize bearings are buried +10 or +20 in the top of the steel shell.

Replacing engine pin bushes

Using a suitable soft metal drift, and with the small end of the connecting rod initially supported, drive out the pin from the rod cap. Ensure the rod cap is free for extraction and, if necessary, polish lightly to remove the tops of all burrs. Standard size and 0.005 oversize bushes are available. Generally speaking, standard size bushes are suitable for replacement but should the connecting rod bushes be over-standard size, the 0.005 oversize bush should be ground to suit, using the interference fit as given in the "General Data". The recommended method of fitting a replacement bush is to freeze it for a short time, then insert the bush with the oil hole aligned with the oil hole in the rod. If facilities for freezing are not available, press in the bush, using a suitable hard press and making sure that the bush is square with the axis of the rod. It is recommended that the bushed rod is set up in a softwax diamond-bushing or honing machine and the bush machined to size. Care must be taken to ensure that the rod surfaces are maintained within the specified limits and that bolt holes are absolutely parallel. Should it be impracticable to use a bearing

or running sections, a standard type universal connecting rod aligging and running jag should be used. It is essential to observe the precautions quoted above. Never running without such a jag should never be attempted. Run the bush down to the finished size, gradually rubbing the edge of the oil balm to remove sharp edges. Clean the rod thoroughly, particularly the longitudinal oil duct, then about the alignment of the rod and check the bearing clearance.

GEARBOX PINION
(0.000 in. and +0.000 in.)

Due to the very fine fit required between the gearbox pin and the bore of the pinion, all replacement pinions are supplied complete with a gearbox pin which has been selected to provide this fit. It may be necessary in some instances to replace the gearbox pin bush of the connecting rod to obtain the correct clearance between the bush and the new gearbox pin. All gearbox pinions are marked on the arms to indicate their size, e.g. +0.000 in.

CRANKSHAFT

DESCRIPTION

The crankshaft is supported in four phosphor-bronze bush bearings fitted in the cylinder block. An integral spiral gear at the center of the shaft meshes with the distributor drive gear which is mounted vertically in a bush pressed into the cylinder block, and is rotated by a wireclip fitted at its lower end. The crankshaft is secured in position by a retaining plate, a cast-iron double-track chain wheel, keyed and secured by a nut to the front-end of the shaft, engages with the timing chain driven by the crankshaft driving sprocket. The

mid-front bearing journal. Because oil groove part way round the circumference, Open jet revolution the groove links the oil feed hole in the bush with an outlet to a groove in the bush outside finOuter, thus providing the intermittent feed to the distributor drive in the distributor drive housing. The rear journal is drilled transversely to provide the intermittent feed to the rocker mechanism. It is also drilled longitudinally to enable any oil trapped behind the journal in the bush to drain back to the sump.

REMOVING AND REFITTING

Dismantle the engine in the manner described for removing the cylinder block, then remove the flywheel and withdraw the distributor and oil pump drive pinion through the distributor-drive housing aperture of the cylinder block. Remove the flywheel and remove the two set-screws securing the retaining plate and release the plates from the front-end of the camshaft. Remove the taper bushes and withdraw the camshaft from the front-end of the cylinder block.

After reconditioning, re-assemble the camshaft in the following manner. Ensure that all components are clean. Insert the camshaft, plain-end first, into the bearings of the cylinder block, and check the clearances with feeler gauges. In order to prevent the option oil pressure, it is essential that the maximum permissible clearance is not exceeded. Assemble the retaining plate over the front-end of the camshaft and secure the plate with the numbered set-screws. Fit the key and the drive wheel to the shaft and secure them with the retaining nut, then check that the end-clearance of the shaft is within the required limits and that it rotates freely in its bearings. Re-assemble the distributor and oil pump drive pinion to its bearing and mount it by fitting a new circlip to the groove in the shaft. Check that the circlip is seating

correctly in the groove and that it is free to rotate. Check that the end-clearance of the piston in the bearing and the backlash between the piston and its mating gear on the crankshaft is within the required limits. When there always have proved satisfactory, for the engine running, remove the retaining nut, main wheel hub key from the crankshaft and rebuild the engine in the manner described in this section for putting the crankshaft.

Inspection

Examine the front crankshaft journals, the pressure and spiral gear for wear, scoring and hard bearing. Check that the thrust faces of the crankshaft and the mating surface of the retaining plate are not scored excessively. Examine the bearings, keys and main wheel location for burns and damage. Mount the crankshaft in "V" blocks on its front and rear journals and, using a dial indicator, check that any misalignment indicated does not exceed the maximum permissible limit.

Inspect the journal bearings in the cylinder block. For tenacity and general condition and check the bore of each bearing and the clearance between the crankshaft journals and the bearings.

Splining bearings

Using a suitable drift, tap the rejected crankshaft bearings from the cylinder block. Clean the bearing locations and ensure that the edges are free from burrs etc. that may cause the replacement bearing to "bind" or "pick-up" during fitting. It is most important to ensure that the bearing has the correct interference fit quoted in the "General Data". The recommended method for fitting the replacement bearings is to choose them for A.T.M. planton, insert them

(bearing first), in their relevant locations and, if necessary, use a soft metal drift to tap them into position. Great care must be taken when inserting the mid-front and rear bearings to ensure that their oil holes are aligned correctly with those of the cylinder block. The larger diameter hole of the mid-front bearing must align with the oil supply hole and the smaller diameter hole with the outlet to the tachometer drive. The rear bearing should be fitted with the larger oil hole aligned with the oil feed hole in the rocker mechanism. When the bearings have been fitted, trial-fit the camshaft; in some instances it will be found to have the correct clearance without resorting to resizing. If this is the case, and it has not been necessary to replace the rear bearing, the blanking plug may be left in position. It is essential that the minimum clearance is not less than that quoted in the "General Data". It is also important that the maximum clearance is not exceeded in order to preserve the optimum oil pressure.

Under normal conditions however, it will be necessary to remove the bearings. In all cases, the blanking plug behind the rear bearing must be removed. The three main bearings a handle T.18546 or similar are mounted the numbers T.185379, T.185380, T.185381 and T.185382 for the front, mid-front, mid-rear and rear bearings respectively. Lubricate the bearings and rollers with a liberal supply of clean engine oil and insert the roller into the bearing from the front end of the cylinder block. Bear the bearing to size, maintaining rotation in the setting direction while withdrawing the roller to prevent withdrawal stresses. Bush set the cylinder block bearings and oil bearings with paraffic under pressure to remove all traces of sharp, then refit the camshaft and check the clearance of the journals in the bearings.

Note:- When removing the cylinder block, it is advisable to remove the blanking plugs from the ends of the main gallery. Replace the plugs when cleaning up is required.

If no clearance is satisfactory, screw a new blanking plug into the rear bearing and tighten by hand. To simplify this operation, the following procedure is recommended. Apply an even coating of "Hercosil 10" grease compound to the threads of the blanking plug and screw it into position in the rear bearing to within $\frac{1}{2}$ to $\frac{3}{4}$ threads of the final position. Loosen the position plug in the housing case, tighten it to within $\frac{1}{2}$ to 1 thread of its final position, apply lightly penetrating oil to the outer 180° position and complete the packing.

Firing

With the engine inverted on a building stand or back, arrange the crankshaft and crankshaft so that the bearing which bears on the chain wheels are vertically upwards. Fit the keys to the shafts, then fit the chain loosely to the chain. On later type engines, firing marks are drilled in the chain wheel; these should be aligned. Fit the flywheel and gear to the shafts and align them in the manner described earlier in this Section (fitting the crankshaft).

CYL. SET

Description

The rear alternative safety pump is fitted with two anti-seize baffles. Two square terminated steel joint washers are fitted to the rear joint faces, and the pump is secured to the cylinder block by sixteen retaining and spring washers. A drain plug is fitted in the rear left side of the base of the pump and a valve for the oil temperature thermometer is provided located on this position.

Servicing and refitting

Assuming that the engine is in position in the chassis, proceed as follows.
Remove the drain plug and drain the sump. Unscrew the wrist nut and withdraw the Chromosilic bolt from the union; take care to prevent damage to the bolt and auxiliary tube and ensure that the metal joint washer is not lost. Disengage the clutch pedal return spring from its anchorage bracket then unclip the exhaust pipe bracket plate from the gearbox bracket. Unscrew both exhaust ring nuts, detach the manifolds of the exhaust system from the chassis and lower the exhaust pipes.

Detach the torque buffer bracket, complete with buffer, from the left side of the gearbox bracket and pull the buffer clear of the buffer plate on the chassis.

Note:- If the car has a left-hand drive, the clutch spring anchorage bracket is detached as the upper buffer bracket bolt is removed.

Remove the remaining bolt securing the gearbox bracket to the clutch housing, and the four nuts which secure it in the cylinder block; detach the bracket, remove the wristnut bolt securing the gear to the cylinder block, then lower the rear end of the sump, turn it towards the rear of the car and lower it clear of the chassis.

Remove and discard the four joint washers which are secured to the sump joint faces with jetting compound.

Before refitting the sump, clean the mating joint faces of the sump and cylinder block then apply an even coating of "Hermatite" joining compound to

the snap ring. Fit a set of new joint washers to the joint faces and secure the washers fitted to the front and rear faces project approximately $\frac{1}{8}$ in. above the top surface of the joint washer on the side faces. This will ensure that a seal is maintained after the joint washer has been compressed into position. Secure a liberal quantity of grease over the upper surfaces of the joint washers, then refit the snap ring to the cylinder block and secure in position with the retaining nut-bolts and spring washers. The remaining assembly procedure is the reverse of that given for dismantling.

IGNITION SYSTEM

Description

The distributor drive casting is secured on the left-hand side of the cylinder block, at the lower end it is secured by two studs in the cylinder block, being located in a recess immediately above the distributor drive gear. It is also secured to the cylinder head with two nut-bolts.

The engine provides an integral marine air inlet pipe and for the distributor drive shaft which is located vertically by a clevis bracket with the shaft. A knotted driving dog is secured to the upturned lower end of the shaft by a driving pin, a thrust washer being interposed between the driving dog and the bearing. Immediately above the driving dog (long-shafted) driving pinion which engages with the bottom of the distributor drive shaft, which is housed in a drive hub secured into the side of the distributor drive casting. The upper end of the shaft is fitted with a knotted driving dog which is also secured to the shaft with a driving pin.

The distributor unit is fitted to the upper end of the drive shafting. The starting lever which is clamped to the body of the distributor is secured to the housing by a sprung-loaded safety retaining lever which cannot pull out.

The slotted upper end of the distributor drives gear engages with the longest helical driving gear of the shaft and the slotted upper driving gear of the driving housing of the distributor.

Distributor maintenance

General

The maintenance of this type of distributor follows similar practice,

clean and oil from the engine power cylinder, using a clean dry cloth. Periodically check the H.T. leads for condition and security in the crimp. Periodically check the H.T. leads for condition and security in the crimp.

To obtain access to the distributor rotor and contact breaker, remove both the two slips and lift away the cover, see Fig. 10. Then carrying out work on the distributor, such as adjusting the contact breaker gap, it is advisable to remove the A.P. filter to prevent contamination.

Periodically check the operation of the automatic timing device by turning the distributor rotor by hand as far as possible in the direction of rotation, then release the rotor and check that it returns smartly to its original position.

If the action is sluggish, lubricate the mechanism as directed in the next paragraph and recheck. If the action persists, remove the distributor, fit a replacement and return the damaged unit to the manufacturer for rectification.




Fig. 29. Distributor drive assembly.




Fig. 30. Distributor details.




Fig. 31. Distributor details
(rotor removed).



Fig. 32. Correct and incorrect contact faces.

Lubrication

Every 3,000 miles (5,000 kilometers), remove the moulded cover, lift off the distributor rotor and lubricate the cam bearing and distributor shaft by injecting 3 or 4 drops of approved oil through the hole in the top of the rotor spindle. Apply a similar quantity of oil through the two clearance holes in the contact breaker bearing pins to lubricate the automatic timing control, then refit the rotor.

Periodically remove the contact breaker layer and apply a smear of grease to the pivot pin, wait the time and wipe off any excess grease. Finally, apply a smear of approved grease or engine oil to the cam surface.

Note:- Great care must be taken to make sure that oil and grease do not come into contact with the contact breaker contacts.

Make sure that the carbon brush in the moulded distributor cover is free in its holder and that the interior of the cover is perfectly clean and dry before refitting the cover.

Cleaning contact breaker

Since the "Triplex 2 Litre" can be a high-performance engine, it is essential that the contact breaker gaps are not accidentally set and that the contacts are maintained parallel and flat and in a clean condition.

Every 3,000 miles (5,000 kilometers) examine the contacts. If they are burned or blackened, clean them in the following manner.

Turn the crankshaft with the starting handle until the contacts are clean, disconnect the L.T. lead at the terminal on the side of the distributor, and

Slacken the terminal lock-out ("A" in Fig. 31) in order to release the top of the contact breaker spring "C", then lift the fibre rocker off its pivot point. An insulating washer is fitted beneath the rocker; take care not to lose this washer. The spring is caused to slide upwards from the journal block and will be withdrawn with the rocker. Use an "India" or fine "Cronquist" wire to clean the contacts, taking care to keep the contacts free perfectly dry, see Fig. 32. Clean away all traces of abrasive powder with a petrol saturated cloth. Once again the lower spring ("B" in Fig. 31) can be withdrawn and cleaned but no all-over clean is made.

If necessary, remove the contact breaker assembly from the engine, make sure that the contacts are absolutely clean, then dislodge the pivot pin, pull the contact breaker lever, engage the lower spring with the terminal fitting and tighten the terminal lock-out. Re-align the G.T. lever.

Booking contact breaker gap.

After cleaning, reset the contact breaker gap in the following manner. The correct gap setting is 0.012 in. (0.301 mm.) and must be checked with a perfectly clean Feeler gauge. First turn the crankshaft until the contacts are open fully, then slacken the two contact plate securing screws ("E" in Fig. 31). Move the plate about its axis until the feeler gauge is a good sliding fit between the contacts. Tighten the two screws and ~~lock them with lock-wire~~; renew if necessary.

Reassembly.

It is permissible to fit replacement contact breaker plates and washers. The distributor should however, be removed and returned to the manufacturer for

register if any serious defect such as failure of the automatic timing device, is indicated.

Replacing contact-breaker

The ordering number of a replacement contact-breaker set is 1600-20700. First remove the bottom cover of the distributor and detach the rotor. Detach the L.T. lead from the terminal on the side of the housing, then slacken the terminal locknut "A" (in Fig. 1) in order to release the end of the contact-breaker spring "C", then lift the fibre washer off the pivot point. An insulating washer is fitted beneath the washer; take care not to lose this washer. The spring is slotted, so always withdraw it from the terminal block and will be accurate with the washer. Detach and remove the two wires ("B" in Fig. 2), taking care not to snap the insulator, then pull out the fixed contact plate ("D").

Make sure that the contacts of the replacement set are perfectly clean, then fit the fixed contact plate unit in position, leaving the contact hole over the fibre spring, with loosely the two screws "D" and "E" above. Apply a smear of approved grease to the contact lever pivot pin and to the set, then fit the lever, engage the spring in the terminal housing and tighten the bolt.

Connect the L.T. lead to the terminal, (see on the contact-breaker page as described in page 7).

Replacing condenser

The ordering number of a replacement condenser is 1600-20702. First remove the bottom cover and lift off the rotor. Disconnect the L.T. lead from the base of the condenser. Remove the cover and subsequent washer covering the

sophomore to the contact breaker base plate and lift away the condenser with the attached mounting bracket. Leave the replacement unit in position, covered with the wire and gauze cloth washer, that insulates the L.T. wiring lead. Set the distributor ratio, followed by the ignition timer.

Reversing and refitting distributor and drive

Disconnect the air-bolts securing the air filter and distributor drive housing to the cylinder block then remove the two clips and remove the air filter. This must not be done on this fitted before the engine starting charge.

Remove the distributor cover. Ground the starting lever push-pull and remove the distributor. Disconnect the small drive-shaft control from the starting lever, then remove the shoulder-screw, spring and washer and remove the lever from the casting. Disconnect the distributor flexible drive from the rear side of the distributor-drive casting, and the oil feed pipe from its union body at the front side of the casting. Remove the distributor-drive body complete with its drive shaft and joint washer from the drive casting. Tap out the drive pin and remove the driving dog and thrust washer from the lower end of the distributor-drive shaft, then withdraw the shaft from the upper end of the casting. Tap out the drive pin and remove the upper driving dog from the shaft.

The assembly may be rebuilt and refitted by reversing the foregoing operations but the fit of the shaft in the casting and body and the backlash of the driving gears should be checked to the limits quoted in the list of "General Data". If necessary, the backlash should be adjusted by selecting a thrust washer of suitable thickness.

Ignition Timing

Remove the cover from the distributor, the central rocker box cover, the front inlet rocker box cover, and the sparking plugs from the cylinders. Move the distributor advancing lever to the full retarded position, then turn the crankshaft until No. 1 piston is at 1° before top dead centre on the compression stroke. Adjust the distributor body so that, with the engine in this position, the contact breaker points are just opening and the rotor arm is aligned with the electrode supplying No. 1 F.T. lead. Tighten the advancing lever pinch-bolt on the distributor body to retain this setting. Defit the sparking plug, extract the lead, then pull the rocker box covers and the distributor lead.

Note:- If the engine has been dismantled completely and the distributor drive gear and its setting ring on the crankshaft have been disengaged, it may be necessary to re-position the leads in the distributor cover.

An ignition timing check to obtain the optimum setting should be carried out with the engine running on a test bed or when the car is on the road. The test bed procedure is to advance the ignition progressively until the engine just commences to "ping" when running at 1,500 r.p.m. and at full throttle. All "pinking" should stop on increasing the engine speed to 3,000 r.p.m. These conditions may be obtained when testing the car, if carried out on a suitably steep gradient. When the ignition setting has been obtained, tighten the advancing lever pinch-bolt securely.

Sparkling plug

The special spark plug (No. R.6000H) supplied in the car tool kit for removing and fitting the spark plugs is fitted with a rubber lined steel grip (or boot)

of the plug, thereby facilitating removal and fitting. Remove the leads and insulation caps from the plug and hold the scanner so that no undue strain is imposed upon the insulation body of the plug during removal or fitting. All plugs should be removed, cleaned, the gas cleaning, tested and, if necessary, retest at least once every 1,000 miles (5,000 kilometers).

SEPARATE SYSTEM

Two exhaust manifolds are fitted to the cylinder bank with manifold cover flange cylinders can communicate in a single-coupled system. These manifolds are common to all engine types. The exhaust pipe-system consists, in general, of several types; a brief description of each type follows.

Bent-type (BC)

A two-piece system. The forward unit has twin pipes which merge the manifold. These merge into a single pipe which is welded to the outlet section "Bent-type" exhaust fitted in series. The outlet from the second "Bent-type" connects with the tail-pipe which is cranked to pass over the rear shroud. This system is more complexly redundant, and is replaceable only by a complete "Bent-type" system as fitted to all other types of engines.

Linear-type (BD)

A three-piece system comprising down-pipe unit, centre unit and tail-pipe unit. The down-pipe unit has twin pipes which merge the manifolds and which merge into a single pipe which is coupled to the centre unit by a plug-weld. The centre unit incorporates a large fixed or small section "Bent-type" elbow; the outlet is coupled to centre with the tail-pipe unit which is cranked to pass over the rear-shroud and incorporate a small cast-section "Bent-type" elbow.

**Pro-protection type 401 and 402
(case 1 to 10)**

Prototype exhaust system which have not been standardized were fitted to these units. In the event of replacement or change, the waste exhaust system should be replaced by the true entry exhaust system.

**Early protection type 401 and 402
(case 11 to 20)**

A four-pipe system comprising dose pipe unit, centre section unit, tail-pipe unit and a tail-pipe extension. The dose pipe unit is as fitted to the later type 400 units. The centre section unit has a large single-entry evaluation "Durasol" silencer with four pipes terminating in the tail-pipe unit which is treated to pass over the rear rail. An extension pipe is fitted in the front of the tail-pipe. In the event of replacement or change, the waste exhaust system should be replaced by the true entry exhaust system.

**Later protection type 401 and 402
(case 21 to 125)**

This system has separate dose pipes which connect with a double-entry, single-section, eval-silencer "Durasol" silencer fitted in the centre section unit. The rear pipe of the centre section unit connects with the tail-pipe unit which is treated to pass over the rear rail. In addition there is fitted to the rear end of the tail pipe.

**Latest protection type 403
(case 126 onwards)**

This system is similar to the previous one but has a new type tail-pipe which passes beneath the rear rail. No extension pipe is fitted.




Fig. 3. The Thurston system.




Fig. 36. Magnets and pins.

REMOVING AND TRANSPORTING THE ENGINE

The recommended procedure for removing the engine is as follows:

Type 400 carb.

1. Remove the exhaust as the owner described in Chapter 14.
2. Disconnect the lead from the battery.
3. Drain the water from the cooling system (See Service 1).
4. Drain the water by removing the drain plug from the rear left-hand side of the pump.
5. Remove the air filter. This will improve accessibility.
6. If the engine is fitted with 3 S.U. carburetors, disconnect the leads from the repeat air valve, the starter connection, fuel shutoff.
7. Remove the oil filter. If an external oil cooler is fitted, disconnect the pipes from the filter head.
8. Disconnect the cables from the flywheel, then remove the flywheel and the fan belt.
9. Remove the radiator hoses. If a fan motor is fitted, disconnect and remove the motor pipe. On type 10 engines, disconnect the pipe from the radiator base to the insertion multi-fold jacket. Put a suitable metal plate against the rear face of the radiator to prevent damage during the subsequent transportation.
10. Remove the water pump.
11. Turn off the petrol tank then disconnect the fuel pipe from the petrol pump.
12. Disconnect the distributor drive from the distributor drive body in the distributor drive casting.
13. Disconnect the L.V. and R.V. leads from the coil in the distributor.
14. Disconnect the ignition control rod.
15. Remove the oil separator tank and strap it carefully on the chassis, with its flexible tube, to prevent damage.

16. Disconnect the oil pressure gauge pipe.
17. Unscrew bolt, exhaust man pipe ring nuts using the "C" spanner 1785, 1050 and remove the nut and bolt securing the exhaust pipe bracket to the manibus bracket.
18. Disconnect the throttle and auxiliary controls.
19. Remove the water thermometer bulb and store it carefully in the chassis, with its capillary tube, to prevent damage.
20. Disconnect the starter cable and remove the starter.
21. Remove the front unit and floor covering (see Section 14).
22. Detach the clutch, brake and accelerator pedals from their levers.
23. Remove the floorboards, dashboard and gearbox control console.
24. Release the clutch return spring from the anchorage bolt, then disconnect the clutch operating rod from the clutch lever and Pedal lever.
25. Disconnect the tachometer cable and the current limit string from the gearbox.
26. Fit the engine lifting sling, No. 178.500, in a position arranged at a convenient height above the engine. Then pass the free end of the front (long) lifting cable around the front end of the crankshaft, between the driving pulley and the sunplate drive cover, and hook it in the front ring of the lifting sling. Pass the free end of the rear (long) lifting cable around the engine, between the sump and gearbox bracket and connect its hook to the rear ring of the sling, see Fig. 16.
27. Raise the vehicle until the weight of the engine is taken on the cables.
28. Disconnect the gearbox shaft at its joint with the front universal coupling.
29. Remove the nuts and bolts securing the gearbox extension to the rear mounting units.
30. Remove the mounting units from the chassis cross-member.
31. Remove the nut-bolts and nuts and bolts securing the flywheel casting to the engine; detach the starting and tachometer cable clips.
32. Carefully move the gearbox assembly towards to form the outer casting joint with the engine, then remove the assembly from the chassis.

16. Note:- Check that the clutch seating bearing domes are seated in the clutch joint hub of the engine.
17. Remove the nuts/bolts and detach the clutch assembly as described in Section 4.
 18. Remove the nuts and bolts securing the front mounting walls to the chassis.
 19. Lower the engine carefully from the car and remove it to a safe location. It may be required if the radiator retaining nuts are slackened sufficiently to permit forward movement of the radiator. This is not possible if shatter resistant is fitted to the radiator.
 20. Lower the engine into an engine stand or, if this is not available, on to wooden support blocks. No blocks will prevent damage to the sump.
 21. Remove the flywheel assembly.
 22. If work is not to be performed on the engine or gearbox assembly immediately, cover all exposed parts and tools with all purpose tape to prevent the ingress of foreign matter.

Type 200 and 200-2000

1. Detach the bonnet as described in Section 14.
2. Disconnect the lead from the battery.
3. Drain the water from the cooling system (see Section 8).
4. Drain the sump by removing the drain plug from the rear left-hand side of the sump.
5. Remove the air filter; this will improve accessibility.
6. If an external oil cooler is fitted, disconnect its pipes from the head of the oil filter.
7. Disconnect the hoses from the dynamo, then slacken the dynamo mounting and adjusting bolts, press the dynamo toward the cylinder block as far as possible, and detach and remove the fan belt. Tighten the dynamo bolts.
8. Remove the radiator hoses. If no hoses are fitted, disconnect and remove the header pipe.
9. Turn off the petrol tank and disconnect the feed pipe from the petrol pump.

10. Disconnect the tachometer cable from the tachometer drive body in the distributor driven housing.
11. Disconnect the L.P. and R.T. leads from the coil to the distributor.
12. Disconnect the ignition central rod.
13. Remove the A/C evaporator bulb and pipe it carefully in the chassis, with its capillary tube, to prevent damage.
14. Disconnect the oil pressure gauge pipe.
15. Unscrew both retaining nuts plus ring bolt using the "E" spanner TPK 1050 and remove the nut and bolt securing the exhaust pipe bracket to the gearbox bracket.
16. Disconnect the thermal and mixture controls.
17. Remove the main transmission bolt and then fit it carefully in the chassis, with the supporting tube, to prevent damage.
18. Disconnect the cables from the electrics.
19. Remove the front seats and floor covering (see Section 16).
20. Detach the clutch, brake and accelerator pedals from their levers.
21. Remove the floorboards, carburettor and gearbox covers.
22. Disengage the idler return spring from the anchorage bolt, then disconnect the clutch operating rod from the clutch lever and datum plate.
23. Disconnect the tachometer drive and the reverse light wiring from the gearbox.
24. Fit the engine lifting sling, Sec. 293, No. 3, so it is arranged at a convenient height above the engine, thus passing the free end of the front (short) lifting cable around the front end of the distributor, between the driving pulley and the clutch cover cover, and back it to the front ring of the lifting sling. Pass the free end of the rear (long) lifting cable around the engine, between the gear and gearbox bracket, and connect it back to the rear ring of the sling, see Fig. 86.
25. Raise the body until the weight of the engine is taken on the sling.

26. Remove the stay from the top of the radiator and slacken the two radiators retaining nuts sufficiently to permit the radiator to be tilted forward. Fit a suitable metal plate against the rear face of the radiator to prevent damage during the subsequent operations.
27. Disconnect the gearbox shaft at the joint with the input universal coupling.
28. Remove the nuts and bolts securing the gearbox assembly to the two rear mounting seats.
29. Remove the mounting bolts from the gearbox cover-plate.
30. Remove the nuts and setts securing the clutch housing to the engine; detach the clutch and transmission input slips.
31. Have the gearbox assembly carefully removed carefully to below the clutch housing joint with the engine, but support the gearbox from the chassis.

Note:- Check that the nuts and bolts securing gearbox are secure at the shaft joint face of the engine.

32. Remove the nuts and bolts securing the front mounting bolts to the chassis.
33. Remove the engine carefully from the car, disconnecting it to other connections.
34. Lower the engine into an engine stand so, if this is not available, sit in wooden blocks; the blocks will prevent damage to the base.
35. Remove the lifting equipment.
36. If work is not to be performed on the engine or gearbox immediately, cover all exposed portions and blank off all apertures to prevent the ingress of foreign matter.

To install the engine, reverse the removal procedure. After re-connecting the controls etc., check their range and adjustment as described in the relevant sections.

ROUTINE TUNE-UP

Before taking complete charge of a engine, inspecting and adjusting operations damage to bring the performance of the engine to the extreme.

The following paragraphs outline the necessary operations, and it is recommended that they are carried out in the sequence in which they appear to make sure that no points are omitted. Only brief instructions are given; refer to the relevant Sections for full details of the operations.

General

1. Blow all carbon material out of the bores between the inlet and exhaust ports and base of the cylinder head with compressed air.
2. Check over the engine for signs of oil leakage.
3. Check the tightness of all major connections and fittings of pipe.
4. Adjust the fuel controls as directed in Section 2.
5. Check the cylinder head retaining nuts for tightness, see page 65.
6. Check the regular combustion.

Sparking plugs

1. Disconnected the H.V. leads and remove the sparking plugs (see page 61).
2. Check that the correct make and type of plug is being used.
3. Clean the plugs, smooth the electrodes for uniformity, and the insulation from cracks and/or chipping. If the latter is observed, discard the plug and fit a new one.
4. If the sparking plugs appear to be satisfactory, adjust the gaps to the dimensions quoted in the "General Data", but if not, if unsatisfactory, refit to the cylinder head.

Battery

Check the electrolyte level and "top-up" if necessary.

Electrical connections and cables

1. Check the battery "earth" cables and the battery-to-starter solenoid cable for cleanliness and security of their connections.
2. Examine the H.T. cables and the distributor-to-cylinder cable for condition. If the insulated covering is badly cracked or frayed, fit replacement cable(s).
3. If the cables are in a satisfactory condition, disconnect each cable, in turn, at the distributor rotor and clean the cable terminals and contacts. Check that the moulded H.T. cable ends are not cracked, and that the cables are secure in the cans before reconnecting to the distributor.
4. Check the distributor-to-cylinder H.T. cable connection for security.

Distributor

1. Remove the distributor cover and wipe the interior with a clean dry cloth. Check the cover for cracks and the electrodes for signs of burning. Check that the central carbon brush is not worn rapidly, and that it is free in the holder.
2. Examine the rotor for freedom from cracks and burning of the electrodes; fit a replacement if defective. Check the operation of the automatic advance and retard mechanism.
3. Check the condition of the contact breaker and if the contacts are worn excessively, fit a new contact breaker set as described in page 79. If the contacts are serviceable, clean and adjust them as described in pages 77 and 78.
4. Check the security of the condenser terminal connection.

Valve lifter clearance

1. Remove the rocker covers and inspect the valve operating mechanism for cracked valve spring seats.
2. Set the rocker clearance to 0.002 in. (0.05 mm.) FULL, then refit the rocker covers.

Curbside(s)

1. Remove, clean and refit the air filter element as described under "Air Filter" in Section 3.
2. Remove and clean the fuel pump body and assembly. Check the operation of the diaphragm unit before refitting the unit.
3. Remove the carburetor and carburetor bonnet for evidence of leakage.
4. Adjust the carburetor(s) following the relevant procedure given in Section 3.


REVISED MARCH

Lack of power...	Poor quality fuel. Overheating - see Section 2. Low compression. Insufficient ignition. Carburetor(s) dirty and/or maladjusted, see Section 3. Air cleaner restricted. Incorrect grade of oil. Restriction in exhaust system.
Low compression	Valves seating incorrectly, incorrect camshaft clearance, valves sticking open. Camshaft and piston seating pistons broken or worn, valve springs weak or broken. Thermostatic valve failing. Piston rings broken, worn or stuck. Piston ring grooves worn.
Excessive cylinder and piston wear	Incorrect grade of oil. Lack of oil. Dirty oil. Overheating - see Section 2. Piston rings seated incorrectly. Piston rings broken or stuck in grooves. Fuel mixture too rich.


Crankshaft main bearing or connecting rod bearing failure.	... Lack of oil. Low oil pressure. Incorrect grade of oil. Restricted oil supply to bearing. Bearing shell loose or fitted incorrectly. Bearing journal scored or worn out.
Incorrect valves and seats.	... Incorrect seat clearance, Weak or broken valve springs, Incorrect valve timing, Valve sticking in guides, Valve seating too narrow, Excessive carbon deposits around seats and valve heads, Mixture strength too weak, see Section 3, Direction 1, see Section 2.
Sticking valves.	... Incorrect seat clearance, Insufficient clearance between valve stem and guide (after replacement), Valve springs weak or broken, Valve stems scored or dirty, Valve sticking or seized (after re-lubricating), Use of poor-quality fuel with high gum content.
Overheating.	... See "Cylinder System" - Section 2, Incorrect ignition, Mixture strength too weak, see Section 3, Air filter restricted, see Section 3, Incorrect grade of oil, Incorrect valve timing.
Knocking oil consumption.	... Oil level too high, Oil leaks at joints and seats, Incorrect oil pressure, Incorrect grade of oil, Cylinder liner worn or scored excessively, Overheating, see Section 2, Piston rings broken, worn or cracked in process, Piston rings fitted incorrectly, Crankshaft and/or connecting rod bearing rings worn.

Low oil pressure	Incorrect grade of oil. Oil pressure relief valve stuck. Oil pump safety valve plugged. Maindrive main bearing and connecting rod bearing clearance. Oil pump worn excessively.
Tapping, spitting back and "pinking"	Incorrect ignition. Carburator(s) adjusted incorrectly, too lean. Insufficient tappet clearance. Excessive carbon deposits in combustion chambers. Weak or broken valve springs. Oil seat in cylinder head, usually caused by clogged valve passage. Valve seating incorrectly. Incorrect valve timing. Tappet and rings in poor condition. Poor quality fuel. Insecure type, mal-adjusted or defective operating plugs.

SPECIAL TOOLS




CYLINDER HEAD REMOVAL



2 SPANNER FOR EXHAUST NUT T-68 1030

ITEM	DESCRIPTION	QTY	MANUFACTURER
1	SWING	1	M.T.B.
2	SWING BAR	1	M.T.B.
3	SWING	1	M.T.B.
4	SWING	1	M.T.B.
5	SWING BAR	1	M.T.B.
6	SWING BAR	1	M.T.B.
7	SWING BAR	1	M.T.B.
8	SWING BAR	1	M.T.B.

SPECIAL TOOLS



REAMER FOR CAMSHAFT BUSHES T-185379-80-81-82

SPPH&T9913




Microsoft TestLab 10




www.Tutor.com

100% COMPLETE
INTEGRATE BY BUILDING




WVU SPRINGS LETTER T.F.M. 9021



ALL PLATELINES ARE IN THE U.S.A., CANADA AND GERMANY. OVER 1000 MODELS
WITHOUT EXCEPTIVE PRICE. NO. OF PLATES: 1000-100000 PLATES. 100% EX-
PORT. 100% EXPORT. 100% EXPORT.

EXTRACTION FOR CRACKSHAFF BILL NUMBER 17316

SPECIAL TOPICS




Walter T. Weller 203

www.ijerph.com

ITEM	DESCRIPTION	QUANTITY	MANUFACTURER	ITEM	DESCRIPTION	QUANTITY	MANUFACTURER
1	BLADE	1	WILSON TOOLS	9	SCREW WRENCH	2	ML
2	L.FITAC ADK	1	ML	10	FLY BOLT	3	ML
3	ADT'S SCRE	1	ML	11	SCREWDRIVER SET	1	ML
4	ADT'S SCRE	1	ML	12	SCREW	2	ML
5	SCREW	2	ML	13	SCREW	1	ML
6	L.H.C	1	ML	14	SCREW	1	ML
7	L.H.S	1	ML				


CAR ENGINE SWING TRAIL 5020

SPECIAL TOOLS



REASONABLE BRIEFING OF THE TEAM BY THE FOLLOWING CHECKLIST, P.T. FROM TIME 0-10
NOT PRACTICABLE DUE TO THE NATURE OF THE MISSION
OR THE NEED FOR SECURITY AND CONFIDENTIALITY.

ITEM	DESCRIPTION	PER CENT	PERIOD
1	100%	100	1970
2	100% OF P	100	1970
3	100% OF P	100	1970
4	100% OF P	100	1970
5	100% OF P	100	1970
6	100% OF P	100	1970
7	100% OF P	100	1970
8	100% OF P	100	1970



WORKSHOP MANUAL

Section 2:

Bulletin No. 2

Subject:

DEPARTMENT OF DEFENSE

US SPECIAL DIVISION ONLY

Due to carburetor conversion (see Bulletin 2, Bulletin No. 1), type 35 and 36A engines may be fitted with three Solex 32 III carburetors. It must be noted that this conversion does not change the engine type.



WORKSHOP MANUAL

Section No. 1

Bulletin No. 2

Subject:

REMOVAL OF STRIPPED THREAD IN DRAIN PLUG

LOCATION:

EXTRODUCTS

1. There is a tendency to strip the threads in the admission step due to constant reworking of the nose drain plug. This does not necessarily mean a new step; it can be re-threaded in position by a person given halfinch. Alternatively another step can be supplied at a replacement charge.
2. To salvage the damaged area, the following tools and parts will be required:-

Item No.	Facilities.	Description	No. Required.
1	-	Twist drill, 0.6718 in. (17.06 mm.)	1
2	TPH. 8237	Tap	1
3	8.513490.1	Wire insert.	1

The special tap may be purchased from the Services Department, Car Division, The Bristol Aeroplane Company Limited, or can be obtained on loan from the Company.

PROCEDURE FOR RE-THREADING THE DRAIN PLUG TUBE

IN POSITION OF THE ENGINE

3. (1) Drain the engine sump, if necessary raising the right-hand front end of the car to facilitate complete drainage.
- (2) Raise the car on a hoist or ramp, or position it over a pit.
- (3) Fill the bottom of the drill (see 1 above) with stiff grease and carefully drill out the drain plug orifice. If necessary withdraw the drill at frequent intervals and clear away any loose stuff. Do not allow water to enter the tank.

- 2 -

- (4) Fill the fluting of the cap (item 2 above) with stiff grease and tap-cut the hole. Ensure that the cap is at right angles to the face of the hole in both planes. Withdraw the cap at frequent intervals and clean away any loose metal. Do not allow dust to enter the sump.

- (5) Inspect through the hole and remove any loose particles which may have entered the sump.

- (6) Enter the wire insert (item 3) ~~into the first~~ into the first thread of the hole just tapped then, with suitable pliers grip the tongue near its root and carefully draw down until the last coil of the insert is just clear of the surrounding base.

Caution 2:- When doing so the insert cannot be unscreamed, make sure therefore that all threads are clean and free from any obstruction.

- (7) Finally break off the tongue of the insert, which is provided, to facilitate a clean break.

- (8) Screw in the drain plug and tighten securely. Lower the car, or remove from the pit and refill the sump with an approved brand and grade of oil to the correct level.

4. If the sump has to be removed, the re-threading can be carried out more satisfactorily.

REPLACEMENT SUMP

5. This can be obtained through a "Bristol" Distributor or direct from the Service Department, Car Division, The Bristol Aeroplane Company Limited.



WORKSHOP MANUAL

Page 10 of 11

• 11 of 11 • Page 15

Page 10

第十一章 项目管理

TYPE 403 CAB

The Type 603 was to fitted with a Type 100A engine, the major difference between the Type 100B and the Type 500 engines involving the following modifications:

- | | | | |
|-----------------------------|-----------------------|----|---------------|
| 1. | Cylinder head. | A. | Overhaul kit. |
| 2. | Exhaust. | B. | Oil pump. |
| 3. | Push rods and levers. | C. | Oil ring. |
| 7. Engine breathing system. | | | |

With the exception therefore of the information given in this Bulletin, Section 1 of the manual applies also to the Type 100A engine. With the introduction of the Type 100A engine the correction factors on the rear dashboard are being changed.

卷之三

Maximum R.R.P.	100 at 3,000 r.p.m. C101,287 cu. in. approx.).
Weight of engine-less gearbox	360 lbs. (163.5 kg.).
P.H. pump	Positive Displacement type.
Oil filter	Tolson "Ball-Flo".
Sump capacity	12 quarts (4.5 liters).

Cylinder head

Valve timing

Intake open...	140°	before top-dead-centre.
Intake closed...	120°	after bottom-dead-centre.
Exhaust open...	140°	before bottom-dead-centre.
Exhaust closed...	100°	after top-dead-centre.

Crankshaft

Main bearing journal diameter (new)	113.5 mm	(4.4605 in.)
	113.562 mm	(4.4610 in.)
Main bearing journal diameter (after 1st regrip)	113.561 mm	(4.4609 in.)
	113.563 mm	(4.4611 in.)
Main bearing journal diameter (after 2nd regrip)	113.565 mm	(4.4609 in.)
	113.564 mm	(4.4610 in.)
Torque limit of balance weight bolts	150	to 200 lb. ft.

Camshaft

Camshaft lift	11.0 mm	(0.43372 in.)
	11.5 mm	(0.45315 in.)

Timing system

Magnitude	144°	at 1,000 r.p.m.	100° at 1,000 r.p.m.
Maximum advance range	110°	at 1,000 r.p.m.	0° to 19°
Advanced lag time	110°	at 1,000 r.p.m.	220 r.p.m. (idle speed)
Advanced rate	110°	at 1,000 r.p.m.	2,600 r.p.m. (idle speed)
Burning point	110°	at 1,000 r.p.m.	100, 120, 140

CYLINDER HEAD

The cylinder head incorporates the following differences from the Type 550 head:

1. Larger diameter intake valves.
2. Lightened base plate when operating with lightened supports and suspended rocker adjusting screws.
3. A base cylinder placket, which can be identified by the embossed name and date of the cylinder-bore supplier.

CRANKSHAFT

The main bearing journal diameters have been increased from 2 1/8, 3 1/8, 3 1/2, 4 1/8, 5 1/8 and bearing journal diameters remain unchanged.

Separate balance weights are fitted to the crankshaft webs; each weighing 1.1 lb therefore necessary to remove the balance weights. Until such time that they are surplus for service, these weights, when the engine is running, add to the torque loading specified in the General Data at the beginning of this Bulletin.

Compensator bearings are available 0.010 in. and 0.020 in. undersize; compensated bearings more than 0.020 in. undersize are not supplied.

CRANKCASE

With the exception that the ears are profiled to give the greater lift listed in the General Data, this casecast is identical to that of the Type 550 engine.

LUBRICATION SYSTEM

This system (which is illustrated diagrammatically in Figs. 1 and 2) is identical with that of the Type 620 engine with the exception that excess oil from the pressure relief valve returns to the inlet side of the oil pump via a return duct in the pump body.

OIL PUMP

Description

The pump is a positive displacement type and is illustrated in Fig. 3. The pump cylinder contains an inner and outer race; the inner race being pinned to the spindle which has a curved and projecting centrally sprung from the body to engage the pump driving shaft. A delivery duct in the body links the discharge side of the pump with the pump body attachment flange, while a return duct links the return outlet of the pressure relief valve in the side of the cylinder block with the inlet side of the pump.

Disassembly

To disassemble the pump proceed as follows:

1. Release the tabs of the locking plate, remove the two set-screws securing the sleeve unit, then remove the locking plate, sleeve and sleeve unit. Discard the ten-joint washers.
2. Oil the locking wire, pass the set-screws securing the pump cover then remove the cover and withdraw the inner and outer races.
3. Clean and dry the components paying particular attention to the sleeve and sleeve unit.

Re-assembling

Make sure that all components are scrupulously clean, then lubricate the outer rotor and assemble it to the body. chamfered edges inward. Lubricate the inner rotor and fit it to the outer rotor, with the squared end of the spindle projecting through the body. Fit the pump cover and secure with the set-screws and plain washers. Turn the pump for freedom of rotation. If the pump is tight, release the set-screws, reposition the cover slightly on the bolts, then re-tighten and re-test.

This will be satisfactory if no leak the cover.

Note: No grease or sealing compound is used on the pump face.

Finally re-assemble the jack-riser, nuts over, another John Walker, sleeve and locking plate, and secure this unit with the two set-screws. Tighten the bolts and bend the ends of the plates to lock the heads.

SUMP

Description

The lower portion of the sump is "stepped" to provide greater capacity and a flange attachment is provided on the left-hand "wing" to accommodate the breather pipe oil return line. A single anti-surge baffle, joined at its centre line by four multi-headed screws and captive nuts, is fitted inside the sump.

Removing and refitting

Assuming that the engine is in the chassis, proceed as follows referring to Fig. 4. Remove the drain plug and drain the sump. Unscrew the union nut and withdraw the thermometer bulb from its union; take care to prevent damage to the

Section I.
Bullit No. 2.

-6-

expellary nuts and ensure that the small jetty washer is not lost. Unclip both exhaust pipe flange nuts. Remove the oil filter complete and the engine bracket pipes and oil separator unit complete. Release the exhaust pipe clip from the clutch housing and the silencer front joint clip and remove both exhaust pipe nuts. Disconnect both anti-roll bar brackets from the chassis members and using the auxiliary lift, hoist rear of the engine base. Detach the torque converter bracket complete with bolts and pull it clear of the chassis before lifting.

Note: If the car is left-hand drive, the clutch pedal return spring anchorage bracket is fitted so the upper half bracket bolt is removed.

Remove the four bolts and nuts securing the rear face of the sump to the sump bell housing.

Note: If the car is right-hand drive, the clutch pedal return spring bracket will be released on removal of the right-hand bolt of the four referred to above.

Remove the twenty-one bolts securing the sump flange to the cylinder block. Note: The rear end of the sump will then be drawn to the rear away from the engine.

Remove and discard the four point gaskets which are affixed to the sump by jointing compound.

Before fitting the sump, clean the mating flange faces of the sump, taking care not to allow any pliers to come between the bolts. Clean and dry the cylinder block flange face, then apply an even coating of good quality jointing compound to the sump faces. Fit a set of new joint gaskets and ensure that those fitted to the front and rear curved faces project upwards by approximately

1/16 in. above the top surface of each side flange gasket. This is to ensure a good seal to be maintained after the gaskets have been compressed. Spread a liberal quantity of grease over the upper surfaces of the gaskets, then refit the snap to the cylinder block and secure it with the twelve one inch bolts and spring washers. Do not omit the weather pipe (subassembly) clip beneath the base of all of the oil filter assembly brackets.

At this stage it is important to note that there is no separate gearbox bracket as with previous types of engine. It is therefore necessary to check that the rear face of the snap is perfectly level with the cylinder block face (or the gearbox bracket is positioned) and that there is no gap between the clutch bell housing and the snap face when the snap is made secure. Failure to do this may result in a cracked snap when the clutch bell housing bolts are finally tightened.

Insert the four bolts of the clutch racing, fit the sprung washer and nuts and tighten evenly. If the engine is a right-hand drive, fit the master plus return spring bracket beneath the nut and sprung washer of the extreme right-hand bolt. The sequence of the assembly procedure is the reverse of that given for dismantling.

ENGINE COOLANT SYSTEM

Description

The radiator is ventilated via the front cold chamber on the left-hand side of the engine aft of the engine. The front position chamber cover is provided with a location for the oil separator unit free from the pipe merges. The cover plate is fastened to a flange on the front of the snap and to the frame by

which may decompose and be returned to the engine. The upper pipe extends upward from engine over and downward to the rear and is open to atmosphere below deck level in order to clear any fumes from the engine bay. The lower extremity of the pipe is fitted with a flexible extension to avoid the risk of damage in ground operations.

Note: No pipe connection is fitted between the air cleaner filter and the forward intake restrictor cover. The connection will be to filter case as blanked off.

Maintenance


Remove and clean the separator unit when the engine oil is changed after every 2,000 miles (3,200 km.).

Draining and refitting

Remove the air cleaner unit as described in Section 1 page 24, omitting reference to the pipe connection between the air cleaner and cold air intake and the forward restrictor box cover. Loosen the pinch bolt in the upper pipe connection of the separator unit, draw the flexible接管 into the bottom of the lower (drain) pipe and withdraw the separator unit. Reverse the above procedure for refitting but make sure that the joint surface (fitted into the separator unit joint case) is in good condition. Do not use more than four pressure on the flexible接管 unit.

FIG. 1. Bridge laboratory diagram.

Section A.
Bridges No. 3.






Fig. 1. Engine lubrication diagram.




Fig. 3. H.H. pump




Fig. 4. Pumping the sump.



WORKSHOP MANUAL

Section No. 1

Bulletin No. 1

Subject: INTEGRAL OIL COOLER

1. EXAMINE CAREFULLY THE INTEGRAL OIL COOLER
FITTED IN THE CYLINDER BLOCK BEHIND THE
CLUTCH SHAFT.

In some of the earlier engines, an oil cooler was fitted into a chamber formed along the right-hand side of the cylinder block, and instructions given on pages 30 to 33 of this section recommended that the AVI cooler element should be removed and discarded, and a blanking plate G.P.231 fitted.

Experience has shown that when this cooler has been carried into the blanking plate it subject to corrosion, and if allowed to continue results finally in leakage between the oil and water systems, the first indication being the presence of oil in the radiator.

If the recommended blanket G.P.231 fails after say 12 months, all such engines should be drained of oil, the oil cooler body removed and the blanking plate examined. If the blanking plate is corroded excessively, it must be replaced by a similar-shaped plate as follows:-

Blanking Plate G.P.232.

If leakage has occurred (as shown by oil in the radiator) drain both the water system, heat blanket or jacket and the engine sump, thoroughly clean out the cooling system before refilling with fresh water.



WORKSHOP MANUAL

Section - 1

Bulletin No. 3

Subject:-

FITTING AN EXTERNAL OIL COOLER TO LADA

TYPE 401 CARS AND TYPE 403 CARS.

INTRODUCTION

The following cars may be fitted with an external oil cooler together with the necessary piping and bypass valve without modification to existing components.

Type 401 Cars From chassis No. 1071 onwards.

Type 403 Cars all cars.

An external cooler is not strictly necessary for normal use on a car in this country, but for competition work or sustained high speed travel, an oil cooler is recommended. This increases the oil ~~capacity~~ of the system by 1 pint approximately.

If the cooler is considered unnecessary for a period after installation, it may readily be disconnected from the engine oil filter. The ports blanked off and the oil cooler inlet and outlet pipes blanched and taped to one side.

Following are details of the work involved and an illustration of the assembly in position; a list of the parts required is given at the end of the bulletin.

SUPPLY THE OIL COUNTER


1. Remove the hood from the car.
2. Raise the oil cooler (item 1) between the front of the radiator core and the front grille and locate it between the flanges of the existing brackets. Do not strain the hoses. Secure to the position with all three nuts-nuts (item 2) on the off-side and the lower nut-screw only on the near-side.
3. Locate the upper bracket (item 6) and secure it with the two outer nuts-nuts.
4. Remove both forward facing blanking plugs from the engine oil filter head, and fit a valve (item 8) to each outlet port with a washer (item 4) interposed.
5. Tie a flexible oil pipe (item 3) between the neck of the front engine mounting bracket and connect the rear end to the inner fitting of the filter head and the forward end to the upper fitting of the oil cooler. Tighten both nuts securely, making sure that the pipe is not twisted.
6. Tie the second flexible pipe (item 3) alongside the just fitted and connect its rear end to the outer fitting of the filter head and the front end to the lower connection of the oil cooler. Tighten the nuts securely, insuring that the pipe is not twisted.
7. Fit the outer (inner) cap (item 7) to the outer nut and outer stub of the oil cooler as indicated in the illustration, and with suitable packing interposed, secure it with the centrally-located nut-nut plain washer, waterproof washer and cap (item 3).
8. Remove the side blanking plug from the engine oil filter head and tie in the correct part of the bypass valve assembly (items 5 and 6) in that order followed by the plug (item 1) with the washer (item 10) interposed between the head of the plug and the filter head.
9. Check that the oil level in the sump is correct, then start up the engine and run at a fast idler speed until the oil temperature has reached 70°C . Run for a further 5 minutes. Stop the engine, withdraw the oil tool and top up the sump.

LIST OF PARTS RECORDED

Line No.	Description	Part No.	Quantity
1	Oil masher,	-	1
2	Set screw 4 in. D.D.T.	R.G. 400/TB	7
3	Plain washer 4 in.	-	7
4	Oilproof washer 4 in.	1214 Code Wash.	7
5	D.D.T. set 4 in.	R.G. 400/TB	3
6	Base, filter head/oil pipe.	R. 361100	2
7	Filter base with item 3 adjacent to oil outlet unions.	R. 364590	2
8	By-pass valve.	R. 361090	1
9	Spring.	R. 360560	1
10	Washer.	R. 361570	1
11	Plug.	R. 362400	1

Section 1
Bulletin No. 3

- 4 -





WORKSHOP MANUAL

Section No. 1

Bulletin No. 6

Subject:-

FITTING A SUMP COOLING SCOOP TO TYPES 400 AND 401 CARS

INTRODUCTION

To assist in cooling the oil in the engine sump, a sump cooling scoop has been introduced, which can be fitted as an option.

The scoop is fitted in close proximity to the sump, taking in air at the forward end and directing it in a free passage throughout the length of the sump.

By this action, the temperature of the oil can be reduced at a large level, at the same time maintaining its viscosity.

The parts required when fitting the sump cooling scoop are listed below.

For types 400 and 401 cars.


Part No.	Description	No. ref.
R.432001	Sump cooling scoop	1
R.632011	Bracket	1
	2 B.A. belt, banjo fast, 1in. long	3
	2 B.A. waterproof washer	3
	2 B.A. nut	2
RS.107/1D	Set screws	2

<u>Part No.</u>	<u>Description</u>	<u>No. off</u>
For type 400 cars only:		
N.705795	Front plate carrier	1

To fit the wiper and the scoop, carry out the following procedure:

1. Raise the car on a ramp, or alternatively, jack up the car and place wood blocks under the chassis wide members, then lower the car on to the wood blocks and remove the jack.
2. From beneath the car, remove and discard the lower bolt from each of the two engine front mounting brackets, fit the scoop attachment bracket Part No. N.65201 into position and hold by loosely fitting the two rear anti-sabot, Part No. P.107/88.
3. Remove the two lowermost bolts securing the clutch housing to the bell housing.
4. Remove the upper longer buffer bracket mounting bolt, then fit the scoop, Part No. N.65201 into position, retaining the two studs in the rear and place with the two loosened clutch mounting, and with the rear stud placed behind the torque buffer bracket.
5. Given that there is an almost 1/2" clearance between the scoop and the base of the wiper, and that the wiper does not foul the front suspension member, the oil filter, the oil temperature auxiliary or the exhaust pipes.
6. Check the alignment of the bolt holes in the front end of the scoop with those in the attachment bracket. If necessary, enlarge the holes in the scoop, then secure the scoop to the bracket with four 2 B.A. bolts, shakleproof washer and nuts.
7. Tighten the clutch case and engine mounting bolts securely.
8. Drill the torque buffer bracket and secure the scoop to the bracket with a 2 B.A. bolt, shakleproof washer and nut.
9. (Applicable to type 400 only) To provide an unrestricted air-flow through the scoop, detach the front registration plate from its carrier, remove the carrier from the mounting and substitute the side carrier, Part No. N.705795. Fit the registration plate to the side carrier.
10. Early type 400 cars have a deep bumper fairing; this must be removed immediately before the rear number plate carrier and up to the bottom of the number plate, to facilitate the flow of air into the scoop.

11. When the pump is to be drained, it will be necessary to use a box spanner to remove the pump drain plug and to ensure that the oil does not drain into the sump and run out the drain sink. After this operation has been completed and the drain plug has been tightened, ensure that any oil that may have been spilled inside the sump is cleaned out.






Type 4121 part

SOLUTION 1


(+)



Positive side of plate

(viii)

SECTION 1



2007.001 - 1.


(7811)




2007.001 - 1
7811

(100A)

SECTION I



Type 100A Regime



Type 100A Engine

L A T R O U B L E C O D E

This manual is intended to provide information on the manufacture, repair and general care of British 4CV, 4DL, and 4DX type cars. The text is grouped under the various units having given in the index and therefore provides a method of ready reference. The author may be subject to amendment without notice and it is therefore essential that holders of manuals should notify the Enquiry of any change of address. Supplementary information may be issued from time to time as necessary in the form of "Service Bulletins" and these should always be regarded as overriding the information given in this manual. Bulletins should be filed immediately at the rear of the relevant Section of this manual, and the Bulletin Index Sheet at the front of each Section should be referred accordingly.

SPECIAL INSTRUCTIONS

When ordering replacement parts, always:-

- (a) Quote the Car Number in full.
- (b) Quote the Engine Number in full.
- (c) Quote the Chassis Number in full.
- (d) Give the Part Number, the number of parts required and the full description of the parts as given in the relevant Spare Part Handbook. To avoid mistakes and to expedite delivery, use only the wording and Part Numbers given in the Spare Part Handbook.
- (e) If in any doubt, send the old part with the request for a spare.
- (f) Order from the nearest authorized "British" Agent. There this is impossible, order direct from the Company.

NOTE: - Left and right-hand side of the car is always
indicated as from the driving position. This
should be carefully noted when steering left or
right-hand parts.

Orders given by telephone or telegraph should be confirmed immediately, in
writing.

The Car Number Plate is attached to the bonnet on the right-hand side of
the car under the bonnet.

The Engine Number Plate is attached to the front rocker box cover on the
left-hand side.

The Chassis Number Plate is attached to the chassis frame on the left-hand
side under the bonnet in the vicinity of the petrol pump.

CONTENTS

**ABSTRACTS
RECOMMENDED INSPECTION
SERVING AND CHASSIS INSPECTION METHODS**

Section 1	Engine and exhaust system
Section 2	Radiator cooling system
Section 3	Fuel system
Section 4	Clutch and clutch adjustment
Section 5	Brake and propeller shaft
Section 6	Front axle and rear suspension
Section 7	Front suspension
Section 8	Braking system
Section 9	Steering gear
Section 10	Power, brake lines, hoses and hoses
Section 11	Electric transmission
Section 12	"One shot" (instant) lubrication system
Section 13	Electrical system
Section 14	Body
Section 15	Storage

卷之三

10

2023年7月6日

Their weight - except for one.

Top gear speed at 1,000 r.p.m. 10.00 miles (16.09 km./hr.)

Turritis glabra — Left and right — 1000 ft. 1000 ft. 1000 ft.

Leptothrix schenckii = *nitidum*

ANSWER

Type	Age	Sex	Length	Width	Height	Weight	Color	Remarks
Type A-00	11	♂	11.0	4.0	1.0	10.0	195, 240, 160	cm. 3
Type A-01	11	♂	11.0	4.0	1.0	10.0	195, 240, 160	cm. 3
Type A-02	11	♂	11.0	4.0	1.0	10.0	195, 240, 160	cm. 3

Digitized by srujanika@gmail.com

卷之二

Type 600	1.0	0.9	1.1	1.0	0.9	0.8	0.8	0.8
Type 601	1.1	1.0	1.1	1.0	0.9	0.8	0.8	0.8
Type 602	0.9	0.8	1.0	1.0	0.9	0.8	0.8	0.8

Bank Account = Fourside Nine-Card Game Fund = \$61,000.00 (\$37.16 = 1)

Suspension - front, rear, ... etc. **Todoparalelo** springing **angle**
etc. & orientation. Just **service**

Region	Type A20	Type A21	Type A22	Type A23	Type A24	Type A25	Type B3 or B3A	Type B3B or B3C	Type B3D or B3E
North America	+++	++*	++*	++*	++*	++*	+++	+++	+++
Europe	+++	++*	++*	++*	++*	++*	+++	+++	+++
Australia	+++	++*	++*	++*	++*	++*	+++	+++	+++
Distribution:									W. Europe and N. America south with extension to S. Amer. and S.E. Asia. Presently least permitted in U.S. ports.
Habitat:									Salt in dry place. Bury and back type salt.

七、对本办法的修改和废止，由市人民政府决定。

Temperature	Pressure	System	Reference
from 20°C. to 80°C.	10 ⁻² atm. to 1 atm.	Methyl 16.1 Å. Cantrot 21. Shell S-130 U.A.S. 70. Kawabata 10. Koropat S.A.S. 70.	
at 32°C., up to 100°C., 10 ² atm., 10 ⁻² atm.	10 ⁻² atm. to 1 atm.	Methyl 16.1 Å. Cantrot 21. Shell S-130 U.A.S. 70. Kawabata 10. Koropat S.A.S. 70.	
at 40°C., 10 ⁻² atm., 10 ² atm., 10 ⁻² atm.	10 ⁻² atm. to 1 atm.	Methyl 16.1 Å. Cantrot 21. Shell S-130 U.A.S. 70. Kawabata 10. Koropat S.A.S. 70.	
at 40°C., 10 ⁻² atm., 10 ² atm., 10 ⁻² atm.	10 ⁻² atm. to 1 atm.	Methyl 16.1 Å. Cantrot 21. Shell S-130 U.A.S. 70. Kawabata 10. Koropat S.A.S. 70.	
Under -0.02 atm., (-23°C.)	10 ⁻² atm. to 1 atm.	Methyl 16.1 Å. Cantrot 21. Shell S-130 U.A.S. 70.	

Temperature	Subrinate					
	Capitol					
Over 32°F. (0°C.)	Mobilite 20, Castrol 20, Shell Dentax 30, Essoolite 30, Engel S.A.E. 30.
Under 32°F. (0°C.)	Mobilite A, Castrol A, Shell Dentax 30, Essoolite 30, Engel S.A.E. 30.
Bear. axle						
Over 32°F. (0°C.)	Mobilene GL 140, Castrol HI grade, Shell Spirax 140 EP, Exxon Super. Compound 140, Engel EP. S.A.E. 140.
Under 32°F. (0°C.)	Mobilene GL 90, Castrol Hyper, Shell Spirax 90EP, Exxon Super. Compound 90, Engel EP. S.A.E. 90.
"One shot" lubrication						
Over 32°F. (0°C.)	Mobilite 20, Castrol 20, Shell Dentax 30, Essoolite 30, Engel S.A.E. 30.
Under 32°F. (0°C.)	Mobilite A, Castrol A, Shell Dentax 30, Essoolite 30, Engel S.A.E. 30.
"Bristol" type shock absorbers						
All temperatures	Mobil shock absorber light oil Bakelite gaiter damping oil - thin. Castrol Xynol. Shell Drene - A.L. Exxon Shock absorber oil. Benzol S.A. light.

(cont.)

Temperature	Preparation	Lubricant
Preparation small		
All temperatures	...	Mobilube G. Castrol Hi-grade. Shell Spirax 140 EP. Bassi Express Compound 140. Energol S.A.E. 150.
Preparation large		
All temperatures	...	Mobil Hi-grade. Castrolane Heavy, Shell Helix A or B. Bassi Urineo. Delsoline G.
Front and rear suspension units		
Over 32°F. (0°C.)	...	Mobilvis SE. Castrol XL. Shell Rustar 90. Bassi 90. Energol S.A.E. 30.
Under 32°F. (0°C.)	...	Mobilvis A. Castrol XL. Shell Rustar 10. Bassi 30. Energol S.A.E. 30.
Water pump and fan (when external grease cap is fitted)		
All temperatures	...	Mobil Hi-grade. Castrolane Heavy. Shell Helix A or B. Bassi Grease. Delsoline G.
Distributor (Bosch type)		
All temperatures	...	Mobilvis Arctic. Castrolite. Shell L-100 S.A.E. 30. Bassi Heavy Oil. Energol S.A.E. 30.

(cont.)

ENGINES AND TRANSMISSIONS

LUBRICATION POINTS

1. Front wheel hub. Park with engine above 12,000 miles. Capacity 4 oz.
2. "One shot" lubrication system reservoir. Refill every 1,000 miles. Capacity 2 pds.
3. Hydraulic rear motor cylinder. Check fluid level every 1,500 miles and refill if necessary. Capacity 1 pt.
4. Front universal joint. Grease every 3,000 miles.
5. "Borexol" type rear shock absorbers. Check fluid level every 3,000 miles and refill if necessary. Capacity 1 pt.
6. Rear axle casing. Change oil after first 500 miles and then every 6,000 miles. Check oil level every 3,000 miles. Capacity 3 to 4 pts.
7. Rear universal joint. Grease every 3,000 miles.
8. Bearings. Change oil after first 500 miles and then every 6,000 miles. Check oil level every 3,000 miles. Only fill to bore plug. Capacity 34 to 36 pts. The bore plug is at the bottom of the gearbox.
9. Engine. Change oil after first 500 miles and then every 1,500 miles. The engine drain plug is situated on the left-hand side of the case. Capacity 10 pds. Replace the filter element (or breast assembly) every 5,000 miles.
10. Brake oil pipes/tank. Check oil level every 500 miles. Do not check while the engine is running.
11. "Borexol" type front shock absorbers. Check fluid level every 3,000 miles and refill if necessary. Capacity 0 pt.
12. Power pump and fan bearing. Refill grease cup (if filled after first 500 miles) and then every 1,500 miles thereafter.