



FIG. 34. ELECTRICAL WIRING DIAGRAM. * EARLIER MODELS—THE PETROL PUMP FUSES ARE FITTED SEPARATELY, INSTEAD OF BEING TAKEN OFF THE MAIN FUSE BOARD.